

Winter Wonder Lane 060-1713-0 2

Winter Wonder Lane 8-Foot Light-Up String Cone Twinkle Tree Instruction Manual

Model: 060-1713-0 2

1. INTRODUCTION

Thank you for purchasing the Winter Wonder Lane 8-Foot Light-Up String Cone Twinkle Tree. This product is designed to provide festive illumination for your indoor or outdoor holiday display. Please read this manual thoroughly before assembly and operation to ensure safe and proper use.

1.1 Package Contents

- Cone Tree Frame (sections)
- LED Light Strings (pre-attached)
- Star Topper with LED Lights
- Control Box
- Power Adapter
- Ground Stakes (for outdoor use)
- Extra Bulbs
- Spare Fuse
- Instruction Manual

2. IMPORTANT SAFETY INFORMATION

Please observe the following safety precautions to reduce the risk of fire, electric shock, or injury.

- **Read all instructions:** Before installing and using this product.
- **Indoor/Outdoor Use:** This product is suitable for both indoor and outdoor use. Ensure all electrical connections are protected from moisture when used outdoors.
- **Power Source:** Use only the provided power adapter. Do not connect to another power source.
- **Electrical Safety:** Do not overload electrical outlets. Do not run power cords under carpeting or through furniture. Inspect cords for damage before each use.
- **Assembly:** Assemble the product completely before connecting to power.

- **Placement:** Place the tree on a stable, level surface. For outdoor use, secure with ground stakes to prevent tipping.
- **Maintenance:** Unplug the product before performing any maintenance or cleaning.
- **Children and Pets:** Keep away from small children and pets. This is not a toy.
- **Storage:** Store in a cool, dry place when not in use.

3. SETUP INSTRUCTIONS

Follow these steps to assemble your Light-Up String Cone Twinkle Tree.

3.1 Unpacking

1. Carefully remove all components from the packaging.
2. Inspect all parts for damage. If any parts are damaged or missing, do not proceed with assembly and contact customer support.

3.2 Assembly

1. **Assemble the Frame:** Connect the metal frame sections according to the diagrams. Ensure all connections are secure. The frame will form a cone shape.
2. **Attach Light Strings:** The LED light strings are typically pre-attached to the frame sections. Ensure they are not tangled and are evenly distributed.
3. **Install Star Topper:** Carefully place the star topper onto the top of the assembled cone frame. Connect its power cable to the designated connector on the main light string.
4. **Positioning:**
 - **Indoor Use:** Place the tree on a flat, stable surface away from heat sources and flammable materials.
 - **Outdoor Use:** Choose a level outdoor location. Secure the base of the tree to the ground using the provided ground stakes. Ensure the power adapter and control box are protected from direct weather exposure.
5. **Connect Power:** Once the tree is fully assembled and positioned, connect the power adapter to the control box, and then plug the adapter into a standard electrical outlet.




Image 1: Fully assembled 8-foot Light-Up String Cone Twinkle Tree with star topper and LED lights.



Image 2: Detail of product features including size, number of lights, multi-functions, and included accessories.

4. OPERATING INSTRUCTIONS

Your Light-Up String Cone Twinkle Tree features a control box to manage the light patterns.

4.1 Powering On/Off

Plug the power adapter into a suitable electrical outlet to power on the tree. Unplug the adapter to power off the tree.

4.2 Changing Light Patterns

The control box has a button to cycle through 16 different light functions. Press the button repeatedly to select your desired pattern.

- **Available Functions:** Combination, Steady on, Dim to Bright, Alternative Twinkling, Glow, Fade, Chasing, and more.

5. MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your Twinkle Tree.

5.1 Cleaning

Unplug the tree from the power source before cleaning. Use a soft, dry cloth to gently wipe down the frame and lights. Do not use abrasive cleaners or immerse any part of the product in water.

5.2 Bulb Replacement

If a bulb burns out, replace it with one of the provided extra bulbs. Ensure the tree is unplugged before replacing bulbs. Carefully twist out the old bulb and insert a new one.

5.3 Fuse Replacement

If the entire tree fails to light up, check the fuse in the power adapter plug. Unplug the adapter, open the fuse compartment, and replace the fuse with the provided spare fuse if necessary. Refer to the power adapter for specific fuse replacement instructions.

5.4 Storage

When not in use, unplug the tree and carefully disassemble it in reverse order of assembly. Store all

components, including the frame, light strings, star topper, control box, power adapter, ground stakes, and spare parts, in their original packaging or a suitable storage container in a cool, dry place, protected from extreme temperatures and moisture.

6. TROUBLESHOOTING

If you encounter issues with your Light-Up String Cone Twinkle Tree, refer to the following common problems and solutions.

- **Tree does not light up:**
 - Ensure the power adapter is securely plugged into a working electrical outlet.
 - Check all connections between the light strings, control box, and power adapter.
 - Inspect the power cord for any damage.
 - Check and replace the fuse in the power adapter plug if it is blown (refer to Section 5.3).
 - Ensure all bulbs are properly seated. Replace any burnt-out bulbs (refer to Section 5.2).
- **Some lights are out:**
 - Identify and replace any burnt-out bulbs (refer to Section 5.2).
 - Check for loose connections in the light string sections.
- **Light patterns are not changing:**
 - Ensure the control box button is functioning correctly. Press it firmly.
 - Unplug the tree for a few minutes and then plug it back in to reset the control box.
- **Tree is unstable (outdoor use):**
 - Ensure all ground stakes are fully inserted into the ground.
 - Verify the tree is placed on a level surface.
 - Consider additional anchoring in windy conditions.

If these steps do not resolve the issue, please contact customer support.

7. SPECIFICATIONS

Feature	Detail
Model Number	060-1713-0 2
Dimensions (L x W x H)	45 x 45 x 96 inches (8 Feet Tall)
Item Weight	12 pounds
Number of LED Lights	144 (tree) + 10 (star) = 154 total
Light Color	Cool White
Light Functions	16 Multi-Functions
Frame Material	Metal
Material	Metal, Plastic
Recommended Use	Indoor/Outdoor Holiday Decoration

Manufacturer	Winter Wonder Lane
--------------	--------------------

8. WARRANTY AND CUSTOMER SUPPORT

For warranty information or assistance with your Winter Wonder Lane Light-Up String Cone Twinkle Tree, please contact the retailer or manufacturer directly. Keep your proof of purchase for warranty claims.

For further support or inquiries, please refer to the contact information provided with your purchase or visit the Winter Wonder Lane official website.