

VINABTY RM-C3607

VINABTY RM-C3607 Replacement Remote Control User Manual

For JVC Television Models

1. INTRODUCTION

This manual provides comprehensive instructions for the VINABTY RM-C3607 infrared replacement remote control. It is designed to function as a direct replacement for your original JVC TV remote, requiring no complex programming or setup. This remote control offers a user-friendly experience with clear buttons and an ergonomic design.

2. SAFETY INFORMATION

- Keep batteries out of reach of children.
- Do not mix old and new batteries, or different types of batteries.
- Ensure correct battery polarity (+/-) when inserting.
- Remove batteries if the remote control will not be used for an extended period.
- Dispose of used batteries according to local regulations.
- Avoid exposing the remote control to direct sunlight, heat sources, or moisture.

3. PACKAGE CONTENTS

- 1 x VINABTY RM-C3607 Replacement Remote Control

Note: Batteries are not included and must be purchased separately. Two AAA 1.5V alkaline batteries are required.

4. PRODUCT FEATURES

- **Infrared Technology:** Operates via infrared sensor, ensuring reliable communication with your TV.
- **No Programming Required:** Ready to use directly out of the box after battery insertion.
- **User-Friendly Design:** Features clear, well-arranged buttons for intuitive operation.
- **Extended Range:** Effective transmission distance of approximately 8 to 10 meters.
- **Ergonomic and Lightweight:** Comfortable to hold and use for extended periods.
- **Durable Construction:** Made from robust ABS material for long-lasting performance.

5. SETUP: BATTERY INSTALLATION

Follow these steps to install batteries into your remote control:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch to open it.
3. Insert two new AAA 1.5V alkaline batteries, ensuring that the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.





Figure 1: Back view of the remote control with the battery compartment open, illustrating correct battery insertion.

Once batteries are installed, the remote control is ready for immediate use with compatible JVC TV models without any further programming.

6. OPERATING INSTRUCTIONS

To operate your JVC TV with the VINABTY RM-C3607 remote control, point the remote directly towards the TV's infrared receiver. Ensure there are no obstructions between the remote and the TV.





Figure 2: Front view of the VINABTY RM-C3607 remote control with button layout.

Button Functions:

- **Power Button** (): Turns the TV on or off.
- **Number Buttons (0-9)**: Selects channels directly.
- **LANG. Button**: Changes audio language or subtitle options.
- **Volume Up/Down (+ / -)**: Adjusts the TV volume.
- **Mute Button** (): Mutes or unmutes the TV sound.
- **Channel Up/Down (^ / v)**: Changes TV channels sequentially.
- **Navigation Buttons** (◀▶ ▲ ▼): Navigates through menus and options.
- **OK Button**: Confirms selections in menus.
- **Back Button** (←): Returns to the previous menu or screen.
- **EXIT Button**: Exits the current menu or application.
- **NETFLIX / YouTube / Gogle Play / Prime Video Buttons**: Direct access to streaming applications.
- **MENU Button**: Opens the TV's main menu.
- **Media Control Buttons** (): Play, Pause, Stop, Fast Forward, Rewind for media playback.
- **TEXT Button**: Accesses Teletext services.
- **Colored Buttons (Red, Green, Yellow, Blue)**: Functionality varies depending on the TV menu or application.

7. COMPATIBLE JVC TV MODELS

The VINABTY RM-C3607 remote control is compatible with the following JVC TV models:

- LT-39VAH3055
- LT-42VAF3055
- LT-24VAH3335
- LT-32VAH3035
- LT-43VA3335
- LT-43VAQ6235
- LT-50VA3300
- LT-55VA3200
- LT-43VA3000
- LT-43VA3200
- LT-43VA3205I
- LT-65VA3205I
- LT-50VAQ6235
- LT-50VAQ7235
- LT-55VAQ6235
- LT-55VAQ7235
- LT-55VAQ8235
- LT-65VAO9335
- LT-65VAQ6235
- LT-65VAQ8235
- LT-70VAQ7235
- LT-75VA6335
- LT24VAH3335
- LT32VAH3035
- LT43VA3335
- LT43VAF3335
- LT43VAQ6235
- LT50VA3300
- LT50VAQ6235
- LT50VAQ7235
- LT55VAQ6235
- LT55VAQ7235
- LT55VAQ8235
- LT65VAQ8235
- LT70VAQ7235
- LT75VA6335
- LT65VAO9335
- LT65VAQ6235

8. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the remote control. Do not use liquid cleaners, abrasive pads, or chemical solvents, as these may damage the surface or internal components.
- **Battery Replacement:** Replace batteries promptly when the remote's response becomes sluggish or

inconsistent. Always replace both batteries at the same time.

- **Storage:** If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage. Store in a cool, dry place.

9. TROUBLESHOOTING

Problem	Possible Cause	Solution
Remote control is not working.	<ul style="list-style-type: none">◦ Batteries are dead or inserted incorrectly.◦ Obstruction between remote and TV.◦ Remote control is too far from the TV.	<ul style="list-style-type: none">◦ Replace batteries with new ones, ensuring correct polarity.◦ Remove any objects blocking the line of sight to the TV's IR receiver.◦ Move closer to the TV (within 8-10 meters).
Buttons are unresponsive or delayed.	<ul style="list-style-type: none">◦ Low battery power.◦ Infrared emitter is dirty.	<ul style="list-style-type: none">◦ Replace batteries.◦ Clean the infrared emitter at the front of the remote with a soft, dry cloth.

10. SPECIFICATIONS

Brand	VINABTY
Model	RM-C3607
Dimensions (L x W x H)	18 x 5 x 1 cm (approximately 7.09 x 1.97 x 0.39 inches)
Weight	60 grams (approximately 2.12 ounces)
Connectivity Technology	Infrared (IR)
Battery Type	2 x AAA 1.5V Alkaline Batteries (not included)
Maximum Range	10 meters (approximately 33 feet)
Number of Buttons	25
Material	ABS

11. SUPPORT AND CONTACT

If you encounter any issues with your VINABTY RM-C3607 remote control or have questions regarding its compatibility, please contact the seller or manufacturer's customer support for assistance. Providing your TV model number may help expedite support.

For general inquiries or to verify compatibility before purchase, please reach out to customer service.