

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Wahl](#) /

› [Wahl Pro Animal Curly Coat KM 2-Speed Pro Clipper Instruction Manual](#)

Wahl KM 2-Speed Pro Clipper

Wahl Pro Animal Curly Coat KM 2-Speed Pro Clipper Instruction Manual

Model: KM 2-Speed Pro Clipper

Brand: Wahl

INTRODUCTION

This manual provides detailed instructions for the safe and effective use of your Wahl Pro Animal Curly Coat KM 2-Speed Pro Clipper. Designed for efficient pet grooming, this corded clipper is suitable for various coat types, including curly and coarse hair. Please read all instructions carefully before initial use and retain this manual for future reference.

SAFETY INFORMATION

WARNING: To reduce the risk of electric shock, injury, or fire, always follow these basic safety precautions:

- Always unplug the clipper before cleaning or changing attachments.
- Keep the clipper away from water sources. Do not use near bathtubs, showers, basins, or other vessels containing water.
- Do not use the clipper on infants or children without adult supervision.
- Exercise caution when using the clipper on animals, as they may move suddenly.
- Always keep the clipper in sight when in use to prevent accidents.
- Always store the clipper out of reach of children and pets when not in use.
- Always follow the recommended cleaning and maintenance procedures to ensure the clipper's safety and longevity.

WHAT'S INCLUDED

Your Wahl Pro Animal Curly Coat KM 2-Speed Pro Clipper package includes the following items:

- Wahl KM 2-Speed Pro Clipper (Corded)
- Power Adapter
- #30 Competition Series Blade (pre-attached or separate)
- Stainless Steel Guide Combs: #E (1" or 25mm) and #0 (5/8" or 16mm)
- Cleaning Brush
- Clipper Oil
- Instruction Manuals





Image: The Wahl Pro Animal Curly Coat KM 2-Speed Pro Clipper with its cord and blade.

Your browser does not support the video tag.

Video: An unboxing and demonstration of the Wahl Pro Animal Clipper, showing its components and initial use.

SETUP

- 1. Unpack Components:** Carefully remove all items from the packaging.
- 2. Inspect Clipper:** Ensure the clipper and all accessories are free from damage.
- 3. Attach Blade:** If the #30 Competition Series Blade is not already attached, align the blade with the clipper head and snap it into place until it clicks securely.
- 4. Attach Guide Comb (Optional):** For desired coat length, slide one of the stainless steel guide combs onto the blade until it locks. Ensure it is firmly seated.
- 5. Lubricate Blade:** Before first use, apply a few drops of the provided clipper oil to the teeth and sides of the blade. This ensures smooth operation and prolongs blade life.

CURLY COAT CLIPPER

ANIMAL GROOMING



POWER THROUGH ALL COATS

Effortlessly powers through all coat types, from curly to coarse, for a stress-free home grooming.

CONTINUOUS CLIPPING

Corded design ensures you have consistent power throughout your entire groom.

ACHIEVE YOUR PERFECT COAT

Comes with stainless steel guide combs (#E - 1" or 25mm & #0 - 5/8" or 16mm) to help you achieve the perfect coat length with ease.



Image: The Wahl Curly Coat Clipper demonstrating the attachment of guide combs for various lengths.

OPERATING INSTRUCTIONS

The Wahl KM 2-Speed Pro Clipper features a powerful motor and two speed settings for versatile grooming.

- Connect Power:** Plug the power adapter into the clipper and then into a suitable electrical outlet. The 14-foot cord provides ample reach for grooming.
- Select Speed:** Use the switch on the clipper body to select your desired speed setting. The two speeds are approximately 3,000 and 3,700 RPMs. The lower speed is ideal for sensitive areas or quieter operation, while the higher speed provides maximum power for thick or matted coats.
- Grooming Technique:** Hold the clipper firmly and move it smoothly against the direction of hair growth. For best results, ensure the animal's coat is clean, dry, and free of tangles.
- Monitor Blade Temperature:** During extended use, blades may become warm. If the blade becomes too hot to touch, turn off the clipper, remove the blade, and allow it to cool. Using a blade coolant spray can also help manage temperature.
- Turn Off:** After grooming, switch the clipper to the 'off' position and unplug it from the power outlet.

Curly coats?

WE GOT YOU!

TWO POWERFUL SPEEDS

This powerful 2-speed clipper makes grooming easier and more efficient.




Image: The Wahl Curly Coat Clipper being used on a curly-coated dog, highlighting its two powerful speeds.

Trusted by industry professionals



2-SPEED CLIPPING

Quickly change between 3,000 & 3,700 RPMs.



14-FOOT CORDED DESIGN

Gives consistent power for efficient grooming.



Image: Close-up of the Wahl Clipper highlighting its 2-speed clipping and 14-foot corded design for consistent power.

MAINTENANCE

Proper maintenance ensures the longevity and performance of your clipper.

- **Clean Blades:** After each use, remove the blade and use the provided cleaning brush to remove any trapped hair.
- **Oil Blades:** Apply 2-3 drops of Wahl clipper oil to the blade teeth and friction points after each cleaning. Run the clipper for a few seconds to distribute the oil. This reduces friction, heat, and wear.
- **Store Properly:** Store the clipper and its accessories in a clean, dry place, away from extreme temperatures and moisture.
- **Cord Care:** Avoid wrapping the cord tightly around the clipper. Store it loosely to prevent damage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Clipper not turning on	Not plugged in; power outlet issue; damaged cord/adapter	Ensure clipper is securely plugged in. Test outlet with another device. Inspect cord for damage.
Clipper pulling hair or cutting poorly	Dull blades; dirty blades; insufficient oil; matted hair	Clean and oil blades. If still dull, consider replacing. Ensure pet's coat is clean and detangled before grooming.
Blades getting hot quickly	Lack of lubrication; prolonged use; dirty blades	Apply clipper oil frequently. Take breaks during long grooming sessions. Clean blades thoroughly. Use a blade coolant spray.
Excessive noise or vibration	Loose blade; internal issue	Ensure blade is securely attached. If problem persists, contact Wahl customer support.

SPECIFICATIONS

- **Product Dimensions:** 2 x 1.75 x 7 inches
- **Item Weight:** 12.96 ounces
- **Brand:** Wahl
- **Model:** KM 2-Speed Pro Clipper
- **Power Source:** Corded Electric
- **Speed Settings:** 2 (approx. 3,000 & 3,700 RPMs)
- **Cord Length:** 14 feet
- **Blade Type:** #30 Competition Series Blade
- **Included Guide Combs:** Stainless Steel #E (1"/25mm) & #0 (5/8"/16mm)
- **Manufacturer:** Wahl Clipper Corp.



Image: Visual representation of the Wahl Clipper's key features including two speed settings, corded design, and stainless steel combs.

WARRANTY AND SUPPORT



Wahl products are manufactured to the highest quality standards. For information regarding warranty, service, or repairs, please refer to the documentation included in your product packaging or contact Wahl directly.

Contact Information:

- **Phone:** 1-800-767-9245 (Monday-Friday 8am - 4pm CST)
- **Email:** techsupport@wahlclipper.com
- **Website:** wahlpro.com

PLEASE DO NOT RETURN PRODUCT TO STORE FOR QUESTIONS, ASSISTANCE, OR RETURNS. CONTACT US FIRST!

Related Documents - KM 2-Speed Pro Clipper

	<p>Wahl Multi Cut Pet Clipper Instructions</p> <p>Comprehensive instructions for operating, cleaning, and maintaining the Wahl Multi Cut Pet Clipper, including safety guidelines, grooming tips, and troubleshooting.</p>
	<p>Wahl Bravura Lithium Professional Cord/Cordless Clipper - Features and Specifications</p> <p>Discover the Wahl Bravura Lithium, a professional cordless clipper offering a 90-minute run time, adjustable 5-in-1 blade, and ergonomic design. Ideal for various grooming tasks on animals.</p>
	<p>Wahl Model 9164 Pet Grooming Clipper User Manual</p> <p>Comprehensive user manual for the Wahl Model 9164 pet grooming clipper, detailing operational steps, grooming styles, maintenance, and company contact information.</p>
	<p>Wahl Clipper User Guide and Haircutting Instructions</p> <p>Comprehensive guide to using Wahl clippers, including safety precautions, maintenance, and step-by-step haircutting instructions for various styles. Learn how to properly oil, align, and use guide combs for professional-quality haircuts at home.</p>
	<p>Wahl Pro Series Plus Cordless Clipper (8550-2401) - Professional Equine Grooming</p> <p>Discover the Wahl Pro Series Plus Cordless Clipper (Model 8550-2401), a medium-duty equine grooming tool designed for precision and ease. Features include a 1-hour cordless run time, powerful 6,000 SPM motor, and a bonus hoof pick. Ideal for trimming horses' faces, ears, bridle paths, and fetlocks. Includes detailed specifications, kit contents, and warranty information.</p>
	<p>Wahl KM2 Speed Clipper - Product Information and Care Guide</p> <p>Detailed information on the Wahl KM2 Speed Clipper, including its features, specifications, blade care, cleaning instructions, and servicing for double-insulated appliances. Essential guide for owners.</p>