Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

onerbl AC-DC Adapter (Compatible with Cobra MicroTalk CXR925, CXT450C, LI7200WX, LI3900DX, CXR800, PR4700 Series)

onerbl AC-DC Adapter Instruction Manual

For Cobra MicroTalk Radios (CXR925, CXT450C, LI7200WX, LI3900DX, CXR800, PR4700 Series)

1. Introduction

This manual provides essential instructions for the safe and effective use of your onerbl AC-DC Adapter. This adapter is designed to provide power to or charge the batteries of various Cobra MicroTalk two-way radios. Please read this manual thoroughly before use and retain it for future reference.

2. Safety Information

Observe the following safety precautions to prevent injury or damage to the product and connected devices:

- Use the adapter only with compatible devices as specified.
- Do not expose the adapter to water, moisture, or extreme temperatures.
- Avoid dropping or subjecting the adapter to severe impact.
- Do not attempt to disassemble or modify the adapter. This will void the warranty and may cause electrical shock or fire.
- Ensure the power outlet is easily accessible and unplug the adapter during lightning storms or when unused for long periods.
- Keep out of reach of children.
- If the adapter shows signs of damage (e.g., frayed cord, cracked casing), discontinue use immediately.

3. Package Contents

- 1 x onerbl AC-DC Adapter

Note: Compatible Cobra MicroTalk radio is sold separately.

4. Setup

Follow these steps to set up your onerbl AC-DC Adapter:

1. **Inspect the Adapter:** Before first use, visually inspect the adapter and its cable for any signs of damage.
2. **Connect to Device:** Insert the barrel connector end of the adapter cable into the power input port of your compatible Cobra MicroTalk radio. Ensure a secure connection.
3. **Connect to Power Outlet:** Plug the AC prongs of the adapter into a standard 120V AC electrical wall outlet.



Figure 4.1: The onerbl AC-DC Adapter, showing the main unit with AC prongs and the attached cable with a barrel connector.



Figure 4.2: The adapter connected to a power strip, demonstrating a typical setup for powering a device.

5. Operating Instructions

Once properly connected, the adapter will begin to supply power to your device or charge its battery. The operation is automatic.

- **Powering the Device:** The adapter provides continuous power to your compatible Cobra MicroTalk radio, allowing it to operate without relying on its internal battery.
- **Charging the Battery:** If your radio has a rechargeable battery, the adapter will charge it while connected. Refer to your radio's manual for specific charging indicators and times.

Important: Always ensure the adapter's output voltage and current match the requirements of your device to prevent damage.

6. Maintenance

Proper maintenance ensures the longevity and safe operation of your adapter:

- **Cleaning:** Disconnect the adapter from the power outlet and the device before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or solvents.
- **Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid tightly coiling the cable to prevent damage.
- **Cable Care:** Do not bend, twist, or pull the cable excessively. Avoid placing heavy objects on the cable.

7. Troubleshooting

If you encounter issues with your onerbl AC-DC Adapter, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No power to device/device not charging.	Adapter not fully plugged into outlet. Device not fully connected to adapter. Power outlet is not functioning. Adapter or cable is damaged. Device is incompatible.	Ensure adapter is securely plugged into a live outlet. Verify the barrel connector is firmly inserted into the device. Test the outlet with another working appliance. Inspect adapter and cable for visible damage. If damaged, discontinue use. Confirm your device model is listed as compatible.
Adapter feels warm during use.	Normal operation.	A slight warmth is normal. If the adapter becomes excessively hot or emits a burning smell, unplug it immediately and discontinue use.

8. Specifications

The following are the technical specifications for the onerbl AC-DC Adapter:

Feature	Detail
Brand	onerbl
Input Voltage	100-240VAC, 50/60Hz
Output Voltage	9VDC - 12VDC, 200mA (0.2A)
Connector Type	Barrel Connector
Special Feature	Short Circuit Protection, Over Voltage Protection, Over Heat Protection
Color	Black
Cable Length	76 inches (approx. 1.93 meters)
Dimensions (Adapter Body)	Approx. 2.6 inches (L) x 1.6 inches (W) x 1.2 inches (H)



Figure 8.1: Front and side views of the adapter, displaying input specifications (100-240VAC, 50/60Hz) and regulatory marks.




Figure 8.2: Diagram illustrating the physical dimensions of the adapter body (2.6 x 1.6 x 1.2 inches) and the cable length (76 inches).

9. Warranty and Support

For warranty information or technical support, please contact the manufacturer or seller directly through your purchase platform. Retain your proof of purchase for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DPFM7H5H

More documents and user manuals: **https://manuals.plus/**