

Generico kangqiling362154

Generico Acacia Wood Sun Lounger

Model: kangqiling362154

Brand: Generico

INTRODUCTION

Thank you for choosing the Generico Acacia Wood Sun Lounger. This manual provides essential information for the safe assembly, operation, and maintenance of your new sun lounger. Please read these instructions carefully before use and retain them for future reference.

SAFETY INFORMATION

- Ensure all components are securely fastened before use.
- Do not exceed the maximum weight capacity (not specified, use common sense for a single person).
- Keep children and pets away during assembly.
- Place the sun lounger on a flat, stable surface to prevent tipping.
- Avoid exposing the wood to extreme weather conditions for prolonged periods without proper protection.

PACKAGE CONTENTS

Please check that all parts are present before beginning assembly. If any parts are missing or damaged, contact customer support.

- Acacia Wood Lounger Frame (various sections)
- Dark Grey Cushion
- Dark Grey Pillow
- Assembly Hardware (screws, bolts, Allen key)
- Instruction Manual

SETUP AND ASSEMBLY

Assembly typically requires two adults. Lay out all components on a soft, clean surface to prevent scratches.

1. **Unpack Components:** Carefully remove all parts from the packaging and verify against the package contents list.

2. **Assemble Frame Sections:** Connect the main frame sections using the provided hardware. Ensure all bolts are finger-tightened initially.
3. **Attach Legs:** Securely attach the legs to the main frame using the appropriate screws and bolts.
4. **Final Tightening:** Once all parts are loosely assembled, gradually tighten all screws and bolts with the Allen key. Do not overtighten.
5. **Place Cushion and Pillow:** Position the dark grey cushion and pillow onto the assembled wooden frame.



Figure 1: Fully assembled sun lounger with cushion and pillow, backrest in flat position.



Figure 2: Side view of the sun lounger, showcasing the wooden frame and cushion.

OPERATING INSTRUCTIONS

The sun lounger features an adjustable backrest for optimal comfort.

1. **Adjusting the Backrest:** To adjust the backrest, gently lift the back section of the lounger. The support mechanism will allow you to select one of the 4 available reclining positions.
2. **Securing Position:** Ensure the backrest is securely locked into your desired position before applying full weight.
3. **Lowering the Backrest:** To lower, lift the backrest slightly past the highest position to disengage the locking mechanism, then gently lower it to the desired angle or fully flat.



Figure 3: Visual representation of the backrest adjustment, showing multiple reclining positions.



Figure 4: Sun lounger with the backrest set to a comfortable, raised position.

MAINTENANCE

Proper maintenance will extend the life and appearance of your sun lounger.

Acacia Wood Care

- **Cleaning:** Wipe the wood frame with a damp cloth and mild soap solution. Dry thoroughly immediately.
- **Oiling:** To maintain the wood's appearance and protect it from the elements, apply a suitable wood oil (e.g., teak oil) periodically, especially if stored outdoors. Follow the oil product's instructions.
- **Protection:** During harsh weather or prolonged periods of non-use, cover the sun lounger or store it indoors to prevent damage.



Figure 5: Detail of the acacia wood slats and the dark grey cushion.



Figure 6: Close-up view of the robust acacia wood construction.

Cushion Care

- **Cleaning:** Spot clean the cushion with a mild soap and water solution. Do not machine wash unless specified on the cushion's care label.
- **Drying:** Allow cushions to air dry completely before storing or replacing them on the lounge.
- **Storage:** Store cushions indoors in a dry place when not in use or during inclement weather to prevent mildew and fading.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Lounger feels unstable/wobbly	Loose hardware; uneven surface	Check and tighten all bolts and screws. Ensure the lounger is on a flat, level surface.
Backrest does not adjust smoothly	Mechanism obstructed or stiff	Ensure no debris is blocking the mechanism. Apply a silicone-based lubricant to moving parts if necessary.
Wood appears dry or faded	Lack of oiling; prolonged sun exposure	Clean the wood and apply a suitable wood oil as per maintenance instructions. Consider covering when not in use.

SPECIFICATIONS

- Model: kangqiling362154
- Brand: Generico
- Material: Solid Acacia Wood, Fabric Cushion
- Color: Dark Grey (Cushion), Natural Wood
- Dimensions (L x W x H): 200 x 95 x 32 cm (78.7 x 37.4 x 12.6 inches)
- Backrest Positions: 4 adjustable positions

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the retailer's policy or contact the point of purchase. Keep your proof of purchase for any warranty claims.

© 2026 Generico. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question