Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- MoKo /
- » MoKo 18mm Silicone Quick Release Watch Band User Manual for Garmin Smartwatches

MoKo 18mm Soft Silicone Quick Release Watch Band

MoKo 18mm Silicone Quick Release Watch Band User Manual

For Garmin Vivoactive 4S/Venu 4 41mm/3S/2S/Forerunner 265S/255S/255S Music/Vivomove 3S

1. Introduction

This manual provides instructions for the installation, use, and maintenance of your MoKo 18mm Soft Silicone Quick Release Watch Band. This replacement band is designed for comfort and durability, offering a secure fit for compatible Garmin smartwatches.



Image 1: A black MoKo 18mm silicone watch band attached to a smartwatch, showcasing its design.

2. COMPATIBILITY

The MoKo 18mm Quick Release Watch Band is compatible with the following Garmin smartwatch models:

- Garmin Forerunner 265S
- Garmin Forerunner 255S
- Garmin Forerunner 255S Music
- Garmin Vivoactive 4S
- Garmin Venu 4 41mm
- Garmin Venu 3S
- Garmin Venu 2S
- Garmin Vivomove 3S
- · Garmin Move 3S




Image 2: An image illustrating the compatibility of the 18mm watch band with Garmin Vivoactive 4S, Venu 2S, Vivomove 3S, Forerunner 255S, Forerunner 255S Music, Garmin Captain, and Garmin Rey models.

3. PRODUCT FEATURES

3.1 Material

The replacement straps are constructed from soft and durable silicone, providing a smooth finish suitable for active use. Metal components, including the buckle, are made from premium stainless steel.



Image 3: An image highlighting the properties of the silicone material: safe and non-toxic, flexible, and waterproof.

3.2 Design

The band features an air-permeable design with multiple perforations, allowing for increased airflow to keep your wrist comfortable and cool during wear.



Image 4: A visual representation of the watch band's air-permeable design, indicating how it allows for increased airflow to keep the wrist cool.

3.3 Buckle and Retainer Rings

An innovative pin-and-tuck closure system ensures a clean and secure fit. The classic metal clasp is designed for easy locking and unlocking, complemented by double retainer rings to keep the excess strap neatly in place.




Image 5: A detailed view of the classic metal buckle and the double retainer rings, designed for a secure fit.

3.4 Adjustable Length

The strap includes multiple precision-cut holes, allowing for easy adjustment to fit wrist circumferences between 5.1 inches (130mm) and 7.8 inches (190mm).



Image 6: A diagram illustrating the adjustable wrist circumference range of the watch band, accommodating wrists from 5.5 inches (139.7mm) to 8.7 inches (221mm).

4. SETUP: INSTALLATION AND REMOVAL

The watch band features a quick-release mechanism for easy installation and removal without the need for tools.

To Install: Locate the quick-release pin on the back of the watch band. Push the pin inwards, align the band with the watch lug, and release the pin to secure it. Ensure the pin is fully seated in the lug hole.
Image 7: A close-up image demonstrating how to push the quick-release pin to detach or attach the watch band.
To Remove: Push the quick-release pin inwards and gently pull the band away from the watch lug.

Image 8: A close-up image showing the process of inserting the quick-release pin into the watch lug for secure attachment.




Image 9: A visual guide showing the simple three-step process to install and remove the quick-release watch band: push the pin, pull to align, and remove/insert.

5. OPERATING

Once installed, adjust the watch band to a comfortable fit on your wrist using the available holes and the pin-and-tuck closure. Ensure the band is snug enough for accurate sensor readings from your smartwatch, but not so tight as to restrict circulation or cause discomfort.

6. MAINTENANCE

To ensure the longevity and hygiene of your silicone watch band, follow these care instructions:

• Cleaning: Regularly clean the band with mild soap and water. Rinse thoroughly and dry with a soft cloth.

- **Avoid Harsh Chemicals:** Do not expose the band to strong chemicals, solvents, or abrasive cleaners, as these can damage the silicone material.
- **Storage:** Store the band in a cool, dry place away from direct sunlight when not in use to prevent material degradation.
- Inspection: Periodically inspect the band and buckle for any signs of wear or damage.

7. TROUBLESHOOTING

7.1 Band Not Fitting

If the band does not fit your wrist comfortably, ensure you have selected the correct size (18mm) for your smartwatch model. The band is adjustable within a range of 5.1"-7.8" (130mm-190mm) circumference. If your wrist falls outside this range, the band may not be suitable.

7.2 Difficulty Installing/Removing

Ensure the quick-release pin is fully retracted when attempting to insert or remove the band. Apply gentle pressure and ensure proper alignment with the watch lugs. If the pin does not retract smoothly, check for any obstructions.

7.3 Skin Irritation

While the silicone material is designed to be safe and non-toxic, some individuals may experience irritation. Ensure the band is kept clean and dry. If irritation persists, discontinue use and consult a healthcare professional.

8. SPECIFICATIONS



Image 10: A diagram showing the dimensions of the 18mm watch band, including the buckle width (0.71 inches), short strap length (3.23 inches), and long strap length (4.21 inches).

Feature	Detail
Band Width	18 millimeters (0.71 inches)
Material	Soft Silicone (Band), Premium Stainless Steel (Metal parts)
Clasp Type	Metal clasp with pin-and-tuck closure
Wrist Circumference	5.1"-7.8" (130mm-190mm)
Compatibility	Garmin Vivoactive 4S, Venu 4 41mm, Venu 3S, Venu 2S, Forerunner 265S, 255S, 255S Music, Vivomove 3S, Move 3S, Active S

9. WARRANTY AND SUPPORT

For warranty information or product support, please refer to the seller's policy on the platform where the product was purchased. Keep your purchase receipt as proof of purchase.

Related Documents - 18mm Soft Silicone Quick Release Watch Band



MOKO H3 Bluetooth Beacon: Datasheet and Technical Specifications

Detailed datasheet for the MOKO H3 Bluetooth Beacon, featuring a 3-axis accelerometer, iBeacon/Eddystone compatibility, long battery life, and configurable parameters for IoT applications. Includes physical characteristics, FCC statement, and technical support.



MOKO L03 Anchor Pro Bluetooth Beacon Product Specification

Comprehensive product specification for the MOKO L03 Anchor Pro Bluetooth beacon, detailing hardware, installation, operation, and package information for MOKO's IoT location tracking devices.



LW008-MTE User Guide - MOKO TECHNOLOGY LTD.

Comprehensive user guide for the MOKO LW008-MTE LoRaWAN Tracker. Learn about product features, specifications, installation, app configuration, communication protocols, and troubleshooting.



MOKO LW005-MP APP Configuration Guide

This guide provides detailed instructions on how to configure the MOKO LW005-MP LoRaWAN smart plug using the MKLoRa application. It covers installation, connection, LoRaWAN parameters, general settings, Bluetooth configuration, and device information.

