

[Manuals.plus](#) /

› [Coleshome](#) /

› Coleshome 120x70cm Reversible L-Shaped Desk with 4 Drawers - Assembly and Usage Manual

Coleshome ZJZ-ZX4D

Coleshome 120x70cm Reversible L-Shaped Desk with 4 Drawers

Model: ZJZ-ZX4D | Brand: Coleshome

INTRODUCTION

Thank you for choosing the Coleshome 120x70cm Reversible L-Shaped Desk. This manual provides detailed instructions for assembly, usage, and maintenance to ensure optimal performance and longevity of your desk. This versatile desk is designed to maximize space, offering a comfortable and organized workspace for home office, gaming, or creative activities.



Image: The Coleshome L-shaped desk in a modern gaming environment, showcasing its spacious design and integrated storage.

SAFETY INFORMATION

- **Self-Assembly Required:** This desk requires self-assembly. Please follow all instructions carefully.
- **Use Appropriate Tools:** Ensure you use the correct tools as specified in the assembly guide.
- **Stability:** For optimal stability and safety, ensure the desk is properly secured and placed on a flat, stable surface. If placed in a corner, verify it is firmly positioned.
- **Weight Limit:** Do not exceed the recommended maximum load capacity of 50 kilograms (110 lbs) to prevent damage or injury.
- **Children and Pets:** Keep small parts and packaging materials away from children and pets during assembly.
- **Maintenance:** Regularly check all screws and connections to ensure they remain tight.

PACKAGE CONTENTS

Before beginning assembly, please verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer service.

- Desk panels (main desktop, side panel)
- Metal frame components (legs, support bars)
- 4 fabric drawers
- Integrated PC shelf
- Headphone hook
- All necessary assembly hardware (screws, bolts, Allen wrench)
- Illustrated assembly instructions

ASSEMBLY INSTRUCTIONS

The Coleshome L-shaped desk is designed for simple assembly, typically completed within 30 minutes with the provided illustrated instructions and tools. Follow these general steps:

1. **Unpack and Identify Parts:** Lay out all components on a clean, soft surface to prevent scratches. Refer to the parts list in the included manual to identify each piece.
2. **Assemble the Frame:** Connect the metal frame components according to the diagrams. Ensure all screws are finger-tightened initially.
3. **Attach Desktop Panels:** Secure the main desktop and side panel to the assembled frame.
4. **Install PC Shelf and Hook:** Attach the integrated PC shelf and headphone hook to the designated areas.
5. **Insert Drawers:** Fold and insert the four fabric drawers into their compartments.
6. **Final Tightening:** Once all parts are in place, fully tighten all screws and bolts using the provided tools. Do not overtighten.
7. **Reversible Design:** The desk can be assembled in either a left or right L-shape configuration. Follow the specific diagrams in your manual for your desired orientation.



Image: Detailed diagram illustrating the dimensions of the Coleshome L-shaped desk, including overall measurements and individual section sizes.



Image: Visual representation of the desk's reversible design, demonstrating how the L-shape can be configured for left or right-hand use.

USAGE AND FEATURES

Space-Saving Corner Design

This L-shaped desk is designed to fit perfectly into corners, transforming unused space into a functional workstation. Its compact dimensions (120x70cm) make it ideal for smaller rooms or dedicated work areas.

Organized Storage with 4 Fabric Drawers

The desk features four integrated fabric drawers, providing convenient storage for office supplies, documents, and personal items. These drawers help keep your workspace tidy and clutter-free, protecting contents from dust.

4 Étagères de rangement à étages

Vous avez suffisamment de place pour ranger les objets de tous les jours



Image: A close-up of the four fabric drawers, illustrating their capacity for organizing office supplies and personal belongings.

Integrated PC Shelf and Headphone Hook

A dedicated shelf is provided for your PC tower, keeping it off the floor and saving desktop space. The convenient headphone hook ensures your headphones are always within reach and neatly stored.

Reversible Configuration

The desk's design allows for flexible assembly, enabling you to configure the L-shape to either the left or right side, adapting to your room layout and personal preference.

MAINTENANCE

- **Cleaning:** Wipe the desk surface with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that could damage the lacquered finish.
- **Dusting:** Regularly dust the desk to prevent buildup.
- **Hardware Check:** Periodically inspect all screws and fasteners to ensure they are tight. Retighten if necessary.

to maintain stability.

- **Avoid Excessive Moisture:** Do not expose the desk to excessive moisture or direct sunlight for prolonged periods.
- **Fabric Drawers:** The fabric drawers can be spot cleaned with a mild detergent and damp cloth. Allow to air dry completely.

TROUBLESHOOTING

Desk is Wobbly

- Ensure all screws and bolts are securely tightened.
- Verify the desk is placed on a level surface. Adjust the leveling feet if present.
- Check that all components are correctly assembled according to the instructions.

Drawers Do Not Slide Smoothly

- Ensure the fabric drawers are correctly folded and inserted.
- Check for any obstructions within the drawer compartments.

Missing or Damaged Parts

- If you find any missing or damaged parts upon opening the package, please contact Coleshome customer service immediately for assistance.

SPECIFICATIONS

Brand	Colehome
Model Number	ZJZ-ZX4D
Desk Design	Computer Desk, L-Shape
Dimensions (L x W x H)	120 x 70 x 75.5 cm (47.2 x 27.6 x 29.7 inches)
Color	Black
Material	Metal and Wood
Finish Type	Lacquered
Number of Drawers	4 (fabric)
Item Weight	10.1 Kilograms (22.3 lbs)
Maximum Recommended Load	50 Kilograms (110 lbs)
Special Features	L-shaped, Reversible, Integrated PC Tray, 4 Fabric Drawers
Assembly Required	Yes (includes illustrated instructions and tools)

WARRANTY AND SUPPORT

Warranty

This Coleshome desk comes with a limited warranty. Please refer to the warranty documentation included with your purchase for specific terms and conditions.

Customer Support

Should you encounter any issues, have questions about assembly, or require assistance with missing/damaged parts, please do not hesitate to contact Coleshome customer service. Our professional support team is committed to resolving your concerns within 24 hours.

Contact information can typically be found on the product packaging or the Coleshome official website.