Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Oliboni ICE-2580

Oliboni 2.6 Quart Stainless Steel Mixing Bowl and Mixing Blade User Manual

Model: ICE-2580 Replacement Parts

Introduction

This manual provides instructions for the Oliboni 2.6 Quart Stainless Steel Mixing Bowl and its accompanying Mixing Blade, designed as replacement components for the ICE-2580 ice cream maker. Please read these instructions carefully before use to ensure proper installation and maintenance.

Product Components

The Oliboni replacement set includes the following parts:

- **2.6 Quart Stainless Steel Mixing Bowl:** The primary container for ingredients during the ice cream making process.
- **Mixing Blade (Churn Blade/Ice Cream Paddle):** The component responsible for stirring and churning ingredients within the mixing bowl.



Image: The Oliboni 2.6 Quart Stainless Steel Mixing Bowl with the white mixing blade inserted. The bowl features a metal handle for easy handling.



Image: A diagram illustrating the main components of the Oliboni ice cream maker, including the transparent lid, mixing blade, and ice cream bucket (mixing bowl).

Setup and Installation

To install the mixing bowl and blade into your ICE-2580 ice cream maker:

1. Ensure the ice cream maker is unplugged and turned off before installation.
2. Place the **Stainless Steel Mixing Bowl** securely into the designated cavity of the ice cream maker. Ensure it sits flat and is stable.
3. Insert the **Mixing Blade** onto the central spindle within the mixing bowl. The blade should fit snugly and be able to rotate freely.
4. Once the bowl and blade are in place, you can proceed to add your ingredients and secure the ice cream maker's lid according to your appliance's specific instructions.

Operating Instructions (with ICE-2580 Ice Cream Maker)

These components are designed to work seamlessly with your Oliboni ICE-2580 ice cream maker. Follow the operating instructions provided with your ice cream maker for specific steps on preparing and churning ice cream. Generally, the process involves:

1. **Add Ingredients:** Pour your pre-chilled ice cream mixture into the installed Stainless Steel Mixing Bowl.
2. **Secure Lid:** Place and lock the ice cream maker's lid, ensuring the mixing blade is properly engaged with the motor.
3. **Start Churning:** Select the desired mode and set the timer on your ICE-2580 ice cream maker to begin the churning process. The mixing blade will rotate to create smooth ice cream.
4. **Enjoy:** Once the cycle is complete, remove the lid and mixing blade, and enjoy your freshly made ice cream.

Maintenance and Cleaning

Proper cleaning and maintenance will extend the life of your mixing bowl and blade.

- **After Each Use:** Immediately after use, remove the mixing bowl and blade from the ice cream maker.
- **Washing:** Wash both the stainless steel mixing bowl and the plastic mixing blade with warm, soapy water. Use a soft sponge or cloth to prevent scratching the stainless steel.
- **Rinsing:** Rinse thoroughly with clean water to remove all soap residue.
- **Drying:** Dry all components completely with a soft cloth before storing to prevent water spots or corrosion on the stainless steel.
- **Storage:** Store the clean and dry mixing bowl and blade in a dry place, away from direct sunlight or extreme temperatures.
- **Dishwasher Safety:** While stainless steel is generally dishwasher safe, hand washing is recommended for the mixing blade to preserve its integrity over time. Consult your ice cream maker's manual for specific dishwasher recommendations for the bowl.

Troubleshooting

If you encounter issues with your mixing bowl or blade, consider the following:

- **Blade Not Spinning:**
  - Ensure the mixing blade is correctly seated on the central spindle of the ice cream maker.
  - Check that the ice cream maker's lid is properly secured and engaged, as this often activates the blade's mechanism.
  - Verify that the ice cream mixture is not too thick or frozen, which could impede blade movement.
- **Bowl Not Fitting Securely:**
  - Ensure the bowl is clean and free of debris that might prevent it from seating properly.
  - Confirm that you are using the correct replacement bowl for the ICE-2580 model.
- **Unusual Noises:**
  - Check that the blade is not rubbing against the sides of the bowl or the lid.
  - Ensure no foreign objects have fallen into the bowl during operation.

For issues related to the ice cream maker itself, please refer to the original ICE-2580 user manual.

Specifications

Feature	Detail
Brand	Oliboni
Model Compatibility	ICE-2580 Ice Cream Maker
Bowl Material	Stainless Steel
Blade Material	Plastic (Mxing Blade)
Capacity	2.6 Quarts
Product Dimensions (Bowl)	7.83"W x 4.09"H

Item Weight (approx.)	1.7 pounds (for the set)
Included Components	Mixing Bowl, Mixing Blade

Warranty and Support

Specific warranty information for this replacement mixing bowl and blade is not provided within this manual. For details regarding warranty coverage, returns, or technical support, please contact Oliboni customer service directly or refer to the original purchase documentation for your ICE-2580 ice cream maker.
You may also visit the official Oliboni website for further assistance or product information.

© 2025 Oliboni. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DPFWZCD5

More documents and user manuals: **https://manuals.plus/**