

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [adidas](#) /

> [Adidas MC87 BOA Spikeless Golf Shoes Instruction Manual](#)

adidas NJY49

# Adidas MC87 BOA Spikeless Golf Shoes Instruction Manual

[Introduction](#)

[Features](#)

[Setup](#)

[Operation](#)

[Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

[Warranty & Support](#)

## 1. INTRODUCTION

---

This manual provides instructions for the proper use, care, and maintenance of your Adidas MC87 BOA Spikeless Golf Shoes. These shoes are designed to offer a blend of traditional style with modern golf performance features, ensuring comfort and stability on the course.



Image 1.1: Top-down view of the Adidas MC87 BOA Spikeless Golf Shoes in Off White/Footwear White/Collegiate Navy.

## 2. KEY FEATURES

- **BOA Fit System:** Provides a micro-adjustable, precise fit with a dial mechanism, replacing traditional laces for quick and secure fastening.



Image 2.1: Close-up view of the BOA Fit System dial and lacing on the shoe's upper.

- **Spikeless Outsole with Torsion Bar:** The outsole features a spikeless design for versatile traction on and off the course. A Torsion bar reinforcement enhances stability during your swing.





Image 2.2: View of the spikeless outsole and the yellow Torsion bar for stability.

- **Lightstrike Cushioning:** Integrated cushioning provides lightweight responsiveness and comfort throughout your round.
- **Waterproof Leather Upper:** The premium leather upper is designed to be waterproof, keeping your feet dry in various weather conditions.
- **Vintage Wingtip Style:** Features a classic wingtip design with a kiltie detail, offering a traditional aesthetic suitable for both the course and clubhouse.



Image 2.3: Side view highlighting the classic wingtip and kiltie design elements.

### 3. SETUP

---

Your Adidas MC87 BOA Spikeless Golf Shoes are ready for use with minimal setup. The primary adjustment involves the BOA Fit System to ensure a comfortable and secure fit.

#### 1. Putting on the Shoes:

Insert your foot into the shoe. Ensure your heel is comfortably seated at the back of the shoe.

#### 2. Adjusting the BOA Fit System:

- To tighten, push the BOA dial inward until it clicks, then turn it clockwise. Turn the dial gradually until the shoe feels snug and secure, but not uncomfortably tight.
- To loosen, pull the BOA dial outward until it releases. The lacing system will instantly loosen, allowing you to remove the shoe or adjust the fit.



Image 3.1: A hand demonstrating the adjustment of the BOA Fit System dial.

### 4. OPERATION

---

The Adidas MC87 BOA Spikeless Golf Shoes are designed for optimal performance during your golf game and comfortable wear off the course.

- **On the Golf Course:** The spikeless outsole provides reliable traction for stability during your swing and comfortable walking across various terrains on the course. The Torsion bar supports midfoot stability.
- **Off the Golf Course:** The versatile spikeless design allows for seamless transition from the golf course to the clubhouse or other casual settings without needing to change footwear.
- **Comfort:** Lightstrike cushioning and the Boost heel provide energy return and comfort, reducing foot fatigue during extended wear.

### 5. MAINTENANCE

---

Proper care will extend the life and maintain the performance of your golf shoes.

### 1. Cleaning the Leather Upper:

- After each use, wipe down the leather upper with a soft, damp cloth to remove dirt and debris.
- For stubborn stains, use a mild leather cleaner specifically designed for footwear. Apply sparingly and wipe clean.
- Allow shoes to air dry naturally at room temperature. Avoid direct heat sources like radiators or direct sunlight, which can damage the leather.

### 2. Cleaning the Outsole:

- Use a stiff brush (e.g., an old toothbrush) to remove grass, mud, and dirt from the spikeless traction elements.
- Rinse with water if necessary, ensuring no water enters the shoe interior.

### 3. BOA Fit System Care:

- Keep the dial and lacing free from dirt and debris. A small brush can be used for cleaning.
- Do not apply lubricants or oils to the BOA system, as this can interfere with its mechanism.

### 4. Storage:

- Store shoes in a cool, dry place away from direct sunlight.
- Consider using shoe trees to help maintain the shoe's shape and absorb moisture.

## 6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Shoe feels too loose or too tight.	Incorrect BOA Fit System adjustment.	Adjust the BOA dial as described in the "Setup" section (Section 3) to achieve the desired fit.
Reduced traction on the course.	Debris (mud, grass) accumulated on the outsole.	Clean the outsole thoroughly using a stiff brush to remove any obstructions from the traction elements.
Feet feel wet after playing in damp conditions.	Waterproof barrier compromised or excessive water exposure.	Ensure the leather upper is regularly cleaned and conditioned. While waterproof, extreme conditions or damage can affect performance. Check for any visible damage to the upper.

## 7. SPECIFICATIONS

- **Model Number:** NJY49
- **Brand:** Adidas
- **Closure Type:** BOA Fit System (Dial-based)
- **Outer Material:** Faux Leather
- **Sole Material:** Rubber (Spikeless)
- **Cushioning:** Lightstrike, Boost heel
- **Stability:** Torsion System
- **Water Resistance:** Waterproof leather upper
- **Department:** Men's
- **First Available:** December 2, 2024
- **Origin:** Imported

## 8. WARRANTY & SUPPORT

For information regarding product warranty, returns, or technical support, please refer to the official Adidas website or contact Adidas customer service directly. Keep your proof of purchase for any warranty claims.

Official Adidas Website: [www.adidas.com](http://www.adidas.com)