

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [SUSTEAS](#) /

› [SUSTEAS Cold Press Juicer MP802K User Manual](#)

## SUSTEAS MP802K

# SUSTEAS Cold Press Juicer User Manual

MODEL: MP802K

### 1. Important Safety Instructions

Please read all instructions carefully before using the SUSTEAS Cold Press Juicer. Retain this manual for future reference.

- Always ensure the juicer is properly assembled and the lid is fully closed and locked before operation.
- The juicer features a safety locking device; if the lid is accidentally opened during operation, the machine will automatically stop working.
- Do not immerse the motor base in water or other liquids.
- Avoid juicing lemons or other highly acidic fruits for extended periods to prevent potential rotor corrosion.
- Keep hands and utensils away from moving parts during operation.
- Unplug the appliance from the outlet when not in use, before assembling or disassembling parts, and before cleaning.

### 2. Product Overview

The SUSTEAS Cold Press Juicer is designed for efficient extraction of juice from fruits and vegetables, preserving nutrients through slow mastication. It features a wide feed chute and a powerful 300W motor.



Image: The SUSTEAS Cold Press Juicer, showcasing its main unit, juice collection cup, and pulp collection cup, ready for use.

### 3. Setup and Assembly

Follow these steps to assemble your juicer before first use:

1. Place the juice collection disk onto the main machine base, ensuring it is securely seated.
2. Screw in the spiral juice lever (auger) into the center of the juice collection disk.
3. Place the filter onto the auger.
4. Install the feeding bin (hopper) onto the top of the assembled parts. Open the lid of the feeding bin and align the

handle with the body's locking mechanism. Turn the lid clockwise to lock it securely into the feed bin.

### 3-Step Assembly & Disassembly



✓  ✗ 

Tip: Open Lid 90° for install / Remove

✓  ✗ 

Tighten Lid Before Power



Open the lid and turn it clockwise to lock it into the feed bin.

Image: A visual guide illustrating the three main steps for assembling and disassembling the juicer components.




Image: A detailed four-step visual guide demonstrating the correct sequence for assembling the juicer, from the juice collection disk

to the feeding bin.

## 4. Operating Instructions

Once assembled, your juicer is ready for use:

1. **Preparation:** Wash fruits and vegetables thoroughly. The 5.3-inch wide feed chute allows for whole fruits and vegetables without extensive pre-cutting, saving preparation time.
2. **Placement:** Place the juice collection cup under the juice spout and the pulp collection cup under the pulp spout.
3. **Operation:** Turn the control knob to the 'ON' position to start juicing. Gently feed fruits and vegetables into the feed chute. Use the provided pusher to guide ingredients if necessary, optimizing juice yield.
4. **Reverse Function:** If ingredients become clogged, turn the knob to the 'REV' (Reverse) position to clear the blockage. This function helps prevent clogging and ensures smoother juicing.
5. **Completion:** Once juicing is complete, turn the knob to the 'OFF' position and unplug the juicer.



### 5.3-INCH OVERSIZED FEED

No pre-cutting saves you waiting time for juicing



Image: The juicer highlighting its 5.3-inch oversized feed chute, designed to accommodate whole fruits and vegetables, reducing

preparation time.



## Simple Operation

One-touch knob operation makes it easy for you to squeeze every glass of juice.



Image: A hand demonstrating the simple one-touch knob operation of the juicer, allowing users to easily control the device.

## SIMPLE DISASSEMBLY AND EASY CLEANING



Image: A close-up of the juicer's control knob, indicating the 'ON', 'OFF', and 'REV' (Reverse) functions for easy operation and anti-

clogging.

## 5. Maintenance and Cleaning

Regular cleaning ensures optimal performance and longevity of your juicer:

1. **Disassembly:** After unplugging, disassemble the juicer by reversing the assembly steps.
2. **Rinsing:** Rinse all detachable parts (feeding bin, filter, auger, juice collection disk, cups) under running water immediately after use to prevent pulp from drying and sticking.
3. **Cleaning:** Use the included special brush to clean the filter and other components thoroughly. The juicing bowl and strainer are designed for easy rinsing.
4. **Dishwasher Safe:** Some parts are dishwasher safe; refer to the product care instructions for specific details. Hand washing is recommended for all parts to prolong their lifespan.
5. **Drying and Storage:** Allow all parts to dry completely before reassembling or storing the juicer.



## AUTOMATIC POMACE SEPARATION

Low-speed and slow-pressing, fully extract every drop of nutrient

Image: A collage demonstrating the simple disassembly process and easy cleaning of the juicer's components under running water,

including the juicer body, helical rod, and filter.

## 6. Troubleshooting Guide

If you encounter issues with your SUSTEAS Cold Press Juicer, refer to the following common problems and solutions:

| Problem                             | Possible Cause                                 | Solution  |
|-------------------------------------|--|---|
| Juicer does not start               | Lid not fully closed and locked.               | Ensure the lid is fully closed and locked into position. The safety mechanism prevents operation if not properly secured.   |
| Juicer stops during operation       | Lid accidentally opened or power interruption. | Check if the lid is securely closed. If not, re-secure it. If power was interrupted, check the power connection.  |
| Ingredients are clogging the juicer | Overfeeding or fibrous ingredients.            | Use the 'REV' (Reverse) function to clear the blockage. Reduce the amount of ingredients fed at once. For fibrous ingredients like celery, cut them into smaller pieces.    |
| Low juice yield                     | Ingredients not properly processed.            | Ensure ingredients are fresh. Use the pusher gently to guide ingredients through the auger for maximum extraction.  |
| Unusual noise or vibration          | Improper assembly or foreign object.           | Disassemble and reassemble the juicer, ensuring all parts are correctly aligned. Check for any foreign objects. If the issue persists, discontinue use and contact support. |

## 7. Specifications

| Feature                   | Detail                          |
|---------------------------|---------------------------------|
| Brand                     | SUSTEAS                         |
| Model Name                | MP802K                          |
| Color                     | White                           |
| Special Feature           | Auto Cleaning                   |
| Product Dimensions        | 8.82"D x 7.8"W x 16.9"H         |
| Finish Type               | Non Stick                       |
| Product Care Instructions | Dishwasher Safe, Hand Wash Only |
| Capacity                  | 1.5 Liters                      |
| Maximum Power             | 300 Watts                       |

| Feature     | Detail      |
|-------------|-------------|
| Voltage     | 110 Volts   |
| Item Weight | 7.45 pounds |



## ONE-CLICK REVERSE ANTI-LAG

Fruit pulp is not easy to be blocked for smoother juicing

Image: The SUSTEAS Juicer displaying its approximate dimensions for reference.

### 8. Warranty and Support

The SUSTEAS Cold Press Juicer is covered by a manufacturer's warranty. For specific warranty details, including duration and coverage, please refer to the warranty card included with your product or contact SUSTEAS customer support directly.

For technical assistance, troubleshooting beyond this guide, or to inquire about replacement parts, please contact SUSTEAS customer service. Contact information can typically be found on the product packaging or the official

SUSTEAS website.

© 2024 SUSTEAS. All rights reserved.