

[Manuals.plus](#) /

› [20 SECOND SOAP](#) /

› Instruction Manual: 494217 Carburetor for Briggs & Stratton Engines

20 SECOND SOAP 494217

Instruction Manual: 494217 Carburetor for Briggs & Stratton Engines

Brand: 20 SECOND SOAP | **Model:** 494217

1. INTRODUCTION

This manual provides essential information for the installation, operation, and maintenance of the 494217 Carburetor. This component is designed to ensure optimal fuel delivery and performance for compatible Briggs & Stratton engines. Please read this manual thoroughly before attempting any installation or maintenance procedures.



Figure 1: The 494217 Carburetor. This image displays the carburetor unit, which is a metallic component with various ports and a fuel bowl at the bottom. A paper gasket and a black rubber O-ring are shown in the foreground, indicating included installation accessories.

2. COMPATIBILITY

The 494217 Carburetor is specifically designed for use with the following Briggs & Stratton engine models:

- Briggs & Stratton engine **123802 3418 01**
- Briggs & Stratton engine **123802 3428 01**

Using this carburetor with incompatible engine models may result in improper function or damage to the engine.

3. SETUP AND INSTALLATION

Safety First: Before beginning any work, ensure the engine is turned off, cooled down, and the spark plug wire is disconnected to prevent accidental starting. Wear appropriate personal protective equipment, including gloves and eye protection.

1. Preparation:

- Gather necessary tools (wrenches, screwdrivers, pliers, fuel line clamps).
- Place a drip pan under the carburetor area to catch any spilled fuel.

2. Fuel System Disconnection:

- Locate the fuel line connected to the carburetor.
- Use fuel line clamps to pinch off the fuel line to prevent fuel flow.
- Carefully disconnect the fuel line from the carburetor.

3. Air Filter and Linkage Removal:

- Remove the air filter assembly to gain access to the carburetor.
- Note the position and connection of all linkages (throttle, choke) and springs attached to the carburetor. Taking photos can be helpful.
- Carefully disconnect all linkages and springs.

4. Carburetor Removal:

- Unbolt the carburetor from the engine manifold. There are typically two nuts holding it in place.
- Remove the old carburetor and any old gaskets.

5. New Carburetor Installation:

- Ensure the mounting surfaces on the engine and the new carburetor are clean.
- Place new gaskets (supplied with the carburetor) in their correct positions.
- Mount the new 494217 carburetor onto the engine manifold, ensuring it seats properly.
- Secure the carburetor with the mounting nuts, tightening them evenly.

6. Reconnect Linkages and Fuel Line:

- Reconnect all throttle and choke linkages and springs to their original positions.
- Reconnect the fuel line to the carburetor and remove the fuel line clamps.
- Reinstall the air filter assembly.

7. Final Checks:

- Check for any loose connections or fuel leaks.
- Reconnect the spark plug wire.
- Start the engine and check for proper operation. Minor adjustments to idle speed or mixture screws may be

necessary, referring to your engine's specific service manual.

Note: If you are unsure about any step, it is recommended to consult a qualified small engine mechanic or refer to the specific service manual for your Briggs & Stratton engine model.

4. OPERATING PRINCIPLES

The 494217 Carburetor is a precision component responsible for mixing air and fuel in the correct ratio for combustion within the engine. It atomizes fuel and delivers it to the engine's cylinders, ensuring efficient and smooth operation. Once installed, the carburetor operates automatically based on engine demand, regulated by the throttle and choke mechanisms.

- **Choke:** Used during cold starts to enrich the fuel-air mixture.
- **Throttle:** Controls the amount of air and fuel entering the engine, thereby regulating engine speed.

Proper operation relies on clean fuel and air filters, and correctly adjusted linkages.

5. MAINTENANCE

Regular maintenance helps prolong the life of your carburetor and ensures optimal engine performance. While the 494217 carburetor is designed for durability, certain practices are recommended:

- **Fuel Quality:** Always use fresh, clean fuel. Stale or contaminated fuel can clog carburetor passages. Consider using a fuel stabilizer if the engine will be stored for extended periods.
- **Fuel Filter:** Regularly inspect and replace the fuel filter according to your engine's maintenance schedule. A clogged fuel filter can restrict fuel flow to the carburetor.
- **Air Filter:** Keep the air filter clean and replace it as recommended. A dirty air filter can restrict airflow, leading to a rich fuel mixture and poor engine performance.
- **Carburetor Cleaning:** If performance issues arise due to fuel contamination, the carburetor may need cleaning. This typically involves disassembling the carburetor, cleaning passages with carburetor cleaner, and replacing gaskets. This procedure should only be performed by individuals with mechanical experience.
- **Storage:** Before long-term storage, run the engine until it runs out of fuel, or drain the fuel tank and carburetor bowl to prevent fuel degradation and gumming.

6. TROUBLESHOOTING COMMON ISSUES

If your engine experiences issues after carburetor installation or during normal operation, consider the following common troubleshooting steps:

Symptom	Possible Cause	Solution
Engine will not start or starts hard	• No fuel reaching carburetor • Clogged fuel passages • Improper choke operation	• Check fuel level, fuel filter, and fuel lines. • Clean or replace carburetor. • Verify choke linkage is free and operating correctly.
Engine runs rough or idles poorly	• Dirty air filter • Clogged idle jet • Vacuum leak (improperly seated gaskets)	• Clean or replace air filter. • Clean carburetor idle circuit. • Inspect and replace gaskets if necessary; ensure mounting bolts are tight.

Symptom	Possible Cause	Solution
Engine lacks power or stalls under load	• Main jet clogged • Incorrect fuel-air mixture • Restricted exhaust	• Clean carburetor main jet. • Ensure carburetor is clean and properly adjusted. • Check exhaust system for blockages.
Fuel leaks from carburetor	• Damaged float needle or seat • Cracked fuel bowl or gasket • Loose fuel line connection	• Inspect and replace float needle/seat. • Inspect fuel bowl and replace gasket. • Tighten fuel line clamp.

***Disclaimer:** This troubleshooting guide provides general advice. For complex issues, professional assistance is recommended.*

7. SPECIFICATIONS

Attribute	Detail
Product Name	494217 Carburetor
Brand	20 SECOND SOAP
Compatible Engine Models	Briggs & Stratton 123802 3418 01, 123802 3428 01
Manufacturer Part Number	494217 (as per product identification)
ASIN	B0DPGH2GXC
UPC	670094077570
Date First Available	December 2, 2024

8. WARRANTY AND SUPPORT

Specific warranty details for the 494217 Carburetor are not provided in this manual. For information regarding warranty coverage, returns, or technical support, please contact the manufacturer, **20 SECOND SOAP**, or the retailer from whom the product was purchased.

It is recommended to retain your proof of purchase for any warranty claims.

© 2024 20 SECOND SOAP. All rights reserved.

This manual is for informational purposes only. The manufacturer is not responsible for any damage or injury resulting from improper installation or use of this product.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question