

[manuals.plus](#) /› [Qubo](#) /› [Qubo GSM Flip Phone User Manual - Model NEONW-Red-QUBO](#)

## Qubo NEONW-Red-QUBO

# Qubo GSM Flip Phone User Manual

Model: NEONW-Red-QUBO

## 1. INTRODUCTION

The Qubo GSM Flip Phone is designed for ease of use, particularly for seniors. It features a simplified operating system, large buttons, high-resolution speakers, and a loud volume. Key functionalities include an SOS emergency button, flashlight, FM radio, audio/video playback, Bluetooth, calculator, alarm clock, and calendar. The phone supports Dual SIM functionality and is compatible with major European GSM (2G) networks, ensuring stable calls.



Image: The Qubo GSM Flip Phone in blue, shown both closed and open, highlighting its large buttons and external display for easy viewing.

## 2. WHAT'S IN THE Box

- Flip mobile phone

- Charger
- User Manual

## 3. SETUP

---

### 3.1. Battery and SIM Card Installation

To install the battery and SIM card(s):

1. Gently remove the back cover of the phone.
2. Insert your SIM card(s) into the designated slot(s). The phone supports Dual SIM.
3. Insert the battery, ensuring the contacts align correctly.
4. Replace the back cover until it clicks securely into place.

For a visual guide on battery and SIM card installation, please refer to the video below:

Video: An unboxing video demonstrating how to install the battery and SIM card(s) into the Qubo GSM Flip Phone.

### 3.2. Charging the Phone

Connect the charger to the Type-C charging port on the phone. Plug the charger into a power outlet. The phone will be fully charged in approximately 2.3 hours. The 800 mAh battery provides up to 8 days of standby time with a single SIM.

## 4. OPERATING INSTRUCTIONS

---

### 4.1. Making Calls

The phone features large, clear buttons for easy dialing. Simply enter the phone number and press the green call button to initiate a call.

### 4.2. Quick Dial Buttons (M1, M2, M3)

The M1, M2, and M3 buttons can be pre-set for quick dialing frequently contacted numbers. Refer to the phone's settings menu to configure these speed dial contacts.

### 4.3. SOS Emergency Function

The SOS button is located on the back of the phone. You can pre-set up to 5 emergency phone numbers and an emergency text message. In an emergency, press and hold the SOS button for 3 seconds. The phone will automatically call the registered numbers sequentially and send the pre-set SMS message.

### 4.4. Flashlight

The phone includes a built-in flashlight. Activate it via the dedicated button or through the phone's menu for convenience in low-light conditions.

### 4.5. FM Radio

The integrated FM radio allows you to listen to your favorite stations. The high-volume speakers ensure clear audio output.

### 4.6. Volume Control

Adjust the call and ringtone volume using the dedicated volume buttons on the side of the phone. The phone is designed with loud and clear audio to ensure important calls are not missed.

For a demonstration of various phone features, please watch the video below:

Video: A demonstration of the phone's features including dual screen, large buttons, SOS function, flashlight, and FM radio.

## 5. MAINTENANCE

---

To ensure the longevity and optimal performance of your Qubo GSM Flip Phone, follow these maintenance guidelines:

- Keep the phone dry and away from extreme temperatures.
- Clean the screen and keypad with a soft, dry cloth. Avoid using harsh chemicals.
- Handle the phone with care to prevent physical damage.
- Charge the battery regularly to maintain its health. Avoid overcharging or completely draining the battery frequently.

## 6. TROUBLESHOOTING

---

If you encounter any issues with your Qubo GSM Flip Phone, consider the following common solutions:

- **Phone not turning on:** Ensure the battery is correctly installed and charged.
- **No network signal:** Check if the SIM card is properly inserted. Verify that your network provider has coverage in your area.
- **Cannot make calls:** Ensure you have sufficient credit or an active plan. Check network signal strength.
- **Sound issues:** Adjust the volume settings. Ensure the speaker is not obstructed.

For solutions to common problems, please refer to the video below:

Video: A guide providing solutions to common operational issues with the phone.

## 7. SPECIFICATIONS

---

<b>Brand</b>	Qubo
<b>Model</b>	NEONW-Red-QUBO
<b>Screen Size</b>	2.4 Inches
<b>Screen Type</b>	LCD
<b>Resolution</b>	320 x 240
<b>Processor Type</b>	Core i5-10600KF (Note: This appears to be a generic placeholder, actual phone processor is MT6261D as per description)
<b>RAM Installed Size</b>	64 MB
<b>Flash Memory Installed Size</b>	32 MB
<b>Battery Capacity</b>	800 mAh (Lithium Ion)
<b>Average Battery Life</b>	8 Days (standby)
<b>Connectivity Technology</b>	2G GSM
<b>Product Dimensions</b>	10.5 x 5.3 x 1.74 cm
<b>Product Weight</b>	0.21 g

## 8. WARRANTY AND SUPPORT

---

For any inquiries or assistance, our customer service team is available to respond to your emails within 24 hours. Please refer to your purchase documentation for specific warranty details.

