

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [FEARWIKY](#) /

› [FEARWIKY M-P6 4K Projector User Manual](#)

FEARWIKY M-P6

FEARWIKY M-P6 4K Projector User Manual

Model: M-P6

1. INTRODUCTION

This user manual provides detailed instructions for the operation, maintenance, and troubleshooting of your FEARWIKY M-P6 4K Projector. Please read this manual thoroughly before using the product to ensure proper functionality and to maximize your viewing experience.





Figure 1: FEARWIKY M-P6 4K Projector - Front View

2. WHAT'S IN THE BOX

Upon opening the package, please verify that all the following items are included:

- FEARWIKY M-P6 4K Projector
- Remote Control
- User Manual
- Power Cord

3. PRODUCT FEATURES


The FEARWIKY M-P6 Projector is equipped with advanced features designed to enhance your entertainment and productivity:

- **Dust-Proof Design:** Features a fully sealed optical engine to prevent dust ingress, ensuring clear images and extended lifespan (50,000+ hours) without maintenance.
- **Built-in Smart Apps:** Access popular streaming services like Netflix, YouTube, and Prime Video directly from the integrated TV Store.


- **Native 4K HD Image Quality:** Supports 4K 1080P Full HD resolution for bright, detailed visuals on screens from 40-120 inches. Optimal projection distance is 5.58 feet.
- **Two-Way Bluetooth 5.4:** Connect to external audio devices (headphones, speakers) or use the projector as a standalone Bluetooth stereo.
- **Auto Keystone Correction & Electric Focus:** Automatically corrects image distortion and allows for precise focus adjustment via remote control.
- **50% Zoom Function:** Adjust projection size from 100% down to 50% for flexible placement.
- **Multi-device Compatibility:** Equipped with HDMI, USB, and audio output interfaces for connecting game consoles, computers, smartphones, and other devices.

+50% Brightness

and Brighter Picture



Ture **1080P** High Resolution,
More Accurate Colour Reproduction



Newly Upgraded Airtight Projector, Effective Dustproof, Anti-Dark Spots



Figure 2: Illustration of the projector's dust-proof optical engine and high-resolution display capabilities.

Smart Projector with Built-in APP Store

No need for Firestick, download apps directly from TV Store



Figure 3: The projector's smart interface showing access to various streaming applications.

Keystone Correction with Zoom Function



Figure 4: Visual representation of automatic keystone correction and the zoom function, ensuring a perfectly rectangular image from various angles.

4. SETUP

Follow these steps to set up your FEARWIKY M-P6 Projector:

1. **Placement:** Position the projector on a stable, flat surface. For optimal viewing, place it approximately 5.58 feet from the projection surface to achieve a 60-inch screen size. The flexible zoom function allows for adjustments if needed.
2. **Power Connection:** Connect the provided power cord to the projector's power input and then to a wall outlet.
3. **Initial Power On:** Press the power button on the projector or the remote control to turn on the device.
4. **Focus and Keystone Adjustment:** The projector features sensorless auto-focus and auto keystone correction. If further adjustment is needed, use the remote control to fine-tune the focus and keystone settings for a clear, rectangular image.
5. **Network Connection:** Navigate to the settings menu to connect the projector to your Wi-Fi network. The projector supports Wi-Fi 6 for fast and stable connections.
6. **Device Connection:** Connect your desired input device (e.g., laptop, game console, TV stick) using an HDMI cable, or a USB drive to the respective ports. For audio, connect external speakers via Bluetooth or the audio output port.

The optimal projection size is 60", and the optimal distance between the projector and the screen is 5.58ft.



Figure 5: Diagram illustrating the optimal projection distance and the flexible zoom capability of the projector.



Figure 6: The projector's Wi-Fi 6 connectivity, demonstrating faster data transfer compared to older Wi-Fi standards.

5. OPERATING INSTRUCTIONS

Operating your FEARWIKY M-P6 Projector is intuitive. Here are the basic steps:

1. **Navigation:** Use the remote control's directional buttons and OK button to navigate through the on-screen menus.
2. **Input Source Selection:** Select the desired input source (HDMI, USB, or built-in apps) from the main menu.
3. **Smart App Usage:** For built-in apps like Netflix or YouTube, select them from the TV Store. Ensure you are logged into your accounts for full access.
4. **Bluetooth Audio:** To connect Bluetooth speakers or headphones, go to the Bluetooth settings, enable Bluetooth, and pair with your device.
5. **Screen Mirroring:** The projector supports screen mirroring from smartphones and other devices. Refer to the on-screen instructions for specific mirroring protocols (e.g., iOS, Android, Windows).
6. **Power Off:** Press the power button on the remote or projector to turn off the device.



Figure 7: Overview of the projector's various connectivity options, including USB, smartphone, headphone, DVD player, TV Box, TV Stick, laptop, and PS4.



Figure 8: Detailed view of the projector's input/output ports, including HDMI, audio output, and USB, and compatible devices.

6. MAINTENANCE

To ensure the longevity and optimal performance of your FEARWIKY M-P6 Projector, follow these maintenance guidelines:

- **Cleaning the Lens:** Use a soft, lint-free cloth specifically designed for optical lenses. Gently wipe the lens surface to remove dust or smudges. Avoid abrasive materials or harsh chemicals.
- **Dust Prevention:** The projector has a sealed optical engine, minimizing internal dust accumulation. However, keep the external vents clear of obstructions to ensure proper airflow.
- **Storage:** When not in use for extended periods, store the projector in a cool, dry place, away from direct sunlight and extreme temperatures. Use the original packaging or a protective case if available.
- **Power Off Properly:** Always power off the projector using the designated power button and allow it to cool down before unplugging or moving.

7. TROUBLESHOOTING

If you encounter any issues with your FEARWIKY M-P6 Projector, refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
No Power	Power cord not connected; Power outlet issue.	Ensure power cord is securely plugged into both the projector and a working outlet. Try a different outlet.
No Image	Incorrect input source; Loose HDMI/USB cable; Device not powered on.	Select the correct input source. Check all cable connections. Ensure the connected device is powered on.
Blurry Image	Out of focus; Incorrect projection distance; Keystone not adjusted.	Use the remote control to adjust the electric focus. Ensure the projector is within the recommended projection distance. Check auto keystone correction or manually adjust if needed.

Problem	Possible Cause	Solution
No Audio	Volume too low; Incorrect audio output selected; Bluetooth device not paired.	Increase volume. Check audio settings and ensure correct output (internal speaker, Bluetooth, or external audio port). Re-pair Bluetooth device.
Wi-Fi Connection Issues	Incorrect password; Router too far; Network interference.	Verify Wi-Fi password. Move projector closer to the router. Restart router and projector.

If the problem persists after trying these solutions, please contact FEARWIKY customer support for further assistance.

8. SPECIFICATIONS

Feature	Detail
Brand	FEARWIKY
Model	M-P6
Display Resolution	1920 x 1080 (Supports 4K)
Connectivity Technology	Bluetooth 5.4, Wi-Fi 6
Special Features	Built-In Speaker, Built-In Wi-Fi, Auto Focus, Auto Keystone Correction, Dust-Proof Optical Engine
Recommended Use	Home Cinema
Item Weight	3.19 pounds
Product Dimensions	5.35 x 4.33 x 7.52 inches
Projection Size	40-120 inches
Optimal Projection Distance	5.58 feet (for 60-inch screen)
Lamp Lifespan	50,000+ hours

9. WARRANTY AND SUPPORT

FEARWIKY stands behind the quality of its products. For warranty information and customer support, please refer to the contact details provided on the product packaging or visit the official FEARWIKY website. Keep your purchase receipt as proof of purchase for warranty claims.

For additional support or inquiries, you may contact FEARWIKY-US Store directly via their Amazon seller page: [FEARWIKY-US Store](#).

