Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- iClever /
- iClever BK08 Foldable Bluetooth Keyboard with Touchpad User Manual

iClever BK08

iClever BK08 Foldable Bluetooth Keyboard with Touchpad User Manual

Model: BK08

1. Introduction

This manual provides instructions for the iClever BK08 Foldable Bluetooth Keyboard with Touchpad. This device is designed for portability and multi-device compatibility, offering a compact typing and navigation solution for various operating systems.



Image: The iClever BK08 keyboard, its accessories, and packaging. The image also shows various usage scenarios, highlighting its portability for travel and work environments.

2. PACKAGE CONTENTS

Verify that all items are present in the package:

- Foldable Keyboard
- USB Cable (for charging)
- Carrying Bag
- Stand Holder

3. PRODUCT OVERVIEW

The iClever BK08 is a 65-key tri-fold Bluetooth keyboard featuring an integrated touchpad. It is constructed with an aluminum frame for durability and portability.

3.1 Key Features

- **Foldable Design:** The keyboard features a tri-fold mechanism for compact storage and portability. Unfolding powers on the device, and folding powers it off.
- **Integrated Touchpad:** A precision touchpad with physical buttons is included for navigation, scrolling, and clicking.
- **Multi-Device Connectivity:** Connects to up to 3 devices via Bluetooth 5.0, allowing for quick switching between them.
- **Durable Construction:** Crafted with an aluminum frame and reinforced hinges.
- USB-C Charging: Features a USB-C port for recharging the internal battery.



Image: The iClever BK08 foldable keyboard in its unfolded state, positioned next to a smartphone on a stand, demonstrating a typical usage setup.

3.2 Design and Components

The keyboard's tri-fold design allows it to be compact when closed. It includes sturdy hinges and balance feet for stability during use. The keys utilize a scissor-switch mechanism for a consistent typing experience.



Image: A visual representation of the keyboard's tri-fold design, highlighting its sturdy hinges, balance feet for stability, and the included multi-angle adjustable stand.




Image: An animated sequence demonstrating the folding and unfolding action of the iClever BK08 keyboard, emphasizing the durability and smooth operation of its hinges.



3.3 Dimensions and Weight

The keyboard is designed to be lightweight and compact for travel.

- Product Dimensions (unfolded): 6.23"L x 3.54"W x 0.59"H
- Item Weight: 7.1 ounces (approximately 201 grams)




Image: A visual comparison of the iClever BK08 keyboard's dimensions in both folded and unfolded states, shown next to a smartphone and tablet to illustrate its compact size.

4. CHARGING THE KEYBOARD

Before initial use, fully charge the keyboard. The keyboard features a 210mAh battery and recharges via USB-C.

- 1. Locate the USB-C charging port on the keyboard.
- 2. Connect the provided USB cable to the keyboard's USB-C port.
- 3. Connect the other end of the USB cable to a USB power source (e.g., computer, wall adapter, power bank).
- 4. The charging indicator light will illuminate.
- 5. A full charge typically takes approximately 2 hours.
- 6. Once fully charged, the indicator light may change or turn off. Disconnect the charging cable.

The keyboard is designed to last up to 60 days on a single charge with typical use and features an auto-sleep function when folded.



5. BLUETOOTH CONNECTION

The iClever BK08 keyboard connects wirelessly via Bluetooth Low Energy (Bluetooth 5.0). It does not support USB receivers or wired connections.

5.1 Pairing with a Device

- 1. Power On: Unfold the keyboard to power it on. The indicator light will flash.
- 2. **Enter Pairing Mode:** Press and hold the **Fn** key and one of the Bluetooth channel keys (**BT1**, **BT2**, or **BT3**) for 3-5 seconds until the corresponding indicator light flashes rapidly. This indicates the keyboard is in pairing mode.
- 3. **Enable Bluetooth on Your Device:** On your smartphone, tablet, or computer, go to the Bluetooth settings.
- 4. **Select Keyboard:** Look for "iClever BK08" (or similar) in the list of available Bluetooth devices and select it.
- 5. **Confirm Connection:** Your device may prompt you to enter a code displayed on the screen, then press **Enter** on the iClever keyboard. Follow the on-screen instructions.
- 6. **Connection Successful:** Once paired, the indicator light on the keyboard will stop flashing and remain solid for a few seconds before turning off, indicating a successful connection.

5.2 Switching Between Multiple Devices

The keyboard supports pairing with up to three devices simultaneously, allowing for quick switching.




Image: The iClever BK08 keyboard displayed with icons representing iOS, Android, Windows, and Mac operating systems, indicating its broad compatibility and ability to connect to three devices.



Image: A visual demonstration of the keyboard's multi-device switching capability, showing it connected to a smartphone, a tablet, and a laptop, with the text 'One Tap to Switch' and 'Type across 3 devices instantly'.

To switch between paired devices:

- Simply press the Fn key along with the corresponding Bluetooth channel key BT1, BT2, or BT3) for the desired device.
- The keyboard will automatically connect to the selected device if it is within range and has Bluetooth enabled.

6. OPERATING THE KEYBOARD

6.1 Basic Typing

The keyboard layout is a 65-key design. While compact, it provides a standard QWERTY layout for efficient typing. Keycaps are 13mm, which are smaller than typical laptop keys.

6.2 Function Keys and Hotkeys

The keyboard includes function keys (F1-F12) and hotkeys that may vary in functionality depending on the operating system (Windows/Mac). Use the **Fn** key in combination with other keys to access secondary functions.

6.3 Touchpad Gestures

The integrated touchpad supports various gestures for navigation, similar to a mouse.




Image: A hand interacting with the multi-gesture touchpad of the iClever BK08 keyboard, demonstrating its functionality for navigation on a connected tablet.



Image: A detailed diagram outlining the various touchpad gestures supported by the iClever BK08, including single and multi-finger actions for clicking, scrolling, and dragging.

- One-finger click: Left-click.
- Two-fingers click: Right-click.
- Slide one finger: Move cursor.
- One-finger quick click to hold and drag: Select and move items.
- Two-fingers move vertically or horizontally: Scroll.
- Additional gestures may be supported depending on the operating system.

Note: The touchpad functionality is not compatible with Samsung DeX touch.

6.4 Compatibility

The iClever BK08 keyboard is compatible with a range of devices and operating systems:

- Laptops & desktops (Windows 10+)
- MacBook & iMac (macOS 10.13+)
- iPad (10.2/Pro/Air)
- iPhone (keyboard use only)
- Android phones & tablets (Android 8+)
- Chromebooks

7. MAINTENANCE

7.1 Cleaning

- Ensure the keyboard is powered off (folded) before cleaning.
- Use a soft, lint-free cloth slightly dampened with water or a mild cleaning solution.
- Avoid excessive moisture and do not spray cleaners directly onto the keyboard.
- Do not use harsh chemicals, abrasives, or solvents.

7.2 Storage

- When not in use, fold the keyboard to protect the keys and touchpad and to conserve battery life.
- Store in a cool, dry place, away from direct sunlight and extreme temperatures.
- Use the provided carrying bag for added protection during travel.

8. TROUBLESHOOTING

If you encounter issues with your iClever BK08 keyboard, refer to the following common solutions:

- Keyboard not connecting via Bluetooth:
 - Ensure the keyboard is charged.
 - · Make sure Bluetooth is enabled on your device.
 - Ensure the keyboard is in pairing mode (indicator light flashing rapidly).
 - Forget the device from your device's Bluetooth settings and attempt to re-pair.
 - Try pairing with a different device to rule out device-specific issues.
- · Keys not responding or typing incorrectly:

- · Check battery level.
- Ensure the keyboard is properly connected to your device.
- Restart both the keyboard (fold and unfold) and your connected device.
- Verify that the correct input language/layout is selected on your device.

• Touchpad not working:

- Ensure the keyboard is fully unfolded and powered on.
- Check if the touchpad is enabled (some operating systems allow disabling).
- Clean the touchpad surface.
- Confirm compatibility (e.g., not compatible with Samsung DeX touch).

• Short battery life:

- Ensure the keyboard is fully charged.
- Make sure the keyboard is folded when not in use to activate auto-sleep.
- Battery performance can degrade over time with extensive use.

9. SPECIFICATIONS

Feature	Detail
Model Number	BK08
Connectivity Technology	Bluetooth Low Energy (Bluetooth 5.0), wireless only
Keyboard Layout	65-key tri-fold with touchpad
Кеу Туре	Scissor-switch, non-backlit
Material	Aluminum frame
Battery Capacity	210mAh
Charging Port	USB-C
Charging Time	Approx. 2 hours
Battery Life	Up to 60 days (typical use)
Product Dimensions (unfolded)	6.23"L x 3.54"W x 0.59"H
Item Weight	7.1 ounces
Compatible Devices	Windows 10+, macOS 10.13+, iPad, iPhone, Android 8+, Chromebooks



Image: A detailed view of a Bluetooth Low Energy (BLE) chip, symbolizing the fast and reliable wireless connectivity integrated into the keyboard.

10. WARRANTY AND SUPPORT

iClever products are designed for reliability and performance. For warranty information, technical support, or customer service inquiries, please refer to the contact details provided on the iClever official website or the warranty card included with your product.

Please retain your proof of purchase for warranty claims.

Related Documents - BK08



iClever IC-BK08 Multi-device Foldable Wireless Keyboard User Guide

Comprehensive user guide for the iClever IC-BK08 Multi-device Foldable Wireless Keyboard, covering operating guidelines, features, FAQs, and troubleshooting for Bluetooth connectivity, touchpad functionality, and compatibility.



iClever BK09 Foldable Bluetooth Keyboard User Manual

User manual for the iClever BK09 foldable Bluetooth keyboard. Learn how to connect and use this portable, USB-C rechargeable keyboard with a number pad for up to 3 devices across iOS, Android, Windows, and macOS. Includes setup, features, and specifications.



iClever IC-BK08 Folding Touchpad Bluetooth Keyboard User Manual

User manual for the iClever IC-BK08 folding Bluetooth keyboard with touchpad, covering package contents, features, indicator lights, pairing procedures, keyboard functions, touchpad gestures, system switching, and technical specifications.

	iClever IC-BK08 Tri-folding Wireless Keyboard with Touchpad User Manual Comprehensive user manual for the iClever IC-BK08 tri-folding wireless Bluetooth keyboard with touchpad. Features include multi-device pairing, system switching for Android, Windows, and iOS, detailed function key mappings, touchpad gestures, and technical specifications. Includes FCC compliance information.
The desired without with Transparal COMES User Name Avenue there are a common of the common of th	iClever IC-BK08 Tri-folding Wireless Keyboard with Touchpad - User Manual Comprehensive user manual for the iClever IC-BK08 tri-folding wireless keyboard with touchpad. Learn about features, pairing, functions, specifications, and troubleshooting.
To Listing Windows Suppose on Tracinosis Gallie Our Water Finding Windows Suppose on Tracinosis Care State Finding windows I was a finding of the suppose of the supp	iClever IC-BK08 Tri-folding Wireless Keyboard with Touchpad User Manual User manual for the iClever IC-BK08, a tri-folding wireless keyboard with touchpad. Features include Bluetooth 3.0, multi-device pairing, magnetic power, and detailed specifications for use with various operating systems.