

[manuals.plus](#) /

› [NutriBullet](#) /

› [NutriBullet Original NB606DG Personal Blender User Manual](#)

NutriBullet NB606DG

NutriBullet Original NB606DG Personal Blender User Manual

Model: NB606DG | Brand: NutriBullet

INTRODUCTION

This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your NutriBullet Original NB606DG Personal Blender. Please read all instructions carefully before first use and retain this manual for future reference.



Image: The NutriBullet Original NB606DG Personal Blender, showcasing the main unit with a blending cup filled with fruits and vegetables, alongside a separate cup containing a prepared smoothie and a comfort lip ring. This illustrates the product's primary function and included accessories.

IMPORTANT SAFEGUARDS

When using any electrical appliance, basic safety precautions should always be observed. Failure to do so may result in serious injury or damage to the appliance.

- Read all instructions before operating the NutriBullet.
- Do not immerse the motor base in water or other liquids.
- Avoid contact with moving parts.
- Do not operate any appliance with a damaged cord or plug.
- Keep hands and utensils out of the blending cup while blending.
- Ensure the blade is securely attached before operation.

COMPONENTS AND ACCESSORIES

Your NutriBullet Original NB606DG comes with the following components:

- **600W Motor Base:** The core power unit of the blender.
- **Extractor Blade:** Designed for nutrient extraction.

- **700ml Tall Cup:** For larger blending tasks.
- **500ml Short Cup:** Ideal for single servings.
- **Comfort Lip Rings:** For comfortable drinking directly from the cups.
- **Handled Comfort Lip Ring:** Provides a handle for the cup.



Image: The NutriBullet Original NB606DG Personal Blender with an empty blending cup attached, illustrating the sleek design of the motor base and the clear cup ready for ingredients.



Image: A close-up view of the NutriBullet motor base, highlighting the "nutribullet" logo and the textured grey finish of the appliance.



Image: A detailed close-up of the NutriBullet extractor blade, showing its stainless steel construction and design optimized for nutrient extraction.

SETUP AND FIRST USE

- 1. Unpack:** Carefully remove all components from the packaging.
- 2. Clean:** Wash the cups, lip rings, and extractor blade with warm soapy water before first use. Rinse thoroughly and dry. The motor base should only be wiped clean with a damp cloth.
- 3. Assemble:**
 - Place the motor base on a clean, dry, and level surface.
 - Add your desired ingredients to the NutriBullet cup (do not exceed the MAX line).
 - Screw the extractor blade firmly onto the cup until it is tightly sealed.
- 4. Connect:** Plug the power cord into a 240V electrical outlet.

OPERATING INSTRUCTIONS

- Load Ingredients:** Fill the cup with your desired ingredients. For best results, add liquids first, then soft ingredients, and finally harder ingredients or ice. Do not overfill.
- Attach Blade:** Securely twist the extractor blade onto the cup.
- Place on Base:** Invert the cup and place it onto the motor base. Align the tabs on the cup with the slots on the base.
- Activate:** Press down firmly on the cup and twist clockwise until the tabs lock into place. The blender will start automatically.
- Blend:** Blend until your desired consistency is achieved. Most smoothies can be made in under 60 seconds. For thicker blends, you may need to pulse by pressing down and releasing the cup.
- Stop:** To stop blending, simply twist the cup counter-clockwise and lift it off the motor base.
- Serve:** Unscrew the blade from the cup. You can attach a comfort lip ring to drink directly from the cup.

Note: The NutriBullet is designed for short bursts of blending. Do not operate continuously for more than one minute to prevent overheating. If the motor stops, allow it to cool down for 15 minutes before resuming use.

MAINTENANCE AND CLEANING

Proper cleaning and maintenance will ensure the longevity and optimal performance of your NutriBullet blender.

- Unplug:** Always unplug the NutriBullet from the power outlet before cleaning.
- Clean Cups and Blades:**
 - Twist off the extractor blade from the cup.
 - Rinse the blade and cups immediately after use with warm water and a mild dish soap.
 - The cups and lip rings are dishwasher safe (top rack only).
 - For stubborn residue on the blade, use a brush to clean around the blades carefully.
- Clean Motor Base:**
 - Wipe the motor base with a damp cloth. Do not immerse the motor base in water or any other liquid.
 - Ensure the motor base is completely dry before storing or next use.
- Storage:** Store the NutriBullet in a clean, dry place.



Image: NutriBullet blending cups and the extractor blade placed on a drying rack, demonstrating the ease of cleaning and air-drying for these components.

TROUBLESHOOTING

| Problem | Possible Cause | Solution |
|---------|----------------|----------|
|---------|----------------|----------|

| Problem | Possible Cause | Solution |
|--------------------------------------|---|---|
| Blender does not turn on. | Not plugged in; cup not properly engaged; motor overheated. | Ensure power cord is securely plugged in. Twist cup firmly onto base until locked. If motor is hot, unplug and let cool for 15 minutes. |
| Leaking during blending. | Blade not screwed on tightly; cup overfilled. | Ensure extractor blade is screwed on tightly. Do not fill ingredients past the MAX line. |
| Motor smells or makes unusual noise. | Overloaded; prolonged use. | Unplug immediately. Reduce ingredients. Do not blend continuously for more than 1 minute. Allow motor to cool. |

SPECIFICATIONS

- **Model:** NB606DG
- **Power:** 600 Watts
- **Voltage:** 240 Volts
- **Material:** Plastic (BPA-free Tritan cups), Stainless steel blade
- **Capacity:** 710 ml (Tall Cup), 500 ml (Short Cup)
- **Dimensions:** Approximately 14 x 14 x 34.3 cm
- **Weight:** Approximately 1.98 kg
- **Special Features:** Easy to Clean, Portable, Powerful Motor, Stainless steel blade

WARRANTY AND SUPPORT

Your NutriBullet Original NB606DG Personal Blender is covered by a **1 Year Manufacturer Warranty** from the date of purchase.

This warranty covers defects in materials and workmanship under normal use. It does not cover damage resulting from misuse, accident, alteration, neglect, or unauthorized repair.

For warranty claims, technical support, or to purchase replacement parts, please visit the official NutriBullet website or contact their customer service department. Keep your proof of purchase for warranty validation.

For more information, you may visit the [NutriBullet Store on Amazon](#).

© 2025 NutriBullet. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.