

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [CAPOXO](#) /

› [CAPOXO K08 Open-Ear Wireless Earbuds User Manual](#)

CAPOXO K08

CAPOXO K08 Open-Ear Wireless Earbuds User Manual

Model: K08

INTRODUCTION

Thank you for choosing the CAPOXO K08 Open-Ear Wireless Earbuds. These earbuds are designed to provide a comfortable listening experience while allowing you to remain aware of your surroundings. Featuring Bluetooth 5.3 for stable connectivity, an IPX7 waterproof rating, and an extended battery life, the K08 earbuds are suitable for various activities, including sports and daily use.

This manual provides detailed instructions on how to set up, operate, maintain, and troubleshoot your earbuds to ensure optimal performance.

SETUP

1. Unboxing and Initial Charge

Upon opening the package, ensure all components are present: the CAPOXO K08 earbuds, the charging case, and the charging cable. Before first use, fully charge the earbuds and the charging case.

- Place both earbuds into the charging case.
- Connect the charging case to a power source using the provided USB cable.
- The LED digital display on the charging case will indicate the battery level. A full charge is indicated by '100'.

Digital Power Display



The charging case features a digital display to show the current battery percentage.

2. Pairing with Your Device

The K08 earbuds utilize Bluetooth 5.3 for a quick and stable connection. Follow these steps for initial pairing:

1. Open the charging case and remove both earbuds. They will automatically enter pairing mode.
2. On your smartphone, tablet, or other Bluetooth-enabled device, navigate to the Bluetooth settings.
3. Ensure Bluetooth is enabled.
4. Search for available devices and select "K08" from the list.
5. Once connected, you will hear an audio prompt, and the earbuds will be ready for use.

One Step Pairing



One-step pairing process shown with earbuds and a smartphone's Bluetooth menu.

OPERATING INSTRUCTIONS

Power On/Off

- **Power On:** The earbuds automatically power on when removed from the charging case.
- **Power Off:** Place the earbuds back into the charging case. They will automatically disconnect and power off.

Music Playback

The K08 earbuds feature touch controls for managing your audio:

- **Play/Pause:** Tap once on either earbud.

- **Next Track:** Double-tap the right earbud.
- **Previous Track:** Double-tap the left earbud.
- **Volume Control:** Adjust volume directly from your connected device.

Call Management

Manage phone calls with the integrated touch controls:

- **Answer/End Call:** Tap once on either earbud.
- **Reject Call:** Press and hold either earbud for 2 seconds.

Voice Assistant

- **Activate Voice Assistant:** Triple-tap either earbud.

MAINTENANCE

Cleaning

To ensure longevity and hygiene, clean your earbuds regularly:

- Use a soft, dry, lint-free cloth to wipe the earbuds and charging case.
- Avoid using abrasive materials, solvents, or chemical cleaners.
- Do not immerse the charging case in water.

Water Resistance (IPX7)

The CAPOXO K08 earbuds are rated IPX7 waterproof, meaning they are protected against temporary immersion in water (up to 1 meter for 30 minutes). This makes them resistant to sweat and rain, ideal for workouts and outdoor activities.

- Do not intentionally submerge the earbuds for extended periods or use them for swimming.
- Ensure the earbuds are dry before placing them back into the charging case to prevent damage.

IPX7 Waterproof



The IPX7 rating ensures resistance to sweat and rain.

Storage

When not in use, store the earbuds in their charging case to protect them and keep them charged.

TROUBLESHOOTING

If you encounter any issues with your CAPOXO K08 earbuds, please refer to the following common solutions:

- **Earbuds not powering on:** Ensure the earbuds and charging case are fully charged. Check the LED display on the case.
- **Earbuds not pairing:**

- a. Ensure Bluetooth is enabled on your device and the earbuds are out of the case.
 - b. Forget "K08" from your device's Bluetooth list and attempt to re-pair.
 - c. If issues persist, place earbuds back in the case, close it, wait 10 seconds, then try pairing again.
- **No sound from one or both earbuds:**
 - a. Check the volume level on your connected device.
 - b. Ensure the earbuds are properly connected to your device.
 - c. Try restarting your device and re-pairing the earbuds.
 - **Poor sound quality or intermittent connection:**
 - a. Ensure the earbuds are within the 10-meter transmission range of your device.
 - b. Avoid environments with significant wireless interference.
 - c. Clean any debris from the earbud speakers.
 - **Charging case not charging:** Ensure the USB cable is securely connected to both the case and the power source. Try a different cable or power adapter.

SPECIFICATIONS



The CAPOXO K08 earbuds and charging case.

Feature	Detail
Model Number	K08
Brand	CAPOXO
Bluetooth Version	5.3
Input	5V/1A
Charging Case Capacity	400 mAh (3.7V, 1.48Wh)
Earbud Capacity	85 mAh (3.7V, 0.315Wh)
Earbud Battery Life (single charge)	Up to 13.5 hours

Total Playtime (with charging case)	Up to 80 hours
Transmission Range	10 meters
Waterproof Rating	IPX7
Driver Size	16mm
Weight	80 Grams
Material	Plastic
Control Type	Touch Control
Impedance	20 ohms
Frequency Response	20000 Hz
Compatible Devices	Smartphones, tablets, laptops, desktops, gaming consoles, Bluetooth-compatible car audio systems, smart speakers, phones

80H Super Long Battery Life



The K08 offers up to 80 hours of total playtime with the charging case.

Open Ear Headphones for Comfort



Non-Intrusive
Design

Skin-friendly
Silicone Earhook

Ultra Light

Designed for comfort with an open-ear, non-intrusive fit and lightweight silicone earhooks.

Portable Charging Case



The portable charging case is compact for easy carrying.

WARRANTY AND SUPPORT

Your CAPOXO K08 Open-Ear Wireless Earbuds come with a standard manufacturer's warranty. Please refer to the product packaging or the seller's information for specific warranty terms and conditions.

For technical support, troubleshooting assistance, or warranty claims, please contact CAPOXO customer service through the retailer where you purchased the product or visit the official CAPOXO website for contact information.




User Manual


Customer Service

Email: amz@cupoco.store
 Web: www.cupoco.store
 WhatsApp: (+86) 139 2349 0475

Packing List



Overview



*Note: Please remove protective film of the LED power display screen and charging port before using them.

Product Specification

1. Model Name: DB
2. Bluetooth Version: V5.3
3. Support: AAC/SBC/EDD/AAC/3
4. Earbuds Size/Weight: 48*28*27mm/5g
5. Charging Case Size/Weight: 100*50*41mm/137g
6. Charging Port: Type-C
7. Standby Time: 148h
8. Earbud Battery: 70mAh
9. Charging Case Battery: 2000mAh
10. Transmission Range: 33 meters (without obstacle)

Power On/OFF

- Auto Power On**
Take the earbuds out from the charging case, they will turn on automatically.
- Auto Power Off**
Put the earbuds back into the charging case, they will disconnect & turn off automatically.
- Manually Power On**
If the earbuds are out of the charging case and power off, then press & hold them for 2s, they will power on.
- Manually Power Off**
In non music mode or standby mode, press & hold either earbud for 5s, both earbuds will power off at the same time.

Bluetooth Connection

Please first use for not in use for long time, please fully charge both earbuds and charging case.

First Time Pairing

- Step 1: Take both earbuds out from charging case, they will automatically power on and enter pairing mode. At this time, the indicator of power earbud will flash Blue & Red light alternately, and the vice earbud will indicator Flash Blue 2 times every 2s.
- Step 2: Activate the Bluetooth setting on your phone, search and connect "DB".

Once connected, the led light of both earbuds goes off.



*Note: If the earbuds are not connected to your device over 5 minutes, the earbuds will power off automatically.

For Second Time Use

If the earbuds have already connected with your device, and the Bluetooth setting of the device is on in the second time using, when you take out the earbuds from the charging case, they will connect with your device automatically.

Pair with Other Device

DB sports earbuds have memory function, they usually auto connect with the last paired device.
 Thus, if you want to pair them with other device, you should disconnect "DB" from the last paired device, also forget the pairing record on the last device. Then try to connect it to a new device, it should work properly.

Mono Mode (Only Left/Right Earbud is being Used)

You can use one earbud alone, leave another earbud in the charging case.

- When in Dual mode, put one earbud into the charging case.
- Or only use one earbud out of the charging case, then search & connect "DB" on your device.



Factory Restore Settings

When should I reset?

- 1) Only one earbud plays music.
- 2) Both earbuds can not work together.
- 3) Occur connection issues.

Follow Steps Below to Reset Earbuds

- Step 1: Delete the pairing name "DB" on your phone and deactivate the Bluetooth setting of all devices used by the earbuds.
- Step 2: Put the two earbuds in the charging case, keep them in the charging case.
- Step 3: Press the MFB button for 8 seconds, then the earbud will flash red & blue light alternately for 3 seconds, which means the both earbuds have reset completely.
- Step 4: Now, take out the earbuds to pair them on, activate the Bluetooth setting on your phone search and select "DB" to connect, it should work properly.

If not, please put the earbuds back to the charging case and repeat the steps above.

*Note: After resetting, the pairing record between the earbuds and all your devices will be cleared. In case there is any unsuccessful message in your device, please consider to delete the historical record of "DB" and try the pairing process again.

D8 Wireless Earbuds User Manual

User manual for the D8 Wireless Earbuds, detailing features, setup, operation, and troubleshooting. Includes information on Bluetooth pairing, charging, call and music controls, and safety precautions.

02

Earbuds Charging

To Charge Earbuds

Insert the Earbuds into charging case properly, they will power off & get charged.

Flash during charging
Turn off once fully charged.



(Earbuds LED light light up means "being charged", led light off means "fully charged")

Low Battery Alarm

When the battery is less than 10% (and the voltage is lower than 3.0V), a prompt voice "Please Charge" will be address, announce once every 5 minutes and 5 times in total, and then the earbuds will power off as normal.

Note: If the earbuds don't charge or even can't turn on, that may because there is oxidized layer on something like on the charging connector or charging pin. You can solve this problem by clearing the magnet connector on the earbuds and charging pin on the charging case with alcohol wipes.

03

Charging Case Charging

Type-C Charging

There is a Type-C charging cable in the small black paper box inside the packing box. Please use the provided Type-C cable with a 5V/1A adapter to charge the charging case.



During charging, the charging case power display will show the battery in real time. The number will be displayed as 100 when fully charged.

Wireless Charging

Easy to charge your charging case without cables, just put the charging case on a wireless charging pad.

If the charging case doesn't start to charge, please try to reposition it. (Please see Charging Pad for details)



04

To Charge Your Phone

With charge charging case supports charging your mobile phone, connect it to your mobile phone with your charging cable.



Multi-Function Operations

For Call

Answer Call Click Once
End Call Click Once
Reject Call Long Press 2S



Voice Assistant

Voice assistant: Quick Triple Click

*Note: Must be in music mode or standby mode.



05

For Music

[Functions on "R" Earbud]

Play/Pause: Click Once
Next Track: Quick Double-Click
Volume +: Long Press & Hold



*Note: In music mode, "R" earbud only supports next song and volume +. You have to go back to the previous song by your phone.



[Functions on "L" Earbud]


Play/Pause: Click Once
Previous Track: Quick Double-Click
Volume -: Long Press & Hold

*Note: In music mode, "L" earbud only supports next song and volume -. You have to go back to the previous song by your phone.

How to Wear the Earbuds Correctly?

Choose best fit ear

Use gently push the earbud into your ear and adjust them to get a comfortable fit.



06

Safety Attention

1. Do not use the earbuds while driving a car, operating machinery or performing other activities that require hearing surrounding sounds.
2. Using earbuds at high to moderate volumes for extended periods of time will result in permanent hearing damage. It is advised you keep volume levels moderate to low at times for your safety.
3. Please avoid use in thundering and raining days to prevent damage or electrical shock.
4. Please keep the earbuds out of extreme heat or humidity, do not use any corrosive chemical to clean the earbuds.
5. Please avoid disassemble/assemble the product in case of failure or the accident.
6. Please keep beyond the reach of kids or pets.
7. Please stop using the device if it causes any discomfort or pain.
8. As the Bluetooth signal cannot transmit in water, it is not suitable for swimming or diving. If submerged in water, do not turn the earbuds on until completely dried.

How to Place the Earbuds?



07

How to Sync Volume on Android?

To protect users from potential hearing damage, Android limits on max volume to safer use for Bluetooth audio device.

If you feel the volume is too low, please access developer options and enable absolute volume, so you'll be able to max the volume at your own will and to the full capabilities of your Bluetooth earbuds.

(Please scan this QR code to watch a video to learn more details.)



Find Build Number Firstly

Android 4.1 and lower: the Developer options screen is available by default.

Android 4.2 and higher: the Developer options in Android phones are hidden, you must enable this screen through Build Number.

Android 7.0 and lower: Settings > About Phone > Build Number

Android 8.0 and Android 8.1: Settings > System > About Phone > Build Number

Enable Developer Options

Locate the Build number and tap it about 7 times in succession to enable Developer options. You may also have to tap to your PIN for verification. Once developer options are activated, you will see a message that reads "You are now a developer".

08

Go back to the Settings page, search Developer options as an entry. At the top of the Developer options screen, you can toggle the options as figure 1.



Figure 1

Enable Absolute Volume

Scroll down until you reach the Networking section. Once there, enable toggle ON the absolute volume option as figure 2.



Figure 2

*Note: These options in the figure may be different from the device you're using. Typically, the choices depend on the type and model of the device you're working with.




User Manual


Customer Service

Phone Call: 857-575-1838
Email: am@capoxo.com
Web: www.capoxo.com

Packing List



Overview



*Note: Please disconnect protective film of the LED power display screen and charging port before using them.

Product Specification

1. Model Name: D8
2. Bluetooth Version: V5.3
3. Support: A2DP, AVRCP, HFP, HSP
4. Earbuds Size/Weight: 48*28*27mm/5g
5. Charging Case Size/Weight: 100*50*41mm/137g
6. Charging Port: Type-C
7. Standby Time: 148h
8. Earbud Battery: 70mAh
9. Charging Case Battery: 2000mAh
10. Transmission Range: 33 meters (without obstacles)

Power On/Off

- Auto Power On**
Take the earbuds out from the charging case, they will turn on automatically.
- Auto Power Off**
Put the earbuds back into the charging case, they will disconnect & turn off automatically.
- Manually Power On**
If the earbuds are out of the charging case and power off, then press & hold them for 2s, they will power on.
- Manually Power Off**
In non music mode or standby mode, press & hold either earbud for 5s, both earbuds will power off at the same time.

Bluetooth Connection

Please first use for not in use for long times, please fully charge both earbuds and charging case.

First Time Pairing

- Step 1: Take both earbuds out from charging case, they will automatically power on and enter pairing mode. At this time, red indicator of power on and red, blue & red light alternately, and the vice earbud led indicator flashes Blue 2 times every 2s.
- Step 2: Activate the Bluetooth setting on your phone, search and connect "D8".

Once connected, the led light of both earbuds goes off.



*Note: If the earbuds are not connected to your device over 5 minutes, the earbuds will power off automatically.

For Second Time Use

If the earbuds have already connected with your device, and the Bluetooth setting of the device is on in the second time using, when you take out the earbuds from the charging case, they will connect with your device automatically.

Pair with Other Device

D8 sports earbuds have memory function, they usually auto connect with the last paired device.
Thus, if you want to pair them with other device, you should disconnect "D8" from the last paired device, also forget the pairing record on the last device. Then try to connect it to a new device, it should work properly.

Mono Mode (Only Left/Right Earbud is being Used)

You can use one earbud alone, leave another earbud in the charging case.

- When in Dual mode, put one earbud into the charging case.
- Or only take one earbud out of the charging case, then search & connect "D8" on your device.



Factory Restore Settings

When should I reset?

- 1) Only one earbud plays music.
- 2) Both earbuds can not work with together.
- 3) Occur connection issues.

Follow Steps Below to Reset Earbuds

- Step 1: Delete the pairing name "D8" on your phone and deactivate the Bluetooth setting of all devices used by the earbuds.
- Step 2: Put the two earbuds in the charging case, keep them in the charging case.
- Step 3: Press the MFB button for 8 seconds, which means the both earbuds have reset completely.
- Step 4: Now, pick up the earbuds to pair them on, activate the Bluetooth setting on your phone search and select "D8" to connect, it should work properly.

If not, please put the earbuds back to the charging case and repeat the steps above.

*Note: After resetting, the pairing record between the earbuds and all your devices will be cleared. In case there is any unsuccessful message in your device, please consider to delete the historical record of "D8" and try the pairing process again.

Detailed user manual and specification sheet for CAPOXO D8 wireless earbuds, covering Bluetooth 5.3, 120-hour playtime, IPX7 waterproofing, 2600mAh charging case, and over-ear earhook design.

02

Earbuds Charging

To Charge Earbuds
Insert the Earbuds into charging case properly, they will power off & get charged.

Flash during charging
Turn off once fully charged.

Earbuds LED light (Red light up means "being charged", Red light off means "fully charged")


Low Battery Alarm
When the battery is less than 10% (and the voltage is lower than 3.0V), a prompt voice "Please charge" will be added, announce once every 5 minutes and 5 times in total, and then the earbuds will power off as normal.

Tip: If the earbuds don't charge or even can't turn on, that may because there is oxidized spot or something else on the charging connector or charging pin. You can solve this problem by cleaning the magnet connector on the earbuds and charging pin on the charging case with alcohol wipes.

03

Charging Case Charging

Type-C Charging
There is a Type-C charging cable in the small black paper box inside the packing box. Please use the provided Type-C cable with a 5V/1A adapter to charge the charging case.



During charging, the charging case power display will show the battery in real time. The number will be displayed as 100 when fully charged.

Wireless Charging
Easy to charge your charging case without cables, just put the charging case on a wireless charging pad.

If the charging case doesn't start to charge, please try to reposition it. (Please check the pad too)



04

To Charge Your Phone

With charged charging case supports charging your mobile phone, connect it to your mobile phone with your charging cable.



Multi-Function Operations

For Call

Answer Call	Click Once	
End Call	Click Once	
Reject Call	Long Press 2S	

Voice Assistant

Voice assistant: Quick Triple Click

*Voice assistant music mode or standby mode.



05

For Music

[Functions on "R" Earbud]

Play/Pause	Click Once	
Next Track	Quick Double-Click	
Volume +	Long Press & Hold	

*Note: In music mode, "R" earbud only supports next song and volume +. You have to go back to the previous song by your phone.

[Functions on "L" Earbud]

Play/Pause	Click Once	
Previous Track	Quick Double-Click	
Volume -	Long Press & Hold	

*Note: In music mode, "L" earbud only supports next song and volume -. You have to go back to the previous song by your phone.

How to Wear the Earbuds Correctly?

Choose best fit ear tip, gently push the earhook into your ears and adjust them to get a comfortable fit.




06

Safety Attention

- Do not use the earbuds while driving a car, operating machinery or performing other activities that require hearing surrounding sounds.
- Using earbuds at high to moderate volumes for extended periods of time will result in permanent hearing damage. It is advised you keep volume levels moderate to low for times for your safety.
- Please avoid use in thundering and raining days to prevent damage or electrical shock.
- Please keep the earbuds out of extreme heat or humidity, do not use any corrosive chemical to clean the earbuds.
- Please avoid disassemble/assemble the product in case of failure or fire accident.
- Please keep beyond the reach of kids or pets.
- Please stop using the device if it causes any discomfort or pain.
- As the Bluetooth signal cannot transmit in water it is not suitable for swimming or diving. If submerged in water, do not turn the earbuds on until completely dried.

How to Place the Earbuds?



07

How to Sync Volume on Android?

To protect users from potential hearing damage, Android limits on max volume to safer one for Bluetooth audio device.

If you feel the volume is too low, please access developer options and enable absolute volume, so you'll be able to max the volume at your own volume and to the full capabilities of your Bluetooth earbuds.



(Please scan this QR code to watch a video to learn more details.)

Find Build Number Firstly

Android 4.1 and lower: the Developer options screen is available by default.

Android 4.2 and higher: the Developer options in Android phones are hidden, you must enable this screen through Build Number.

Android 7.0 and lower: Settings > About Phone > Build Number

Android 8.0 and Android 8.0.0: Settings > System > About Phone > Build Number

Enable Developer Options

Locate the Build number and tap it about 7 times in succession to enable Developer options. You may also have to tap to your PIN for verification. Once developer options are activated, you will see a message that reads "You are now a developer".

08

Go back to the Settings page, search Developer options as an entry. At the top of the Developer options screen, you can toggle the options as figure 1.



(Figure 1)

Enable Absolute Volume


Scroll down until you reach the Networking section. Once there, enable toggle ON the absolute volume option as figure 2.



(Figure 2)

*Note: These options in the figure may be different from the device you're using. Typically, the choices depend on the type and model of the device you are working with.

09

	<p>Capoxo D7 True Wireless Earbuds User Manual</p> <p>User manual for the Capoxo D7 True Wireless Earbuds, covering setup, pairing, charging, touch controls, and troubleshooting.</p>
	<p>Capoxo X19 Wireless Earbuds User Manual</p> <p>Comprehensive user manual for the Capoxo X19 wireless earbuds, covering product overview, specifications, charging instructions, pairing, troubleshooting, and multi-function operations.</p>
	<p>CAPOXO N7 True Wireless Earbuds User Manual Bluetooth 5.3 Headphones</p> <p>Comprehensive user manual for CAPOXO N7 True Wireless Earbuds. Learn about setup, operations, charging, Bluetooth connection, and troubleshooting for your N7 earbuds.</p>
	<p>CAPOXO H06 True Wireless Earbuds User Manual</p> <p>User manual for CAPOXO H06 true wireless earbuds, detailing setup, power management, Bluetooth pairing, and specifications.</p>