



[Manuals.plus](#) /

> [KEEPOW](#) /

> KEEPOW Rock Tumbler Belt Replacement Set Compatible with KoolStone Rock Tumbler C1, C1 Pro & C3, 5 Pack

KEEPOW KoolStone C1, C1 Pro, C3

KEEPOW Rock Tumbler Belt Replacement Set Instruction Manual

Compatible with KoolStone Rock Tumbler Models C1, C1 Pro & C3

1. PRODUCT OVERVIEW

This manual provides instructions for the KEEPOW Rock Tumbler Belt Replacement Set. These belts are designed to restore optimal performance to your compatible rock tumbler by replacing worn or broken drive belts.



Image 1.1: KEEPOW Rock Tumbler Belt Replacement Set, showing five black rubber belts and a compatible rock tumbler.

Key Features:

- **Premium Material:** Made from high-quality, elastic, wear-resistant, and durable rubber for long-lasting performance.
- **Easy to Install:** Designed for straightforward replacement, allowing quick restoration of tumbler function.
- **Package Contents:** Each set includes 5 replacement belts.

2. COMPATIBILITY

The KEEPOW Rock Tumbler Replacement Belts are specifically designed to be compatible with the following KoolStone rock tumbler models:

KoolStone Rock Tumbler C1

KoolStone Rock Tumbler C1 Pro

KoolStone Rock Tumbler C3

Compatible with

All KomeStone Rock Tumblers



✓ C3



✓ C1



✓ C1 Pro



keepow

Image 2.1: Visual representation of compatibility with KoolStone C1, C1 Pro, and C3 rock tumblers, alongside a replacement belt.

Ensure your rock tumbler model matches one of the listed compatible devices for proper fit and function.

3. INSTALLATION GUIDE

Follow these steps to replace the drive belt on your KoolStone rock tumbler:

- 1. Preparation:** Ensure the rock tumbler is unplugged from the power source before beginning any maintenance or installation.
- 2. Access the Belt Mechanism:** Carefully locate the area where the existing drive belt is situated. This typically involves removing a cover or accessing the motor and roller assembly. Refer to your specific KoolStone tumbler's user manual for detailed access instructions if needed.
- 3. Remove Old Belt:** Gently remove the broken or worn-out belt from its position around the motor pulley and the tumbler's drive shaft. You may need to carefully stretch it off or cut it if it's severely damaged.
- 4. Install New Belt:** Take one of the new KEEPOW replacement belts. Carefully stretch the new belt around the motor

pulley and the drive shaft, ensuring it is seated correctly and securely in the grooves. The belt should be taut but not overly strained.

5. **Verify Placement:** Once installed, manually rotate the drive shaft or pulley a few times to ensure the belt moves smoothly and does not slip or rub against other components.
6. **Reassemble:** Replace any covers or components that were removed to access the belt mechanism.
7. **Test Functionality:** Plug in the rock tumbler and perform a brief test run to confirm that the new belt is functioning correctly and the tumbler operates smoothly.



Image 3.1: Illustration demonstrating the process of removing a worn belt and replacing it with a new one on a rock tumbler's drive system.

4. MAINTENANCE

Proper maintenance of your rock tumbler belts can extend their lifespan and ensure consistent performance:

- **Regular Inspection:** Periodically inspect the belts for signs of wear, cracking, fraying, or stretching. Replace belts at the first sign of significant degradation to prevent unexpected failures.

- **Keep Clean:** Ensure the belt and pulley areas are free from dust, grit, and debris, which can cause premature wear. Use a soft, dry cloth to clean these components.
- **Proper Storage:** Store unused replacement belts in a cool, dry place away from direct sunlight and extreme temperatures to preserve their material integrity.



Image 4.1: Visual comparison highlighting the difference between a worn, broken belt and a new, intact KEEPOW replacement belt.

5. TROUBLESHOOTING

If your rock tumbler is not functioning correctly after belt replacement, consider the following:

- **Tumbler Not Turning:**
 - *Check Belt Seating:* Ensure the new belt is properly seated in the grooves of both the motor pulley and the drive shaft. A misaligned belt can slip or prevent rotation.
 - *Belt Tension:* Verify the belt has appropriate tension. It should be snug but not overly tight, which could strain the motor, or too loose, which would cause slipping.
 - *Obstructions:* Inspect for any debris or foreign objects obstructing the belt's path or the tumbler's moving parts.

- **Unusual Noise:**

- *Belt Rubbing:* Check if the belt is rubbing against any internal components. Adjust its position if necessary.
- *Motor Issues:* If the noise persists and the belt appears correctly installed, the issue might be with the tumbler's motor or bearings, which are beyond the scope of belt replacement.

- **Premature Belt Wear:**

- *Overloading:* Ensure the tumbler is not consistently overloaded, as this can put excessive strain on the belt.
- *Misalignment:* Verify that the motor pulley and drive shaft are correctly aligned. Misalignment can cause uneven wear on the belt.
- *Environmental Factors:* Extreme temperatures or exposure to chemicals can degrade rubber belts. Ensure the tumbler is used and stored in appropriate conditions.

If troubleshooting steps do not resolve the issue, refer to the original KoolStone rock tumbler manual or contact KEEPOW customer support.

6. SPECIFICATIONS

KEEPOW Rock Tumbler Belt Specifications

Attribute	Detail
Product Name	KEEPOW Rock Tumbler Belt Replacement Set
Compatible Models	KoolStone Rock Tumbler C1, C1 Pro, C3
Material	High-quality Rubber
Quantity per Pack	5 Belts
Belt Perimeter	24.3 cm / 9.56 inches
Belt Width	0.4 cm / 0.15 inches
Belt Diameter	7.8 cm / 3.04 inches

PRODUCT SIZE



Image 6.1: Detailed dimensions of the KEEPOW replacement belt, indicating perimeter and width.

7. WARRANTY AND SUPPORT

KEEPOW is committed to customer satisfaction. If you encounter any issues with your replacement belts or require assistance, please contact our customer support team.

- **Satisfaction Guarantee:** We offer a 30-day money-back guarantee. If you are not satisfied with your purchase, please contact us for a resolution.
- **Customer Support:** For any questions, concerns, or problems, please do not hesitate to contact KEEPOW customer service. We aim to respond promptly and assist you in resolving any issues.

Contact information can typically be found on the product packaging or through the retailer's platform where the product was purchased.

© 2025 KEEPOW. All rights reserved.

This manual is for informational purposes only. KEEPOW is a registered trademark.