

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [Hiwill](#) /
- › [Hiwill HiElite A41 4.1ch Dolby Atmos Soundbar User Manual](#)

Hiwill HiElite A41

Hiwill HiElite A41 4.1ch Dolby Atmos Soundbar User Manual

Model: HiElite A41

1. INTRODUCTION

Thank you for purchasing the Hiwill HiElite A41 4.1ch Dolby Atmos Soundbar. This system is designed to elevate your home entertainment experience with immersive 3D spatial audio, powerful bass, and crystal-clear dialogue. Please read this manual thoroughly before using the product to ensure proper setup, operation, and maintenance.



Image: The Hiwill HiElite A41 soundbar system, including the main soundbar unit, a wireless subwoofer, and two wired surround speakers, positioned in front of a television displaying vibrant aquatic life. The image highlights the compact design and the Dolby Atmos logo on the

2. SAFETY INFORMATION

To reduce the risk of electric shock, fire, or damage to the unit, please observe the following safety precautions:

- Do not expose this appliance to rain or moisture.
- Do not place objects filled with liquids, such as vases, on the apparatus.
- Ensure proper ventilation. Do not block any ventilation openings.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- Only use attachments/accessories specified by the manufacturer.
- Unplug this apparatus during lightning storms or when unused for long periods of time.
- Refer all servicing to qualified service personnel.

3. PACKAGE CONTENTS

Please check that all items listed below are included in your package:

- Hiwill HiElite A41 Soundbar
- Wired Subwoofer
- 2 Wired Surround Speakers
- Remote Control (with 2 AAA Batteries)
- Power Adaptor
- Stereo Cable
- ARC Cable (HDMI)
- Optical Cable
- Wall Mount Kit
- User Manual (this document)

4. PRODUCT OVERVIEW

The Hiwill HiElite A41 is a 4.1 channel sound system designed for an immersive audio experience. It features a main soundbar, a powerful external subwoofer, and two wired front surround speakers.

4.1 Key Features

- **4.1 Channel Configuration:** Delivers a wide soundstage with dedicated front surround channels.
- **Dolby Atmos Support:** Provides multi-dimensional audio that moves around you.
- **300W Peak Power:** Ensures robust and dynamic sound output.
- **Aluminum-Magnesium Alloy Diaphragm Drivers:** Offers enhanced audio performance with reduced distortion and clearer highs.
- **HXS-Processing ClearVoice:** Optimizes vocal clarity for dialogue.
- **5.25-inch External Wired Subwoofer:** Delivers deep, resonant bass.
- **Iconic Copper Ring:** Reduces distortion and stabilizes the magnetic field for crisper highs.

- **Multiple Connectivity Options:** HDMI eARC, Bluetooth 5.3, Optical, and AUX inputs.
- **Adjustable Bass & Treble:** Customize sound to your preference with 12 levels.
- **Three EQ Modes:** Music, Movie, and News for optimized audio profiles.

4.1CH

Elevate Your Sound to Dolby Atmos



Image: An illustration demonstrating the 4.1 channel setup of the Hiwill soundbar system, showing sound waves emanating from the soundbar, subwoofer, and two wall-mounted surround speakers, creating an immersive audio field around a listener.

Hiwill Exclusive High-quality Speaker Material




Image: An exploded diagram of a speaker driver, highlighting its internal components, specifically pointing out the aluminum-magnesium alloy diaphragm and the high-quality copper shorting ring, emphasizing Hiwill's exclusive speaker material.

5. SETUP

5.1 Placement

- **Soundbar:** Place the soundbar centrally below your TV, ensuring it does not obstruct the TV's remote sensor.
- **Subwoofer:** Position the subwoofer on the floor, ideally in a corner or near a wall for optimal bass response.

- **Surround Speakers:** Mount the two wired surround speakers on the wall, to the left and right of your viewing area, allowing sound to flow freely throughout the space.

2 Front Wired Surround Speakers



Image: A visual representation of the two wired surround speakers mounted on a wall, flanking a television, demonstrating their ideal placement for an immersive audio experience.

5.2 Connections

Connect your soundbar to your TV or other devices using one of the following methods:

1. **HDMI eARC (Recommended):** For the best audio quality and Dolby Atmos support, connect the soundbar to your TV's HDMI eARC port using the provided ARC cable. This allows for uncompressed high-resolution audio and seamless audio-video synchronization.
2. **Optical:** Connect the soundbar to your TV's optical output using the provided optical cable. This supports compressed audio.
3. **Bluetooth:** For wireless audio streaming from smartphones or tablets, enable Bluetooth on your device and pair with the 'HiElite A41' soundbar.
4. **AUX:** Use the stereo cable to connect the soundbar to devices with a 3.5mm audio output.

5.3 Powering On

After all connections are made, connect the power adaptor to the soundbar and plug it into a wall outlet. The soundbar will power on automatically or can be turned on using the remote control.

6. OPERATING INSTRUCTIONS

6.1 Remote Control Functions

The included remote control allows you to manage all functions of your soundbar system. Insert the two AAA batteries before first use.

Tailor Your Sound Atmosphere



Image: The remote control for the Hiwill soundbar, showing various buttons for power, volume, input selection, playback controls, and dedicated buttons for News, Music, Movie EQ modes, and Bass/Treble adjustments.

6.2 Input Selection

Press the 'INPUT' button on the remote control to cycle through available input sources: HDMI eARC, Optical, Bluetooth, and AUX.

6.3 Volume Control

Use the 'VOL+' and 'VOL-' buttons on the remote to adjust the master volume.

6.4 EQ Modes

Select from three pre-tuned equalization (EQ) modes to optimize audio for different content types:

- **Music Mode:** Enhances musical clarity and dynamics.
- **Movie Mode:** Provides an immersive cinematic experience with enhanced surround effects.
- **News Mode:** Optimizes vocal clarity for dialogue-heavy content.

Optimized Sound Profiles



News



Movie



Music



Image: A visual representation of the three optimized sound profiles: News, Movie, and Music, displayed above a TV setup with the soundbar and surround speakers, indicating how each mode tailors the audio experience for specific content.

6.5 Bass & Treble Adjustment

Fine-tune the audio to your personal preference:

- Press 'BAS+' or 'BAS-' to adjust the bass level (12 customizable levels).
- Press 'TRE+' or 'TRE-' to adjust the treble level (12 customizable levels).

6.6 Dolby Atmos Usage

For the full Dolby Atmos experience, ensure your TV and content support Dolby Atmos and are connected via HDMI eARC. The soundbar will automatically process Dolby Atmos signals when detected.

7. MAINTENANCE

To maintain the performance and appearance of your soundbar system:

- Wipe surfaces with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Keep the soundbar and speakers away from direct sunlight, heat sources, and excessive dust.
- Ensure proper ventilation around the units to prevent overheating.

8. TROUBLESHOOTING

If you encounter issues with your Hiwill soundbar, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No sound from soundbar	Incorrect input selected; Cables not connected properly; Soundbar not powered on; TV audio output settings incorrect.	Press 'INPUT' on remote to select correct source; Check all cable connections; Ensure soundbar is powered on; Set TV audio output to 'External Speaker' or 'PCM' (for Optical) or 'Passthrough' (for HDMI eARC).
No sound from subwoofer/surround speakers	Subwoofer/surround speakers not connected to soundbar.	Ensure the wired connections for the subwoofer and surround speakers are securely plugged into the soundbar.
Bluetooth pairing issues	Soundbar not in pairing mode; Device too far; Interference.	Select Bluetooth input on soundbar; Ensure soundbar is discoverable; Move device closer; Turn off other Bluetooth devices.
Sound distortion or crackling	Volume too high; Poor cable connection; Interference.	Lower volume; Check and re-secure all cables; Move soundbar away from other electronic devices.
Remote control not working	Batteries depleted; Obstruction; Remote sensor blocked.	Replace batteries; Remove any obstructions between remote and soundbar; Ensure soundbar's remote sensor is clear.

8.1 Firmware Update

The soundbar may require a firmware update for optimal performance, including features like smart memory function. Please contact Hiwill customer support for the latest firmware and instructions.

Upgrade Contents

* Get the Latest Firmware Through Us

- ✓ Expanded Surround Soundstage
- ✓ Clearer Dialogue & Deeper Bass
- ✓ Smart Memory Function

- ✓ Reduced Default Volume
- ✓ Auto LED Off (30s)
- ✓ Softer Screen Brightness



Firmware Upgrade

Image: A graphic illustrating a 'Firmware Upgrade' process with circular arrows, accompanied by a list of benefits such as expanded surround soundstage, clearer dialogue, deeper bass, smart memory function, reduced default volume, auto LED off, and softer screen brightness.

9. SPECIFICATIONS

Feature	Detail
---------	--------

Feature	Detail
Model Name	HiElite A41
Speaker Type	Soundbar with External Subwoofer and Surround Speakers
Surround Sound Channel Configuration	4.1
Speaker Maximum Output Power	300 Watts
Audio Output Mode	Dolby Atmos
Frequency Response	20 Hz - 20 KHz
Connectivity Technology	HDMI eARC, Bluetooth 5.3, Optical, Auxiliary
Product Dimensions (Soundbar)	11D x 41W x 6H Centimetres
Included Components	Power Adaptor, Stereo Cable, ARC Cable, Optical Cable, Remote Control with 2 pack Batteries, Soundbar, Wired Subwoofer, 2 Wired Surround Speakers, Wall Mount Kit, User Manual
Special Features	Dolby Atmos Enabled, Aluminum-magnesium Alloy Diaphragms, 2 Front Speakers, HarmonicX Sound Processing, Adjustable Bass & Treble

45Hz-20kHz

Frequency response

99%
High fidelity

<1%
Distortion rate








Image: A detailed diagram of a DSP (Digital Signal Processor) chip, illustrating its role in achieving a frequency response of 45Hz-20KHz, 99% high fidelity, and less than 1% distortion rate, highlighting the soundbar's audio processing capabilities.



10. WARRANTY AND SUPPORT

Hiwill products are manufactured to the highest quality standards. For information regarding warranty coverage, technical support, or service inquiries, please refer to the warranty card included with your product or visit the official Hiwill website. You may also contact Hiwill Technologies Inc. directly through their Amazon seller page for assistance.



Related Documents - HiElite A41

 <p>Hiwill HW210</p> <p>User Manual</p> <p>Model Number: HW210 Product Name: HW210</p>	<p>Hiwill HW210 Soundbar User Manual</p> <p>Detailed user manual for the Hiwill HW210 soundbar, covering setup, features, connectivity options (Bluetooth, HDMI ARC, Optical, AUX), and troubleshooting for home theater audio.</p>
 <p>Hiwill Dolby Atmos</p> <p>User Manual</p> <p>A51 PRO</p> <p>Model Number: A51 PRO Product Name: A51 PRO Brand: Hiwill</p> <p>册号: 1.0, 1.0, 2025 设备型号: 1.0 (2025年10月) (设备型号: 1.0)</p>	<p>Hiwill A51 PRO Dolby Atmos Soundbar User Manual</p> <p>User manual for the Hiwill A51 PRO soundbar with Dolby Atmos. Includes setup instructions, safety information, connectivity options (eARC, Optical, AUX, Bluetooth), remote control functions, wall mounting guide, and specifications.</p>
 <p>Hiwill Dolby Audio</p> <p>User Manual</p> <p>D20</p> <p>Model Number: D20 Product Name: D20</p> <p>册号: 1.0, 1.0, 2025 设备型号: 1.0 (2025年10月) (设备型号: 1.0)</p>	<p>Hiwill D20 Soundbar User Manual: Setup, Connections, and Specifications</p> <p>A comprehensive user manual for the Hiwill D20 soundbar, detailing setup instructions, connection methods (ARC, Optical, AUX, Bluetooth), control panel and remote functions, placement guidance, technical specifications, and FCC compliance information.</p>
 <p>Hiwill HW310</p> <p>User Manual</p> <p>Model Number: HW310 Product Name: HW310</p>	<p>Hiwill HW310 Soundbar User Manual</p> <p>User manual for the Hiwill HW310 soundbar system, detailing setup, connections, controls, specifications, and safety instructions.</p>

<div data-bbox="126 98 301 331"><div><div>Hiwill</div><div>Dolby Atmos</div></div><div></div><div><div>User Manual</div><div>A502</div></div><div><div>Model Number: A502</div><div>Product Name: A502</div><div>Product Code: A502</div></div></div> <div data-bbox="126 333 271 351"><div>型号: A502</div><div>产品规格: 138 x 105 x 105mm / 105g (不含底座和遥控器)</div></div>	<div data-bbox="341 300 740 331">Hiwill A502 Soundbar User Manual</div> <div data-bbox="341 340 1428 412"><p>User manual for the Hiwill A502 soundbar, detailing setup, connections, controls, specifications, and safety instructions.</p></div>
<div data-bbox="126 658 301 891"><div><div>Hiwill</div><div>HW210</div></div><div></div><div><div>User Manual</div><div>HW210</div></div><div><div>Model Number: HW210</div><div>Product Name: HW210</div><div>Product Code: HW210</div></div></div>	<div data-bbox="341 748 766 779">Hiwill HW210 Soundbar User Manual</div> <div data-bbox="341 788 1468 860"><p>Detailed user manual for the Hiwill HW210 soundbar, covering setup, features, connectivity options (Bluetooth, HDMI ARC, Optical, AUX), and troubleshooting for home theater audio.</p></div>