

Manuals.plus /

› LEDIARY /

› LEDIARY 15.7" Modern Ceiling Fan with Lights and Remote Instruction Manual

LEDIARY 15.7 INCH White 1

LEDIARY 15.7" Modern Ceiling Fan with Lights and Remote

Model: 15.7 INCH White 1 | Brand: LEDIARY

INTRODUCTION

Thank you for choosing the LEDIARY 15.7" Modern Ceiling Fan with Lights and Remote. This low-profile ceiling fan is designed to provide optimal air circulation and versatile lighting for various indoor spaces. Featuring stepless color temperature change, 6 fan speeds, and convenient remote and app control, it offers a comfortable and modern solution for your home.

SAFETY INFORMATION

Please read all instructions carefully before installation and use. Failure to follow these instructions may result in electric shock, fire, or serious personal injury.

- Always disconnect power at the circuit breaker before installation or servicing.
- Installation should be performed by a qualified electrician or a trained professional.
- Ensure the mounting structure can support the weight of the fan.
- Do not operate the fan with damaged wiring or if it is not functioning properly.
- Keep hands, hair, and clothing away from moving fan blades.
- This product is designed for indoor use only.

PACKAGE CONTENTS

Verify that all components are present and undamaged before beginning installation.

- LEDIARY 15.7" Ceiling Fan with Integrated Light
- Remote Control (requires 2 AAA batteries, included)
- Mounting Hardware Kit
- Instruction Manual



Image: Overview of the LEDIARY 15.7 inch Modern Ceiling Fan, showing the integrated light, fan blades, and included remote control.

SPECIFICATIONS

Feature	Detail
Model	15.7 INCH White 1
Dimensions	15.7 x 15.7 x 5.7 inches
Weight	6.89 pounds
Material	Acrylic, Metal, Plastic
Voltage	120 Volts
Wattage	44 watts
Light Output	3000 Lumens
Color Temperature	3000K-6500K (Stepless Change)
Dimming	10%-100% Smooth Dimming
Fan Speeds	6 Speeds
Motor Type	Reversible DC Motor
Control Method	Remote, App (Bluetooth required), Wall Switch
Timer Setting	2H
Noise Level	Max 30dB Mute Operation



Image: Detailed dimensions of the ceiling fan, highlighting its low-profile design.

SETUP AND INSTALLATION

Installation of the LEDIARY ceiling fan is designed to be straightforward. For safety and optimal performance, it is recommended to have the installation performed by a qualified professional.

Pre-Installation Checklist:

1. Ensure power is disconnected at the main circuit breaker.
2. Confirm all package contents are present and undamaged.
3. Prepare necessary tools (screwdriver, wire strippers, ladder, etc.).

Mounting the Fan:

Attach the mounting bracket securely to a ceiling joist or an approved electrical junction box capable of supporting the fan's weight. Connect the electrical wiring according to local codes and the provided wiring diagram. Carefully lift and secure the fan body to the mounting bracket.



Image: Close-up view of the fan's mounting mechanism, showing how it attaches to the ceiling.

Final Assembly:

Once the fan body is securely mounted and wired, attach any decorative elements or covers. Ensure all connections are tight and secure before restoring power.

OPERATING INSTRUCTIONS

Your LEDIARY ceiling fan can be controlled via the included remote control or a dedicated mobile application (Bluetooth required).

Remote Control Functions:

- **Power On/Off:** Turn the fan and light on or off.
- **Fan Speed Control:** Select from 6 fan speeds (1-6) to adjust airflow.
- **Light Brightness Adjustment:** Smooth dimming from 10% to 100% brightness.
- **Color Temperature Change:** Adjust light color from warm white (3000K) to cool white (6500K).
- **Reversible Motor (F/R):** Switch between downdraft (summer mode) and updraft (winter mode) for optimal air circulation.
- **Timer Setting:** Set the fan to turn off automatically after 2 hours.
- **Night Light Mode:** Activates a low-brightness setting for ambient lighting.

APP & Remote Control

✦ Tips: APP Control Needs Bluetooth



6 Fan Speeds

1-2-3-4-5-6



Timer Setting



Reverse Function



Smooth Dimming
10%-100%



Night Light

Image: The remote control and a smartphone screen demonstrating the mobile app interface for controlling the fan and light functions.

App Control:

Download the LEDIARY app from your device's app store. Ensure Bluetooth is enabled on your smartphone to pair with the fan. The app provides comprehensive control over all fan and light functions, mirroring the remote control capabilities.

Color Temperature Changeable & Brightness Adjustable




Image: Illustrates the stepless color temperature adjustment from 3000K (Warm White) to 6500K (Clear White) and smooth dimming from 10% to 100% brightness.

Memory Function:

The fan features a memory function that retains the last used color temperature and brightness settings when turned off and back on.

Cool in Summer & Warm in Winter

Through Reversible Air Circulation




Image: Demonstrates the reversible airflow feature, showing downdraft for cooling in summer and updraft for circulating warm air in winter.

MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your ceiling fan.

- **Cleaning:** Dust the fan blades and light fixture regularly with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Blade Inspection:** Periodically check the fan blades for any signs of damage or imbalance.
- **Tighten Screws:** Over time, some screws may loosen. Periodically check and tighten all screws on the mounting bracket and fan body.

Always ensure power is disconnected before performing any maintenance.

TROUBLESHOOTING

If you encounter issues with your LEDIARY ceiling fan, refer to the following common problems and solutions:

Problem	Possible Cause & Solution
Fan does not operate	<ul style="list-style-type: none"> ◦ Power supply off: Check circuit breaker and wall switch. ◦ Loose wiring: Ensure all electrical connections are secure (consult a professional). ◦ Remote control battery: Replace AAA batteries in the remote.
Light does not turn on	<ul style="list-style-type: none"> ◦ Power supply off: Check circuit breaker and wall switch. ◦ Loose wiring: Ensure light connections are secure. ◦ Light setting: Adjust brightness or color temperature via remote/app.
Remote control not working	<ul style="list-style-type: none"> ◦ Batteries: Replace remote batteries. ◦ Pairing: Re-pair the remote with the fan according to the setup instructions (usually involves holding a setup button). ◦ Obstruction: Ensure no objects are blocking the signal between the remote and the fan.
Fan is noisy	<ul style="list-style-type: none"> ◦ Loose screws: Tighten all mounting and blade screws. ◦ Unbalanced blades: Check for any bent or damaged blades. ◦ Motor hum: A slight hum is normal for DC motors; excessive noise may indicate an issue.

If problems persist, please contact LEDIARY customer support.

WARRANTY AND SUPPORT

LEDIARY provides **2-year support** for this ceiling fan. If you have any issues or require assistance, please contact our after-sales service team. We are always ready to serve you.

For further assistance, please refer to the contact information provided on the product packaging or the official LEDIARY website.