

## HOFSTEIN H3881606

# HOFSTEIN Rapoila LED Wall Light

Model: H3881606

---

## 1. INTRODUCTION

Thank you for choosing the HOFSTEIN Rapoila LED Wall Light. This manual provides essential information for the safe installation, operation, and maintenance of your new lighting fixture. Please read these instructions carefully before installation and retain them for future reference.

The Rapoila LED Wall Light is designed for indoor use, offering a modern and Scandinavian-inspired aesthetic. It features a combination of metal and plastic with a wood-look finish, black, and white elements, providing warm white light suitable for various rooms such as dining rooms, hallways, bedrooms, and living rooms.



Image 1.1: The HOFSTEIN Rapoila LED Wall Light, illuminated, highlighting its unique circular design and warm light output.

## 2. SAFETY INFORMATION

**Important:** Always disconnect the power supply before installation, maintenance, or repair work. Installation should only be performed by a qualified electrician in accordance with local wiring regulations.

- This product is designed for **indoor use only** (IP20 rating). Do not expose to water or high humidity.
- This is a **Class I** appliance, meaning it must be earthed. Ensure proper earthing during installation.
- The light source is an integrated LED and is **not replaceable**. Do not attempt to open or modify the LED module.
- The fixture is **non-dimmable**. Do not connect to a dimmer switch.
- Ensure the mounting surface is capable of supporting the weight of the fixture.
- Keep packaging materials out of reach of children.

## 3. PACKAGE CONTENTS

Please check that all components are present and undamaged before proceeding with installation. If any parts are missing or damaged, contact your retailer.

- HOFSTEIN Rapoila LED Wall Light fixture (1 unit)
- Mounting bracket (1 unit)
- Screws and wall plugs for mounting (quantity may vary)
- Instruction Manual (this document)

## 4. INSTALLATION INSTRUCTIONS

Follow these steps carefully to install your HOFSTEIN Rapoila LED Wall Light.

1. **Prepare for Installation:** Turn off the main power supply at the circuit breaker before starting any electrical work. Ensure the power is completely disconnected.
2. **Mark Mounting Position:** Choose a suitable location on the wall. Use the mounting bracket as a template to mark the drilling points for the screws.
3. **Drill Holes:** Drill holes at the marked positions using an appropriate drill bit for your wall type. Insert the wall plugs into the drilled holes.
4. **Attach Mounting Bracket:** Secure the mounting bracket to the wall using the provided screws. Ensure it is firmly attached.
5. **Electrical Connection:** Connect the electrical wires from your wall to the terminal block on the fixture. Ensure correct polarity (Live, Neutral, Earth) according to local wiring standards. The fixture is Class I and requires an earth connection.
6. **Mount the Fixture:** Carefully align the light fixture with the mounting bracket and secure it in place. Ensure all connections are tight and the fixture is stable.
7. **Restore Power:** Once installation is complete and all connections are secure, restore power at the circuit breaker.



Image 4.1: Dimensional diagram of the Rapoila LED Wall Light, including the mounting bracket for installation reference.

## 5. OPERATING INSTRUCTIONS

The HOFSTEIN Rapoila LED Wall Light operates via your standard wall switch. There are no additional controls on the fixture itself.

- **To Turn On:** Flip the wall switch connected to the fixture to the 'ON' position.
- **To Turn Off:** Flip the wall switch connected to the fixture to the 'OFF' position.

This fixture is not dimmable. Do not attempt to use it with a dimmer switch, as this may damage the integrated LED.

## 6. MAINTENANCE AND CARE

Regular cleaning will help maintain the appearance and performance of your light fixture.

- **Cleaning:** Ensure the power is off before cleaning. Wipe the fixture with a soft, dry, or slightly damp cloth. Do not use abrasive cleaners, solvents, or harsh chemicals, as these can damage the finish and materials.
- **Light Source:** The LED light source is integrated and does not require replacement. Do not attempt to

disassemble the fixture to access the LED.

- **Inspection:** Periodically check the fixture for any signs of damage or loose connections. If any issues are found, disconnect power and consult a qualified electrician.



Image 6.1: Detail of the fixture's materials, including the wood-look finish and the contrasting black and white rings.

## 7. TROUBLESHOOTING

If you encounter issues with your light fixture, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Light does not turn on.	No power supply.	Check the circuit breaker and wall switch. Ensure power is restored.
Light flickers.	Loose wiring connection.	Turn off power and check wiring connections. If unsure, consult a qualified electrician.

Problem	Possible Cause	Solution
Light is too dim or too bright.	Fixture is not dimmable.	This fixture has a fixed light output (3320 lumens, 3000K) and cannot be adjusted.
Fixture is hot to the touch.	Normal operation or improper ventilation.	Some warmth is normal for LED fixtures. Ensure the fixture is not covered or in an enclosed space that restricts airflow. If excessively hot, disconnect power and consult a qualified electrician.

If the problem persists after attempting these solutions, please contact HOFSTEIN customer support or a qualified electrician.

## 8. TECHNICAL SPECIFICATIONS

Feature	Specification
Model Number	H3881606
Brand	HOFSTEIN
Type	LED Wall Light
Material (Lamp)	Metal
Material (Shade)	Plastic
Color (Lamp)	Wood look, Black
Color (Shade)	White
Style	Modern, Scandinavian
Dimensions (Width)	7 cm
Dimensions (Height)	37.5 cm
Dimensions (Length)	36.5 cm
Canopy Height	4 cm
Canopy Diameter	16 cm
Light Source	Integrated LED
Number of Bulbs	1 (integrated)
Power Consumption	24 W
Luminous Flux	3320 lumens
Color Temperature	3000 Kelvin (Warm White)
Dimmable	No

Feature	Specification
Average Lifespan	20,000 hours
Switching Cycles	15,000 times
Power Supply	230 V
Protection Rating	IP20 (Indoor use only)
Protection Class	I (Earthed)

## 9. DISPOSAL

Do not dispose of electrical appliances as unsorted municipal waste. Use separate collection facilities. Contact your local government for information regarding the collection systems available. If electrical appliances are disposed of in landfills or dumps, hazardous substances can leak into the groundwater and get into the food chain, damaging your health and well-being.

## 10. WARRANTY AND SUPPORT

For warranty information or technical support, please contact your retailer or visit the official HOFSTEIN website. Please have your model number (H3881606) and proof of purchase ready when contacting support.

### HOFSTEIN Contact Information:

- Website: [Visit the HOFSTEIN Store on Amazon](#)
- Seller ID: A1PXOQQK3TQOT8