

[manuals.plus](#) /› [Koolatron](#) /› [Koolatron Kenmore Espresso Machine User Manual](#)

Koolatron KKSACM-W

Koolatron Kenmore Espresso Machine User Manual

Model: KKSACM-W

1. INTRODUCTION

Thank you for choosing the Koolatron Kenmore Fully Automatic Espresso Machine. This appliance is designed to provide a professional barista-style coffee experience in the comfort of your home. With its intuitive full-color touchscreen, integrated bean grinder, and dual cream milk frothing system, you can enjoy a wide variety of beverages, from rich espresso to creamy lattes and cappuccinos, with ease.

This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new espresso machine. Please read it thoroughly before first use and keep it for future reference.



Image: The Koolatron Kenmore Espresso Machine in white, showcasing its sleek design, integrated touchscreen display, and the detachable milk container connected to the side.

2. SAFETY INFORMATION

Please observe the following safety precautions to prevent injury or damage to the appliance:

- Read all instructions before operating the appliance.
- Do not immerse the appliance, power cord, or plug in water or other liquids.
- Ensure the voltage indicated on the appliance corresponds to your local mains voltage before connecting.
- Keep the appliance and its cord out of reach of children.
- Unplug from the outlet when not in use and before cleaning.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has

been damaged in any manner.

- Use only accessories recommended by the manufacturer.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always ensure the water tank is filled to the appropriate level before brewing.
- Exercise extreme caution when handling hot steam or hot liquids.

3. COMPONENTS INCLUDED

Your Koolatron Kenmore Espresso Machine package includes the following items:

- Coffee machine
- Filter
- Cleaning brush
- Measuring spoon
- Milk container and tube

4. SETUP

4.1 Unpacking and Placement

1. Carefully remove all packaging materials from the machine.
2. Place the espresso machine on a stable, flat, heat-resistant surface, away from water sources and direct sunlight. Ensure adequate ventilation around the unit.
3. Ensure the power cord is not pinched or tangled.

4.2 Initial Cleaning

1. Wash the water tank, milk container, drip tray, and coffee grounds container with warm, soapy water. Rinse thoroughly and dry.
2. Wipe the exterior of the machine with a damp cloth.

4.3 Filling the Water Tank

1. Remove the water tank from the back or side of the machine.
2. Fill the tank with fresh, cold drinking water up to the MAX line.
3. Replace the water tank securely into the machine.

4.4 Adding Coffee Beans or Ground Coffee



Image: A detailed view of the machine's integrated conical burr grinder, showing coffee beans being processed.

- 1. For Whole Beans:** Open the bean hopper lid on top of the machine. Pour fresh whole coffee beans into the hopper. Adjust the grind size setting as desired (7 grind sizes available).
- 2. For Pre-Ground Coffee:** Use the bypass chute located next to the bean hopper. Open the bypass chute cover and add one scoop of pre-ground coffee using the provided measuring spoon. This is ideal for decaf or different coffee types.



Image: A hand demonstrating how to add pre-ground coffee into the machine's bypass chute using a measuring spoon.

4.5 Setting Up the Milk Container

DUAL CREAM MILK FROTHING SYSTEM

Makes silky-smooth foam from dairy & non-dairy milks

A photograph of a Kenmore espresso machine. The machine is light-colored with a dark control panel on top. The control panel features a digital display with icons for Espresso, Coffee, Americano, Little Macchiato, Cappuccino, Milk Froth, and Hot Water, along with a 'Clean & Calc' button. A clear plastic milk container is attached to the side of the machine, with a glass pitcher being filled with milk foam. A glass mug is on the machine's tray, partially filled with coffee. The machine is positioned on a white tiled countertop.



ONE-TOUCH SELF-CLEANING FUNCTION

Image: The Koolatron Kenmore Espresso Machine with its transparent milk container securely attached to the side, ready for use.

1. Fill the detachable 20 oz milk canister with your preferred milk (dairy, soy, oat, almond, etc.).
2. Attach the milk tube to the designated port on the machine and insert the other end into the milk container.
3. Ensure the milk container lid is securely closed. The airtight plug allows for easy storage in the refrigerator.



Image: A close-up view of the milk container's lid, highlighting its design and the airtight plug for convenient storage.

4.6 Initial Rinse Cycle

Before first use, perform an initial rinse cycle to clean the internal components:

1. Place a large container under the coffee spout and milk frother.
2. Follow the on-screen prompts for the initial rinse or cleaning cycle. This typically involves dispensing hot water through the system.
3. Discard the water after the cycle is complete.

5. OPERATING INSTRUCTIONS

5.1 Control Panel Overview



Image: A close-up view of the machine's full-color touchscreen display, showing various drink options and control icons.

The full-color touchscreen display provides intuitive access to all functions and drink options. Navigate through the menu by tapping the icons.

- **Drink Selection:** Icons for Espresso, Coffee, Americano, Latte Macchiato, Cappuccino, Milk Froth, and Hot Water.
- **Settings:** Icons for adjusting drink size, milk volume, and coffee strength.

- **Maintenance:** Indicators for filter, clean, and descaling.

5.2 Making Coffee and Espresso



Image: A close-up shot of rich, dark espresso pouring from the machine's dual spouts into a small glass cup.

1. Place a cup under the coffee spout. The adjustable height brewing outlet can accommodate various cup sizes.
2. Select your desired drink (Espresso, Coffee, Americano) from the touchscreen.
3. Customize settings such as coffee strength and drink size if prompted or desired.
4. Press the start button. The machine will automatically grind the beans (if using whole beans) and brew your coffee.



Image: The adjustable coffee spout of the machine, with white arrows indicating its vertical movement to fit different cup heights.

5.3 Making Milk-Based Beverages

The dual cream system heats and froths various types of milk to create silky, smooth foam.

1. Ensure the milk container is filled and properly connected to the machine.
2. Place a cup under the coffee spout and milk frother.
3. Select your desired milk-based drink (Latte Macchiato, Cappuccino, Milk Froth) from the touchscreen.
4. Customize milk volume and coffee strength as desired.
5. Press the start button. The machine will first froth and dispense milk, then brew the coffee.

ULTRA SLIM DESIGN

Narrow profile takes up less counter space



ADJUSTABLE SPOUT FITS VARIOUS CUP SIZES

Image: The Koolatron Kenmore Espresso Machine actively preparing a milk-based coffee beverage, with the milk frother dispensing foam into a glass cup.

5.4 Hot Water Function

To dispense hot water for tea or other beverages:

1. Place a cup under the coffee spout.
2. Select the 'Hot Water' option on the touchscreen.
3. Press the start button to dispense hot water.

6. MAINTENANCE

Regular cleaning and maintenance ensure optimal performance and longevity of your espresso machine.

6.1 Automatic Cleaning Functions

- **Self-Cleaning Milk System:** After preparing milk-based drinks, the machine will prompt or automatically perform a quick rinse of the milk system. Follow any on-screen instructions.
- **Automatic Rinsing Cycle:** The machine performs an automatic rinsing cycle upon startup and shutdown to keep the brewing unit clean.

6.2 Manual Cleaning

- Drip Tray and Coffee Grounds Container:** Empty and clean these components daily or as needed. They are removable for convenient cleaning.
- Brewing Unit:** The brewing unit is removable. Refer to the on-screen instructions or manual for specific removal and cleaning steps. Rinse under lukewarm water.
- Water Tank:** Clean the water tank regularly with warm, soapy water.
- Milk Container:** After each use, empty any remaining milk and rinse the container and tube thoroughly. For deeper cleaning, disassemble and wash with warm, soapy water.
- Exterior:** Wipe the exterior of the machine with a soft, damp cloth. Do not use abrasive cleaners or solvents.

6.3 Descaling

The machine will indicate when descaling is required. Descaling removes mineral buildup and is crucial for maintaining performance and extending the life of your machine. Use a descaling solution recommended for espresso machines and follow the on-screen instructions or the detailed descaling procedure in the full manual (if available).

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
No coffee dispenses	Water tank empty; brewing unit clogged; no coffee beans/ground coffee.	Fill water tank; clean brewing unit; add coffee beans/ground coffee.
Coffee is too weak	Grind setting too coarse; insufficient coffee strength selected; low brewing temperature.	Adjust grind to finer setting; increase coffee strength; perform descaling if prompted.
Milk not frothing properly	Milk container empty; milk system clogged; milk type unsuitable.	Refill milk container; clean milk system; ensure fresh, cold milk is used.
Machine displays descaling alert	Mineral buildup in the system.	Perform a descaling cycle as per instructions.
Error message on display	Specific internal issue.	Refer to the specific error code in the full manual or contact customer support.

8. SPECIFICATIONS

DIMENSIONS



Image: A diagram illustrating the dimensions of the Koolatron Kenmore Espresso Machine, showing its height (13.39"), width (8.66"), and depth (18.31").

Feature	Detail
Brand	Koolatron
Model Name	KKSACM-W
Color	White
Product Dimensions	18.31"D x 8.66"W x 13.39"H
Item Weight	20.9 pounds
Coffee Maker Type	Espresso Machine

Feature	Detail
Operation Mode	Fully Automatic
Human Interface Input	Touchscreen
Coffee Input Type	Whole Bean, Ground
Special Features	Auto Shut-Off, Automatic Cleaning, Customizable Grinding & Brewing, Dual Cream System, Full Color Display, Integrated Coffee Grinder, Intuitive Controls, Milk Frother

9. WARRANTY AND SUPPORT

This Koolatron Kenmore Espresso Machine comes with a **Two-Year Warranty**, providing peace of mind and assurance of its quality and durability. Please retain your proof of purchase for warranty claims. For technical support, warranty inquiries, or service, please contact Koolatron customer service. Contact information can typically be found on the manufacturer's website or on the product packaging.

© 2024 Koolatron. All rights reserved.

Related Documents - KKSACM-W

	<p>Smeg ECF01WHAU Espresso Coffee Machine - White, 50's Style Specifications</p> <p>Comprehensive technical specifications for the Smeg ECF01WHAU Espresso Coffee Machine in White, featuring a 50's style design. Details include type, aesthetics, programs, functions, controls, technical features, electrical connection, logistic information, and included accessories.</p>
	<p>Baratza Vario W+ Operations Manual: Setup, Operation, and Maintenance Guide</p> <p>A comprehensive guide to the Baratza Vario W+ coffee grinder, covering setup, grinding operation, burr calibration, cleaning, troubleshooting, and warranty information for optimal home coffee preparation.</p>

	<p>Conrad 2377925 Espresso Machine with Filter Holder, Silver, 1450W - User Manual</p> <p>Comprehensive user manual for the Conrad 2377925 silver 1450W espresso machine with filter holder. Includes intended use, safety instructions, operation guide, care and cleaning, troubleshooting, and technical specifications.</p>
	<p>Fisher & Paykel 24" Series 9 Minimal Built-in Coffee Maker - Quick Reference Guide</p> <p>A quick reference guide for the Fisher & Paykel 24" Series 9 Minimal Built-in Coffee Maker, detailing its features, benefits, specifications, and functions. Learn about its coffee choices, self-cleaning capabilities, complementary design, and personalized brewing options.</p>
	<p>Manuale Utente e Guida alla Sicurezza Eureka ATOM W 65/75</p> <p>Manuale utente completo e istruzioni di sicurezza per il macinacaffè Eureka ATOM W 65/75, che copre funzionamento, programmazione, pulizia, manutenzione e avvertenze essenziali per un uso sicuro e performante in contesti commerciali.</p>
	<p>Krea Touch 120V 60Hz: Installation, Use, and Maintenance Manual</p> <p>Comprehensive installation, use, and maintenance manual for the Krea Touch 120V 60Hz coffee machine by Evoca S.p.A. (N&W Global Vending). Includes technical specifications, operation guides, safety warnings, and troubleshooting.</p>

Documents - Koolatron – KKSACM-W



[\[pdf\]](#) User Manual Instructions Troubleshooting Guide Guide Warranty

KKSACM series manual FRE Product Manual Kenmore Super Automatic Coffee Maker EN FR v 1731003624 cdn shopify s files 1 0558 1674 9125 |||

Super-Automatic Coffee Machine with Dual Cream System KKSACM-B Customer Assistance 1-800-265-8456 www. koolatron.com **KKSACM-W** Use Care Guide

CONTENTS SAFETY INSTRUCTIONS 2 IMPORTANT SAFEGUARDS 2 PRODUCT OVERVIEW 4 PRODUCT OPERATION 5 CLEANING AND MAINTENANCE 18 TROUBLESHOOTING 22 ...

lang:en **score:24** filesize: 7.54 M page_count: 64 document date: 2024-11-07



[\[pdf\]](#) User Manual Instructions Troubleshooting Guide Guide Warranty

KKSACM series manual FRE Kenmore Super Automatic Espresso Coffee Machine Touchscreen WhiteKKSACM Maker Manual EN FRcdn shopify s files 1 0558 1674 9125 FR v 1729794852 |||

Super-Automatic Coffee Machine with Dual Cream System KKSACM-B Customer Assistance 1-800-265-8456 www. koolatron.com **KKSACM-W** Use Care Guide

CONTENTS SAFETY INSTRUCTIONS 2 IMPORTANT SAFEGUARDS 2 PRODUCT OVERVIEW 4 PRODUCT OPERATION 5 CLEANING AND MAINTENANCE 18 TROUBLESHOOTING 22 ...

lang:en **score:23** filesize: 7.54 M page_count: 64 document date: 2024-11-07



[\[pdf\]](#) User Manual Instructions Troubleshooting Guide Guide Warranty Catalog

KKSACM series manual ENG KENMORE Super Automatic Coffee Machine with Dual Cream System Grinder Touchscreen 7 Cup Black Espresso B The Home Depotca1bcdec 2211 43f4 86e2 aea3ea0a564cimages thdstatic catalog Images ca ca1bcdec aea3ea0a564c |||

Super-Automatic Coffee Machine with Dual Cream System KKSACM-B Customer Assistance 1-800-265-8456 www. koolatron.com **KKSACM-W** Use Care Guide

CONTENTS SAFETY INSTRUCTIONS 2 IMPORTANT SAFEGUARDS 2 PRODUCT OVERVIEW 4 PRODUCT OPERATION 5 CLEANING AND MAINTENANCE 18 TROUBLESHOOTING 22 ...

lang:en **score:22** filesize: 4.4 M page_count: 32 document date: 2024-09-13

