

[Manuals.plus](#) /

› [Flybar](#) /

› Flybar 6V Blue Glow Bumper Car for Kids – LED Ride-On Toy with 360° Spin, Rechargeable Battery, and Soft Rubber Bumpers – Safe Indoor Fun for Toddlers Ages 1.5+, Up to 66 lbs Glow Blue

Flybar FB24014BC

Flybar 6V Glow Bumper Car Instruction Manual

Brand: Flybar

Model: FB24014BC

1. IMPORTANT SAFETY INFORMATION

Adult supervision is suggested at all times when the Flybar 6V Glow Bumper Car is in use. Ensure the play area is clear of obstacles to prevent accidents.

2. PRODUCT OVERVIEW

The Flybar 6V Glow Bumper Car is an LED ride-on toy designed for toddlers aged 1.5 to 4 years, supporting up to 66 lbs. It features 360-degree spin capabilities, exciting flashing LED lights, and a soft rubber bumper for safe indoor play. The car is powered by an integrated 6V rechargeable battery and is controlled via easy-to-use dual joysticks.

Key Features:

- **Lights & Action:** Fun, exciting flashing LED lights glow bright, enhancing the play experience.
- **Bump & Play:** The car spins 360 degrees, providing engaging and screen-free entertainment.
- **Durability & Safety:** Built with a tough plastic shell and a soft rubber bumper to protect walls and furniture, cushioning impact during bumping games. An adjustable safety belt keeps little ones securely in place.
- **Dual Joystick Controls:** Easy-to-use dual joysticks allow for intuitive steering and 360-degree spins.
- **Rechargeable Battery:** Powered by an integrated 6V battery, rechargeable with the included 120V wall charger.
- **Maximum Speed:** Reaches a maximum speed of 1 MPH.

Product Components:



Front view of the Flybar 6V Glow Bumper Car, showcasing its vibrant blue glow and front LED lights.



Side view of the bumper car, highlighting its sleek design and the continuous glow from the LED lights.



Detailed view of the dual joysticks for steering, the adjustable safety belt, and the soft rubber bumper.



A child enjoying the bumper car, demonstrating its comfortable seating and ease of use.



Visual representation of the 360-degree spin capability, rechargeable battery, recommended age (1.5-4 years), and maximum speed (1 mph).



Two children engaging in interactive play with the bumper cars, showcasing the fun of multiple units.

3. SETUP GUIDE

The Flybar 6V Glow Bumper Car comes largely pre-assembled for your convenience.

1. **Unboxing:** Carefully remove all components from the packaging.
2. **Bumper Attachment:** Attach the soft rubber bumper to the main body of the bumper car. Ensure it is securely fastened all around the perimeter.
3. **Initial Charge:** Before first use, fully charge the integrated 6V battery. Connect the included 120V wall charger to the charging port on the bumper car and plug it into a standard wall outlet. The charging indicator (if present) will show when charging is complete.
4. **Battery Connection:** Ensure the battery is properly connected internally. Refer to the battery compartment for specific instructions if needed, though typically it comes pre-connected.

Once the bumper is attached and the battery is charged and connected, the bumper car is ready for use.

4. OPERATING INSTRUCTIONS

Operating the Flybar 6V Glow Bumper Car is straightforward, designed for young users.

1. **Power On:** Locate the power switch (usually a red button or switch) and turn the bumper car ON. The LED lights will illuminate.

2. **Seating:** Ensure the child is seated comfortably and securely in the driver's seat. Fasten the adjustable safety belt.
3. **Steering with Joysticks:**
- To move forward, push both joysticks forward simultaneously.
 - To move backward, pull both joysticks backward simultaneously.
 - To turn, push one joystick forward and pull the other backward. Experiment to achieve desired turns.
 - To perform a 360-degree spin, push one joystick forward and pull the other backward in opposite directions.
4. **Stopping:** Release the joysticks to bring the bumper car to a stop.
5. **Power Off:** When playtime is over, turn the power switch to the OFF position to conserve battery life.

Always ensure the child is operating the bumper car in a safe, open indoor area, free from hazards.

5. MAINTENANCE

To ensure the longevity and optimal performance of your Flybar 6V Glow Bumper Car, follow these maintenance guidelines:

- **Cleaning:** Wipe the exterior of the bumper car with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners. Avoid getting water into electrical components.
- **Battery Care:**
 - Charge the battery fully after each use.
 - If storing for an extended period, charge the battery every 2-3 months to maintain its health.
 - Do not overcharge the battery. Disconnect the charger once charging is complete.
- **Storage:** Store the bumper car in a cool, dry place away from direct sunlight and extreme temperatures.
- **Inspection:** Periodically check all parts, including the bumper, wheels, joysticks, and safety belt, for any signs of wear or damage. Replace damaged parts immediately.

No other specific maintenance procedures are required for this product.

6. TROUBLESHOOTING

This section provides solutions to common issues you might encounter with your Flybar 6V Glow Bumper Car.

Problem	Possible Cause	Solution
Bumper car does not move or lights do not turn on.	Power switch is OFF. Battery is not charged or connected. Loose electrical connection.	Ensure the power switch is in the ON position. Charge the battery fully. Verify battery connection. Check for any loose wires or connections (adult supervision required).
Bumper car moves slowly or loses power quickly.	Low battery charge. Overweight user. Operating on an unsuitable surface (e.g., thick carpet).	Recharge the battery completely. Ensure user weight is within the 66 lbs limit. Operate on smooth, hard surfaces for best performance.

Problem	Possible Cause	Solution
LED lights are not working.	Loose connection to LED strip. LED component failure.	Check connections to the LED lights. If problem persists, contact Flybar customer support.

If you encounter an issue not listed here or if the suggested solutions do not resolve the problem, please contact Flybar customer support for assistance.

7. SPECIFICATIONS

Attribute	Detail
Product Dimensions	27 x 25 x 21 inches
Item Weight	18 pounds
Item Model Number	FB24014BC
Manufacturer Recommended Age	18 months and up
Maximum User Weight	Up to 66 lbs
Battery Type	1 x 6V rechargeable battery (included)
Charger	120V wall charger (included)
Maximum Speed	1 MPH
Manufacturer	Flybar

8. WARRANTY AND CUSTOMER SUPPORT

For information regarding product warranty, returns, or any other customer support inquiries, please contact Flybar directly.

Visit the official Flybar website or refer to the product packaging for the most up-to-date contact information and warranty details.

Manufacturer: Flybar

Online Store: [Flybar Store on Amazon](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question