

[Manuals.plus](#) /

> [OURPIC](#) /

> OURPIC 6-Drawer Dresser and TV Stand (Model: DS-020-6D-51-BBO) User Manual

OURPIC DS-020-6D-51-BBO

OURPIC 6-Drawer Dresser and TV Stand User Manual

Model: DS-020-6D-51-BBO

Brand: OURPIC

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, maintenance, and safety of your OURPIC 6-Drawer Dresser and TV Stand. Please read all instructions carefully before assembly and use to ensure proper function and safety.

The OURPIC 6-Drawer Dresser is designed for versatile use in various rooms, offering ample storage with its six fabric drawers and a sturdy wooden top that can also serve as a TV stand.



Image: The OURPIC 6-Drawer Dresser and TV Stand, showcasing its black finish and six drawers, with a television and projector placed on top.

SAFETY INFORMATION

WARNING: Furniture tip-over hazard. Serious or fatal crushing injuries can occur from furniture tip-over. To prevent tip-over, this furniture must be permanently attached to the wall using the anti-tipping kit provided.

- Always install the anti-tipping kit as instructed to prevent accidental tip-over.
- Do not allow children to climb on or play with the dresser.
- Place heavier items in the lowest drawers to improve stability.
- Ensure the dresser is placed on a level surface.
- Keep small parts and packaging materials away from children during assembly.

Safety design

Make the dresser safer during use



Image: A diagram showing the correct and incorrect way to secure the dresser to a wall using an anti-tipping kit, emphasizing safety.

PACKAGE CONTENTS

Before beginning assembly, please ensure all parts and hardware are present. Refer to the included parts list in your packaging. If any parts are missing or damaged, please contact customer support.

ASSEMBLY INSTRUCTIONS

Assembly is designed to be straightforward with clear instructions and all necessary hardware included. No complex or lengthy installation steps are required.

Assembly Video Guide

Your browser does not support the video tag.

Video: An official OURPIC installation guide for the 6-drawer dresser, demonstrating each step of the assembly process.

Step-by-Step Assembly

1. **Step 1:** Connect the main frame components. Secure frame parts 4 and 5 using screws A (x2).
2. **Step 2:** Install the upper support bars. Attach frame parts 6 and 7 using screws A (x2).
3. **Step 3:** Integrate the side panels. Insert one end of frame 8 into the holes on frame 4, and the other end into the holes on board 2. Secure board 2 with screws C (x4).
4. **Step 4:** Complete the frame structure. Insert one end of frame 8 into the holes on frame 4, and the other end into the holes on board 3. Secure board 3 with screws C (x4).
5. **Step 5:** Install the X-steel bar for stability. Attach the X-steel bar 9 using screws C (x4).
6. **Step 6:** Attach the top board. Screw nails D (x4) and insert wooden dowels F (x4) into the top board 1. Then, install the top board 1 onto the assembled frame and secure it with screws E (x4) and B (x8).
7. **Step 7:** Assemble and install the fabric drawers. Assemble each fabric drawer (part 10) and install the drawer handles G. Insert the completed drawers into the frame.
8. **Step 8:** Install the anti-tipping kit. For safety and stability, install the anti-tipping kit I as per the instructions provided in the kit.

OPERATING INSTRUCTIONS

Your OURPIC 6-Drawer Dresser is designed for efficient storage and versatile use.

Drawer Usage

The dresser features six spacious fabric drawers, each with a depth of 15.75 inches, providing ample room for various items. To open a drawer, gently pull the handle. To close, push the drawer back until it is fully seated within the frame.

- Organize clothes, toys, office supplies, socks, blankets, and other accessories.
- The fabric drawers are lightweight yet durable, making them easy to pull out and push in.



Image: The dresser with its six fabric drawers pulled out, demonstrating the large storage capacity for clothes, socks, and other items.

TV Stand Functionality

The robust top panel, measuring 51.18 inches in length, provides a stable surface for a television up to 60 inches. Ensure the TV's base fits securely on the top surface and does not overhang excessively.



Image: The dresser functioning as a TV stand in a living room, with a large television placed on its top surface.

CARE AND MAINTENANCE

To maintain the appearance and longevity of your dresser, follow these care instructions:

- **Cleaning the Top and Side Panels:** The wooden top and side panels are designed to be waterproof and easy to clean. Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish.
- **Cleaning Fabric Drawers:** For the fabric drawers, spot clean with a mild detergent and a damp cloth. Allow to air dry completely. Do not machine wash or tumble dry the fabric drawers.
- **Regular Checks:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.
- **Avoid Overloading:** Do not overload the drawers beyond their capacity to prevent damage to the fabric or frame.



Image: A close-up view of the dresser's top surface and side panel, indicating the wide thickened tabletop and wood side board, and noting its waterproof and easy-to-clean properties.

TROUBLESHOOTING

If you encounter any issues with your dresser, please refer to the following common solutions:


- **Dresser feels wobbly:** Ensure all screws are tightened securely. Verify that the dresser is placed on a level surface. Re-check the installation of the X-steel bar.
- **Drawers do not slide smoothly:** Check for any obstructions inside the drawer slots. Ensure the fabric drawers are assembled correctly and not overfilled.
- **Anti-tipping kit not secure:** Re-read the anti-tipping kit instructions and ensure it is properly anchored to both the dresser and the wall.

If the problem persists, please contact customer support for further assistance.

SPECIFICATIONS

Feature	Detail
Brand	OURPIC
Model Name	DS-020-6D-51-BBO
Product Dimensions (D x W x H)	15.75"D x 51.18"W x 26.06"H
Color	Black
Room Type	Bedroom, Closet, Dressing Room, Home Office, Living Room
Assembly Required	Yes
Item Weight	40.9 pounds
Manufacturer	Ourpic

PRODUCT SIZE



D x W x H
51.2"D x 15.8"W x 26.1"H (6 Drawers)

Image: A detailed diagram illustrating the dimensions of the dresser and its drawers, including overall width (51.2"), depth (15.8"), and height (26.1").

WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the contact details provided with your purchase or visit the official OURPIC website. Our customer service team is available to assist with any questions or concerns regarding your product.