

FLEXISPOT XL5

FLEXISPOT XL5 Dual OKIN Motor Power Lift Recliner Chair User Manual

Model: XL5

INTRODUCTION

This manual provides comprehensive instructions for the safe and efficient use of your FLEXISPOT XL5 Dual OKIN Motor Power Lift Recliner Chair. This chair is designed to offer comfort and assistance with its independent backrest and footrest adjustments, massage, and heating functions. Please read this manual thoroughly before assembly and operation to ensure proper usage and longevity of your product.

IMPORTANT SAFETY INFORMATION

WARNING: Failure to follow these safety instructions may result in injury or damage to the product.

- Always allow the chair to fully expand before use. The sofa is delivered in a compressed state; allow 48 hours after receiving it to fully rebound.
- Unplug the chair from the power outlet when not in use or during assembly and maintenance.
- Keep the power cord away from heat sources, water, and sharp objects to prevent damage.
- Do not attempt to adjust the chair's position manually while it is in operation or powered on. Use the remote control for all adjustments.
- Ensure children and pets are kept clear of the chair's moving parts during operation.
- Do not exceed the maximum weight capacity of 350 pounds.
- Always follow the manufacturer's instructions for safe operation and maintenance.

PACKAGE CONTENTS

Your FLEXISPOT XL5 recliner is shipped in one box for convenience. Please verify all components are present before beginning assembly.

- Main Chair Body (with integrated motor and frame)
- Backrest
- Left Armrest
- Right Armrest
- Power Adapter and Cable
- Remote Control
- Instruction Manual (this document)

ALL IN ONE BOX

Receive & Enjoy it instantly. No more Waiting!



Image: The FLEXISPOT XL5 recliner is conveniently packaged in a single box for delivery.

SETUP AND ASSEMBLY

Assembly of your FLEXISPOT XL5 recliner is designed to be straightforward. It arrives in one box, simplifying the unboxing process.

1. **Unpack Components:** Carefully remove all parts from the single shipping box. Place them on a clean, flat surface.
2. **Attach Backrest:** Align the metal brackets on the backrest with the corresponding slots on the main

chair body. Slide the backrest down firmly until it clicks into place. Ensure it is securely fastened.

3. **Attach Armrests:** Slide each armrest onto the side rails of the main chair body. Push down until they are fully seated and locked.
4. **Connect Power:** Locate the power cable from the chair and connect it to the power adapter. Plug the adapter into a standard wall outlet.
5. **Allow Rebound:** As the chair is delivered in a compressed state, allow approximately 48 hours for the cushions and fabric to fully rebound to their intended shape and firmness.



Image: The fully assembled FLEXISPOT XL5 recliner, ready for use.

OPERATING INSTRUCTIONS

Your FLEXISPOT XL5 recliner offers multiple functions for enhanced comfort, all controlled via the included remote.

Power Lift and Recline Function

The chair features German OKIN dual motors, allowing independent adjustment of the backrest and footrest. This enables a wide range of positions, from an upright sitting position to a nearly flat recline (approximately 180°), and a gentle lift function to assist in standing.

- **Recline Backrest:** Use the designated button on the remote to smoothly recline the backrest.
- **Raise Backrest:** Use the designated button to bring the backrest to a more upright position.
- **Lower Footrest / Lift to Stand:** Use the designated button to lower the footrest. Continue holding to activate the lift mechanism, gently raising the chair to assist you in standing.
- **Raise Footrest:** Use the designated button to elevate the footrest for leg support.

FlexiSpot
Official Online Store



CONTACT US

Email: contact@flexispot.com

Call: +1(855)585-5618




30 DAYS RETURN

You are allowed to return/
exchange the furniture within
30 days of when you receive it.

Image: Detail of the German OKIN dual motor system, ensuring smooth and independent movement of the backrest and footrest.

MASSAGE & HEATING

A Spa-Like Experience



Lumbar
Heating



8 Points
Massage



3 Massage
Modes



Timing
Control



Image: The power lift function of the recliner, designed to assist users in standing up easily.

LIFT AND RECLINE REMOTE



Image: The remote control for the FLEXISPOT XL5, illustrating buttons for backrest recline, raise, footrest raise, and lift-to-standing functions.

Massage and Heating Functions

Enhance your relaxation with the integrated massage and lumbar heating features.

- **8 Massage Points:** The chair includes 8 massage points targeting the back, lumbar, thighs, and legs.
- **3 Massage Modes:** Select from various massage modes and intensities using the remote control.
- **Lumbar Heating:** Activate the lumbar heating function for soothing warmth.
- **Timing Control:** Set a timer for your massage and heating sessions.



Image: The recliner showcasing the locations of the 8 massage points and the lumbar heating element.

USB Charging Ports

Conveniently located USB charging ports allow you to charge your devices while relaxing in the chair.

- Locate the USB port on the side of the chair or integrated into the remote control.
- Connect your device's charging cable to the USB port.

PRODUCT DETAILS



Built-in Cup Holders



Side Pockets



USB Charging Ports

Image: Product details including built-in cup holders, side storage pockets, and a USB charging port for convenience.

CARE AND MAINTENANCE

Proper care will ensure the longevity and appearance of your recliner.

- **Cleaning:** Wipe clean with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which may damage the fabric.
- **Spills:** Blot spills immediately with a clean, dry cloth. Do not rub.
- **Power Cord:** Regularly inspect the power cord for any signs of damage. If damaged, discontinue use and contact customer support.
- **Moving the Chair:** When moving the chair, lift it rather than dragging to prevent damage to the base and flooring.

TROUBLESHOOTING

If you encounter issues with your recliner, refer to the following common problems and solutions:

- **Chair Not Moving/Responding:**

- Ensure the power cord is securely plugged into both the chair and a working wall outlet.
- Check if the power adapter is properly connected.
- Verify that the remote control cable is firmly connected to the chair.
- If the chair was recently assembled, ensure all connections (backrest, armrests) are fully engaged.

- **Grinding or Clicking Noise:**

- Unplug the chair immediately.
- Inspect the motor and frame area for any obstructions.
- If the noise persists after checking for obstructions, contact customer support.

- **Remote Control Lost/Malfunctioning:**

- Ensure the remote's cable is not damaged or disconnected.
- If the remote is lost, contact customer support for replacement options.

- **Cushions Not Fully Expanded:**

- Allow the recommended 48 hours for the compressed foam to fully rebound after unboxing.
- Gentle fluffing of cushions may assist in the process.

For any issues not listed here or if troubleshooting steps do not resolve the problem, please contact FLEXISPOT customer support.

PRODUCT SPECIFICATIONS

PRODUCT DIMENSIONS



NEARLY 180°



Image: Detailed product dimensions for the FLEXISPOT XL5 recliner, including width, depth, and height.


OVERSIZED RECLINER

Safely holds up to **350lbs** ✓

Barely hold 265lbs ✕



✓ **Our**



✕ **Other**

Image: Visual comparison highlighting the spacious, oversized design of the FLEXISPOT XL5 recliner.

Feature	Detail
Brand	FLEXISPOT
Model Name	XL5
Product Dimensions	29"D x 36.8"W x 41.5"H
Seat Dimensions	24.5" wide, 21" deep
Maximum Weight Recommendation	350 Pounds
Motor Type	Dual OKIN Motor
Reclining Positions	Infinite (nearly 180° lay flat)
Special Features	Power Lift, Massage (8 points, 3 modes), Lumbar Heat, USB Ports

Feature	Detail
Material	Fabric (Blue), Foam Fill
Item Weight	144.5 pounds
UPC	840460423830

WARRANTY AND CUSTOMER SUPPORT

FLEXISPOT is committed to providing high-quality products and excellent customer service.

- **Return Policy:** You are allowed to return or exchange the furniture within 30 days of receipt. Please refer to your purchase platform's return policy for detailed instructions.
- **Customer Support:** For any questions, issues, or warranty claims, please contact FLEXISPOT customer support.

Contact Information:

Email: contact@flexispot.com


Call: +1(855)585-5618

You can also visit the official FLEXISPOT store for more information:[FLEXISPOT Official Store](#)

© 2025 FLEXISPOT. All rights reserved.

Related Documents - XL5

	FlexiSpot XP6 Pushback Recliner Chair User Manual User manual for the FlexiSpot XP6 Pushback Recliner Chair, providing assembly instructions, usage guidelines, maintenance tips, warnings, and troubleshooting information.
	FlexiSpot DT3B-EU User Manual and Warranty Information Comprehensive user manual for the FlexiSpot DT3B-EU height adjustable desk frame, including detailed assembly instructions, parts list, and warranty coverage information.
	FlexiSpot XP6 Pushback Recliner Chair User Manual Comprehensive user manual for the FlexiSpot XP6 Pushback Recliner Chair, covering assembly instructions, product specifications, usage guidelines, maintenance tips, warnings, and troubleshooting.
	FlexiSpot XC6 Recliner Chair User Manual: Assembly, Operation, and Safety Guide This user manual provides detailed assembly instructions, usage guidelines, maintenance tips, and safety warnings for the FlexiSpot XC6 recliner chair (Item No. XC6-BG-EU/XC6-OB-EU/XC6-LG-EU). Learn how to set up, operate, and safely use your chair.

	Flexispot Power Swivel Rocker Recliner Assembly and User Guide Detailed assembly instructions, product specifications, usage guidelines, and troubleshooting for the Flexispot Power Swivel Rocker Recliner. Learn how to set up and operate your new recliner chair safely and efficiently.
	FlexiSpot XR5 Electric Recliner Chair: Assembly, Specifications, and Operation Guide Comprehensive guide for the FlexiSpot XR5 electric recliner chair. Learn about its materials, specifications, energy efficiency, step-by-step assembly, switch functions, and troubleshooting. Includes power supply details and safety warnings.