Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- > Perlegear /
- > Perlegear Long Arm Full Motion TV Wall Mount (Model PGXLF02) Instruction Manual

Perlegear PGXLF02

Perlegear Long Arm Full Motion TV Wall Mount (Model PGXLF02) Instruction Manual

For 42-90 Inch TVs up to 150 lbs

1. Introduction

This manual provides detailed instructions for the safe and proper installation, operation, and maintenance of your Perlegear Long Arm Full Motion TV Wall Mount, Model PGXLF02. Please read all instructions carefully before beginning installation and keep this manual for future reference.



Image 1: Perlegear Long Arm Full Motion TV Wall Mount, Model PGXLF02.

2. SAFETY INFORMATION

- Weight Capacity: Do not exceed the maximum weight capacity of 150 lbs (68 kg).
- TV Size: This mount is designed for TVs between 42 and 90 inches.
- Wall Type: Install only on wood studs (8"/12"/16"/24" spacing), solid concrete, or brick walls.**Do not install on drywall alone.**
- **Professional Assistance:** If you are unsure about the installation process or wall type, consult a qualified professional.
- Tools: Handle all tools with care to prevent injury.
- Assembly: Two people are recommended for safe installation, especially when lifting the TV.

3. SETUP & INSTALLATION

3.1. Tools Required

The following tools are required for installation. Some are included, others are not.

- Not Included: Electric Drill, Pencil, Phillips Screwdriver, Tape Measure, 1/2" (13mm) Socket Wrench.
- For Wood Stud Walls: Stud Finder, Awl, 7/32" (5.5mm) Wood Drill Bit.
- For Solid Concrete/Brick: Hammer, 3/8" (10mm) Concrete Drill Bit.
- Included: Bubble Level, Allen Key.

3.2. TV and Wall Compatibility

Ensure your TV and wall are compatible with this mount before proceeding.

- TV Size: Compatible with most flat or curved 42"-90" TVs.
- Weight Capacity: Supports TVs up to 150 lbs (68 kg).
- VESA Patterns: Supports VESA patterns from 200x100mm to 800x400mm.
- Wall Types: Suitable for 8"/12"/16"/24" wood studs, solid concrete, or brick walls. Do not install on drywall alone.

Wide Compatibility

Concrete Walls



Wood Stud Spacing **24"/16"/12"**

Max 24"

Brick Walls







VESA PATTERNS

800x400mm 600x400mm 500x400mm 400x400mm 400x300mm 400x200mm 300x400mm 300x300mm 300x200mm 200x400mm 200x300mm 200x200mm

200x100mm

Image 2: Compatibility details for wall types, TV sizes, and VESA patterns.




Image 3: Visual guide for checking TV and wall compatibility, including VESA patterns and wall plate dimensions.

3.3. Step-by-Step Installation

The Perlegear TV mount features a pre-assembled design for easier installation. Follow these general steps:

- 1. Attach TV Brackets to the TV: Select the appropriate bolts and spacers for your TV type (flat back, curved back, or TVs with mounting restrictions). Secure the TV brackets to the back of your TV.
- 2. **Mount Arm Assembly / Wall Plate on the Wall:**Locate your wall studs (for wood stud installation) or mark drill points (for solid concrete/brick). Use the provided drilling template and bubble level to ensure accurate placement. Drill pilot holes and securely fasten the wall plate to the wall using the appropriate lag bolts and washers. Verify the wall plate is securely attached by pulling down on it.
- 3. **Hang the TV:** Carefully lift the TV with the attached brackets and hook them onto the wall plate. Secure the TV to the mount using the safety locks.



Image 4: Overview of the 3-step installation process: attach TV brackets, mount wall plate, and hang TV.

3.4. Installation Video Guide

For a visual guide on the installation process, please refer to the official video below:

Your browser does not support the video tag.

Video 1: Perlegear Long Arm Full Motion TV Mount Installation Guide. This video demonstrates the complete installation process for the PGXLF02 series TV mount, including tool gathering, attaching TV brackets, mounting the wall plate, and securing the TV.

4. OPERATION & ADJUSTMENTS

Your Perlegear TV mount offers various adjustments for optimal viewing comfort.

4.1. Extension and Retraction

The long arm extends up to 40 inches (101.6 cm) for closer viewing and retracts to 3.55 inches (9 cm) to save space. This allows for flexible positioning and multi-zone viewing.



Image 5: Demonstrates the mount's extension capability, bringing the TV closer for viewing or retracting it to save space.

4.2. Swivel Adjustment

The mount allows for a ±90° swivel, enabling you to adjust the TV's angle for viewing from different positions in a room, including corner installations.



Image 6: Illustrates the multi-zone viewing capability with swivel and leveling adjustments.




Image 7: Shows the mount's suitability for corner installations, allowing for wide swivel angles.

4.3. Tilt Adjustment

Adjust the TV tilt from +5° to -12° to reduce glare and achieve your preferred viewing angle. The mount features a tool-free tilt adjustment mechanism.



Image 8: Highlights the tool-free tilt adjustment feature for quick and easy angle changes.

4.4. Leveling Adjustment

After installation, you can make a ±3° leveling adjustment to ensure your TV is perfectly horizontal.

4.5. Cable Management

Route your cables along the mount arms and secure them with the provided cable ties to maintain a neat and organized appearance.

4.6. Motion Demonstration Video

Observe the full range of motion and adjustment capabilities of the mount in the video below:

Your browser does not support the video tag.

Video 2: Long Arm TV Mount for Cross-Zone Viewing Experience. This video showcases the mount's long extension, swivel, and tilt features, demonstrating how it enables flexible viewing from various angles and locations.

5. MAINTENANCE

Regular maintenance helps ensure the longevity and safe operation of your TV mount.

- Cleaning: Wipe the mount with a soft, dry cloth to remove dust. Avoid abrasive cleaners or solvents.
- Periodic Checks: Periodically check all screws and bolts to ensure they remain tight. Re-tighten if necessary.
- Moving Parts: The articulating arms are designed for smooth movement. If movement becomes stiff, ensure no cables are snagged and check for any obstructions. Do not apply lubricants unless specifically recommended by the manufacturer.

6. TROUBLESHOOTING

If you encounter issues with your TV mount, refer to these common solutions:

- TV Not Level: Use the ±3° leveling adjustment feature. If still not level, slightly loosen the bolts on the leveling mechanism, adjust, and then retighten.
- **Difficulty Tilting:** If the tilt is too stiff or won't hold, slightly loosen the bolt on one side of the tilt mechanism, adjust, and then retighten both bolts. If it won't hold, fully tighten the bolt on the other side.
- **Mount Feels Loose:** Re-check all wall plate lag bolts and TV bracket screws to ensure they are securely tightened.
- Limited Movement: Ensure no cables are obstructing the articulating arms. Check for any physical obstructions around the mount.

7. Specifications

Feature	Specification
Brand	Perlegear
Model	PGXLF02
TV Size Compatibility	42-90 inches

Feature	Specification		
Maximum Load Capacity	150 lbs (68 kg)		
VESA Compatibility	200x100mm to 800x400mm		
Wall Plate Dimensions	14.6 inches (width) x 28.07 inches (length)		
Wall Stud Spacing	8"/12"/16"/24"		
Extension from Wall	3.55 inches (retracted) to 40 inches (extended)		
Swivel Angle	±90°		
Tilt Angle	+5° / -12°		
Leveling Adjustment	±3°		
Material	Alloy Steel		
Color	Black		
Item Weight	29.3 pounds		




Image 9: Detailed view of the mount's construction, highlighting features for maximum stability and flexibility, such as thicker arms and an arm reinforcement bar.

8. WARRANTY & SUPPORT

This product is designed for durability and reliability. While specific warranty details are not provided in this manual, Perlegear typically offers product support for its customers.

For any questions, technical assistance, or to inquire about warranty information, please contact the Perlegear support team directly.

Support Email: support@perlegear.com

Related Documents - PGXLF02



Perlegear PGLF8 Full Motion TV Wall Mount Installation Guide

Comprehensive instruction manual for the Perlegear PGLF8 Full Motion TV Wall Mount. Learn how to safely install and adjust your TV mount for TVs up to 132 lbs, with detailed steps for wood stud and concrete wall installations.



Perlegear PGMFK3 Full-Motion TV Wall Mount Instruction Manual

Comprehensive instruction manual for the Perlegear PGMFK3 full-motion TV wall mount, covering VESA compatibility, load capacity, wall type selection, installation steps, and TV mounting. Includes safety guidelines and parts identification.



PERLEGEAR PGSF6 Full-Motion TV Wall Mount Installation Guide

Comprehensive installation guide for the PERLEGEAR PGSF6 Full-Motion TV Wall Mount. Includes safety warnings, compatibility checks, parts list, step-by-step assembly instructions for various wall types, TV attachment, adjustments, and troubleshooting FAQs.



Perlegear PGLF18 Full-Motion TV Wall Mount Instruction Manual

Comprehensive instruction manual for the Perlegear PGLF18 full-motion TV wall mount. Includes installation steps, parts list, safety guidelines, and troubleshooting for mounting TVs up to 100 lbs.



Perlegear PGLF12 Full-Motion TV Wall Mount Installation Manual

This manual provides detailed instructions for installing the Perlegear PGLF12 Full-Motion TV Wall Mount. It covers safety information, parts identification, and step-by-step assembly for various TV types and wall constructions, including wood studs, solid concrete, and brick walls.



Perlegear PGMF21 Full-Motion TV Wall Mount Instruction Manual

Comprehensive instruction manual for the Perlegear PGMF21 full-motion TV wall mount. Learn how to safely and securely install your TV, compatible with 32-65 inch TVs up to 99 lbs and VESA patterns up to 400x400mm.