

[Manuals.plus](#) /

› [HOLFENRY](#) /

› HOLFENRY JKS60E Rechargeable Personal Sound Amplifier Instruction Manual

HOLFENRY JKS60E

HOLFENRY JKS60E Rechargeable Personal Sound Amplifier Instruction Manual

Model: JKS60E

INTRODUCTION

This manual provides detailed instructions for the HOLFENRY JKS60E Rechargeable Personal Sound Amplifier. Please read this guide carefully before using your device to ensure proper operation, maximize its lifespan, and understand all features. This device is designed to amplify sound for individuals with mild to moderate hearing loss.

WHAT'S IN THE BOX


Verify that all items are present in your package:

- 1x HOLFENRY JKS60E Personal Sound Amplifier
- 1x Earphones
- 3 Pairs of Ear Domes (Sizes: Small, Medium, Large)
- 1x Charging Cable (Type-C)

Charging Port
Headphone Port

Power on / off

Volume
Adjustment



Ear Domes
(S/M/L)



Earphone



Pocket
Hearing Aid



Charge Cable

Image: Components included with the HOLFENRY JKS60E Personal Sound Amplifier.

SETUP INSTRUCTIONS

Follow these steps to prepare your personal sound amplifier for first use:

1. **Charge the Device:** Before initial use, fully charge the amplifier. Refer to the "Charging" section for detailed instructions.

2. **Select Ear Domes:** Choose the ear domes that best fit your ear canal. A proper fit is crucial for comfort and optimal sound quality, and helps reduce feedback (squealing).
3. **Attach Earphones:** Plug the earphone cable securely into the designated port on the personal sound amplifier.
4. **Power On:** Long press the power button (located on the side) for 2-3 seconds until you hear 4 beeps, indicating the device is powered on.

How To Use?



Step1 >>

Choose ear domes.



Step2 >>

Plug in the headphone cable to the pocket hearing aid.



Step3 >>

Long press to power on.



Step4 >>

Click the button to adjust the volume (▲ In order to protect your ears, please adjust the volume before wearing it for the first time)

Setup Video Guide

Your browser does not support the video tag.

Video: A comprehensive guide demonstrating the setup and initial use of the HOLFENRY JKS60E Personal Sound Amplifier.

OPERATING THE DEVICE

Volume Adjustment

The HOLFENRY JKS60E features 10 levels of volume adjustment to suit various listening environments and personal preferences.

1. **Adjusting Volume:** Click the middle button on the amplifier to cycle through the 10 volume levels.
2. **Wearing Caution:** To prevent potential ear damage from sudden loud sounds, it is recommended to adjust the volume to a comfortable level **before** placing the earphones in your ears for the first time. The device retains your last set volume level.



Image: The amplifier is designed for user-friendly operation, particularly for seniors.

CHARGING

The HOLFENRY JKS60E is equipped with a rechargeable battery, offering approximately 100 hours of continuous use on a single charge. A full charge typically takes about 2 hours.

1. **Connect Charger:** First, unplug the earphone cable from the amplifier. Then, connect the provided Type-C charging cable to the microphone port on the device.
2. **Charging Indicator:** An orange indicator light will illuminate when the device is charging.
3. **Full Charge:** The orange indicator light will turn off once the device is fully charged.

No Longer Replace Battery

Charge before bed and wake up with a week of hearing

100H

Used for a week

Working Time

2H

Type-C

Charge Time




Image: Charging the amplifier, highlighting its long battery life and quick charge time.

Charging Video Guide

Your browser does not support the video tag.

Video: This segment of the video demonstrates how to properly charge the HOLFENRY JKS60E Personal Sound Amplifier and interpret its charging indicators.

MAINTENANCE

Proper care and maintenance will extend the life of your personal sound amplifier:

- **Cleaning:** Regularly clean the ear domes and the amplifier body with a soft, dry cloth. Do not use harsh chemicals or immerse the device in water.
- **Storage:** Store the amplifier in a cool, dry place away from direct sunlight and extreme temperatures when not in use.
- **Ear Wax:** Ensure ear domes are free of ear wax buildup, as this can affect sound quality and device performance.

TROUBLESHOOTING

If you encounter issues with your HOLFENRY JKS60E, refer to the following common solutions:

- **No Sound or Low Volume:**
 - Ensure the device is powered on.
 - Check the volume level and adjust it using the middle button.
 - Verify the earphones are securely plugged in.
 - Inspect ear domes for blockages (e.g., ear wax) and clean if necessary.
 - Ensure the device is fully charged.
- **Squealing/Feedback:**
 - Ensure the ear domes are correctly sized and properly seated in your ear canal to create a good seal.
 - Adjust the volume to a lower setting.
 - Check for any obstructions near the microphone.
- **Ear Domes Don't Fit:**
 - The package includes three sizes (S/M/L) of ear domes. Experiment with different sizes to find the most comfortable and effective fit for your ear canal.
- **Device Does Not Turn On:**
 - Ensure the device is fully charged.
 - Press and hold the power button for the required 2-3 seconds.
- **Loud Sound on Power On:**
 - It is recommended to adjust the volume to a low setting before placing the earphones in your ears and powering on the device.

SPECIFICATIONS

Feature	Detail
Model Name	JKS60E
Brand	HOLFENRY
Power Source	Battery Powered (Rechargeable)
Maximum Output	Up to 130 dB
Squealing Reduction	95%

Continuous Use Time	Approx. 100 hours
Charging Time	Approx. 2 hours (Type-C)
Volume Levels	10 levels
Package Dimensions	4.45 x 3.46 x 2.05 inches
Item Weight	4.97 ounces



Image: Key performance specifications of the amplifier.

WARRANTY AND SUPPORT

Specific warranty details for the HOLFENRY JKS60E Personal Sound Amplifier are not provided in the product information. For any warranty claims, technical support, or service inquiries, please contact HOLFENRY customer service directly through their official channels or the retailer where the product was purchased.

Optional protection plans may be available for purchase separately from third-party providers. Please refer to the terms and conditions of any such plans for coverage details.

You can visit the official HOLFENRY store for more information:[HOLFENRY Store](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question