

[Manuals.plus](#) /

› [viquee](#) /

› viquee P60 3G Mini Smartphone User Manual

viquee P60

viquee P60 3G Mini Smartphone User Manual

Model: P60

1. INTRODUCTION

This manual provides essential instructions for setting up, operating, maintaining, and troubleshooting your viquee P60 3G Mini Smartphone. Please read this guide thoroughly to ensure proper use and to maximize the device's functionality.

Product Overview

The viquee P60 is a compact 3G mini smartphone featuring a 3.0-inch HD screen, 3GB RAM, 64GB ROM (expandable), dual cameras, GPS, and Face ID. It operates on Android 8.1 and supports dual SIM cards, making it suitable for various communication and educational needs.



Image 1.1: Front and back view of the viquee P60 Mini Smartphone.

2. SETUP

2.1 Unboxing

Upon opening the package, verify that the following items are present:

- viquee P60 3G Mini Smartphone

- Phone Case
- Charging Cable (USB)
- Power Adapter (may vary by region)
- User Manual (this document)

2.2 SIM Card and Memory Card Installation

The viquee P60 supports dual SIM cards and an expandable memory card. To install:

1. Locate the SIM/memory card tray on the side of the device.
2. Insert the SIM ejector tool (not typically included, use a thin pin) into the small hole next to the tray to open it.
3. Place your Nano-SIM cards and/or microSD card into the designated slots on the tray. Ensure correct orientation.
4. Gently push the tray back into the device until it clicks into place.

2.3 Initial Charging

Before first use, fully charge the device. Connect the USB charging cable to the phone's charging port and the other end to the power adapter. Plug the adapter into a wall outlet. The battery indicator on the screen will show charging progress.

Hi-def camera, quick release

Every time you press the shutter, it shows subtle colors and moving momentsof light and dark details better.



The figure is more beautiful and chaming

Portrait mode, how to shoot are photogenic,provide a variety of illusory style mask intelligent optimization of skineasy to take a shot, change the style of selfie.



Capture the moment, wonderful moment

The main camera has a large aperture and micron pixels This powerful combination enhances sensitivity in backlight or low lightso just aim and shoot to make sure your photos stay shanp and bright



2.4 Power On and Initial Setup

Press and hold the Power button (located on the side) until the screen lights up. Follow the on-screen prompts to complete the initial setup, including language selection, Wi-Fi connection, Google account login, and security settings.

3. OPERATING INSTRUCTIONS

3.1 Basic Navigation

The viquee P60 features a touchscreen interface. Use the following gestures:

- **Tap:** To select an item or open an app.
- **Swipe:** To scroll through screens or lists.
- **Pinch:** To zoom in or out on images and web pages.

3.2 Calls and Messaging

To make a call, open the Phone app, enter the number, and tap the call icon. To send a message, open the Messages app, select a contact or enter a number, type your message, and tap send.

3.3 Camera Usage

The device is equipped with a 2.0MP front camera and a 5.0MP rear camera. Open the Camera app to capture photos and videos. Tap the screen to focus and press the shutter button to take a picture.

Product Size



Image 3.1: Illustration of the viquee P60 Mini Smartphone's camera capabilities.

3.4 Connectivity

- **Wi-Fi:** Go to Settings > Network & Internet > Wi-Fi to connect to available networks.
- **Bluetooth:** Go to Settings > Connected devices > Bluetooth to pair with other Bluetooth devices.
- **Hotspot:** Share your phone's 3G internet connection by navigating to Settings > Network & Internet > Hotspot & tethering.

3.5 GPS Navigation

Utilize the built-in GPS for location services and navigation. Compatible mapping applications can be downloaded from the Google Play Store.

3.6 Face ID

To set up Face ID for secure unlocking, go to Settings > Security & location > Face Unlock. Follow the on-screen instructions to register your face.

3.7 App Management

The viquee P60 runs on Android 8.1 and supports applications from the Google Play Store. To download apps, open the Play Store app, search for your desired application (e.g., Facebook, YouTube, WhatsApp, TikTok), and tap 'Install'.



Image 3.2: Example of educational applications on the viquee P60 Mini Smartphone.

4. MAINTENANCE

4.1 Cleaning

Use a soft, lint-free cloth to clean the screen and body of the phone. Avoid using harsh chemicals or abrasive materials.

4.2 Software Updates

Periodically check for software updates to ensure optimal performance and security. Go to Settings > System > System update.

4.3 Battery Care

To prolong battery life:

- Avoid extreme temperatures.
- Do not leave the phone charging for extended periods after it's full.
- Use the original charger or a certified compatible charger.

4.4 Storage Management

The device has 64GB of internal storage. To manage storage, go to Settings > Storage. You can free up space by uninstalling unused apps, deleting old files, or moving media to an installed microSD card.

RAM 3GB+ ROM 64GB

Massive Memory Can Help You Record The Good Times in Your Life



Image 4.1: Visual representation of the 3GB RAM and 64GB ROM in the viquee P60 Mini Smartphone.

5. TROUBLESHOOTING

If you encounter issues with your viquee P60, try the following solutions:

Problem	Solution
Phone does not turn on	Ensure the battery is charged. Press and hold the Power button for at least 10 seconds.
Apps are crashing or freezing	Restart the phone. Clear the app's cache (Settings > Apps & notifications > [App Name] > Storage & cache).
No network signal	Check SIM card installation. Ensure Airplane Mode is off. Restart the phone. Contact your service provider.
Battery drains quickly	Reduce screen brightness. Close unused apps. Disable Wi-Fi/Bluetooth when not in use.
Face ID not working	Ensure your face is well-lit and unobstructed. Re-register your face in settings if necessary.

If problems persist, consider performing a factory reset (Settings > System > Reset options > Erase all data).**Warning:** A factory reset will erase all data on your phone. Back up important information before proceeding.

6. SPECIFICATIONS

Feature	Detail
Model Number	P60
Operating System	Android 8.1
Display Size	3.0 Inches
Resolution	480 x 800
RAM	3 GB
ROM	64 GB (expandable via microSD)
CPU Model	MTK 8121
CPU Speed	1.3 GHz
Front Camera	2.0 MP
Rear Camera	5.0 MP
Battery Capacity	2000 mAh
Connectivity	3G, Wi-Fi, Bluetooth
GPS	Yes
Dimensions (L x W x H)	90.5 x 46.5 x 11.2 mm (3.56 x 1.83 x 0.44 inches)
Item Weight	10.6 ounces

Fast charging and long standby



Strong performance

Mrk6580 Quad core series CPU Play games, multitask, stress free, experience smooth and smooth without stuttering

Image 6.1: Physical dimensions of the viqee P60 Mini Smartphone.

7. WARRANTY AND SUPPORT

Your viqee P60 3G Mini Smartphone is covered by a standard manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions.

For technical support or warranty claims, please contact viqee customer service through the retailer where you purchased the device or visit the official viqee website for contact information.

© 2024 viqee. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question