

043-8609-4, 043-0758-6, 043-0759-4

Replacement Remote Control User Manual

For NOMA Window Air Conditioner Models: 043-8609-4, 043-0758-6, 043-0759-4

INTRODUCTION

This document provides instructions for the replacement remote control designed for specific NOMA Window Air Conditioner models. This remote is a dedicated replacement and may not support all functions of the original remote control. No programming or complex setup is required for its use.

SETUP AND BATTERY INSTALLATION

This replacement remote control requires no programming or complex setup. Simply install the batteries to begin operation.

Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards or in the direction indicated by an arrow to open it.
3. Insert two AAA batteries (not included), ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery cover back into place until it clicks securely.



Image: Front view of the white replacement remote control. The battery compartment is located on the back of the device.

OPERATING INSTRUCTIONS

Remote Control Layout



Image: Angled view of the white replacement remote control, displaying its various buttons and their labels.

Button Functions

The remote control features several buttons for operating your NOMA Window Air Conditioner. Please note that as a replacement remote, some functions may not be identical to or supported by your original unit.

- **Power Button** (⏻): Turns the air conditioner On or Off.
- **Temperature Up/Down** (▲ / ▼): Adjusts the desired temperature setting.
- **Fan**: Cycles through fan speed settings (e.g., Low, Medium, High, Auto).
- **Mode**: Changes the operating mode of the air conditioner (e.g., Cool, Dry, Fan, Auto).
- **Dimmer**: Adjusts the brightness of the air conditioner's display panel.
- **Sleep**: Activates or deactivates the sleep mode, which typically adjusts temperature for comfort during sleep and saves energy.
- **Timer**: Sets a timer for the air conditioner to turn On or Off automatically.
- **Filter**: Resets the filter indicator light after cleaning or replacing the air filter.

MAINTENANCE

Cleaning

- Wipe the remote control periodically with a soft, dry cloth.
- Do not use liquid cleaners, sprays, or abrasive materials, as these can damage the remote's surface or internal components.

Battery Replacement

- Replace batteries when the remote's range decreases or it stops responding.
- Always replace both batteries at the same time with new ones of the same type (AAA).
- Remove batteries if the remote will not be used for an extended period to prevent leakage.

TROUBLESHOOTING

- **Remote not responding:**
 - Check if the batteries are inserted correctly with the correct polarity.
 - Replace old batteries with new ones.
 - Ensure there are no obstructions between the remote control and the air conditioner's receiver.
 - Make sure you are within the effective operating range of the air conditioner.
- **Some functions do not work:**
 - This is a replacement remote control. It may not support all advanced or specific functions of your original air conditioner remote. This is not a defect.
 - Refer to your air conditioner's original manual for specific feature compatibility.

SPECIFICATIONS


| | |
|--|--|
| Brand | Generic |
| Manufacturer | REMOTE NKEB STORE |
| Compatible Devices | NOMA Window Air Conditioner Models: 043-8609-4, 043-0758-6, 043-0759-4 |
| Material | ABS/Plastic |
| Color | Random (as supplied) |
| Special Feature | Digital Display (Refers to the controlled unit's display, not the remote itself) |
| Max Number of Supported Devices | 1 |

SUPPORT

If you encounter issues not covered in this manual or require further assistance, please contact the seller or manufacturer directly for support.



Related Documents - 043-8609-4, 043-0758-6, 043-0759-4

| | |
|--|---|
|  <p>NOMA PORTABLE AIR CONDITIONER www.noma.com/43-8610-8-043-8611-6-043-8612-4-0756-0 Toll Free: 1-866-827-4985 Please see our website for the most current information on our products. Instruction Manual</p> | <p>NOMA Portable Air Conditioner Instruction Manual</p> <p>Comprehensive instruction manual for NOMA portable air conditioners, covering installation, operation, care, and troubleshooting for models 043-8610-8, 043-8611-6, 043-8612-4, and 043-0756-0.</p> |
|  <p>NOMA TRUE HEPA AIR PURIFIER ...MEDIUM... ...LARGE... USER MANUAL ...DEAD AND LIVE TEST BODIES...</p> | <p>NOMA True HEPA Air Purifier User Manual</p> <p>User manual for NOMA True HEPA Air Purifiers (Medium and Large models), covering setup, operation, cleaning, filter replacement, specifications, FAQs, safety, troubleshooting, and warranty.</p> |
|  <p>NOMA TRUE HEPA AIR PURIFIER ...MEDIUM... ...LARGE... USER MANUAL ...DEAD AND LIVE TEST BODIES...</p> | <p>NOMA True HEPA Air Purifier User Manual</p> <p>User manual for NOMA True HEPA Air Purifiers (Medium & Large models 043-7340-6, 043-7341-4) covering setup, operation, cleaning, filter replacement, specifications, FAQs, safety, and troubleshooting.</p> |
|  <p>NOMA PORTABLE AIR CONDITIONER WINDOW KIT INSTALLATION MANUAL ...PARTS LIST... ...TOOL LIST... ...WINDOW SUITABILITY... ...STEP-BY-STEP ASSEMBLY AND CONNECTION PROCEDURES...</p> | <p>NOMA Portable Air Conditioner Window Kit Installation Manual</p> <p>This manual provides instructions for installing the NOMA Portable Air Conditioner Window Kit, including parts identification, window suitability, and step-by-step assembly and connection procedures.</p> |
|  <p>NOMA OSCILLATING DIGITAL CERAMIC TOWER HEATER WITH REMOTE CONTROL ...MODELS 043-7364-0 AND 043-7365-8... Toll Free: 1-866-827-4985 Please see our website for the most current information on our products. Instruction Manual</p> | <p>NOMA Oscillating Digital Ceramic Tower Heater with Remote Control - Instruction Manual</p> <p>Comprehensive instruction manual for the NOMA Oscillating Digital Ceramic Tower Heater (models 043-7364-0 and 043-7365-8), covering safety, operation, assembly, maintenance, and troubleshooting.</p> |

PATTERSON
 645-2428 FAX 603
 645-2428 FAX 603
E-type Low-speed Airmotor

1. Introduction
 The Patterson E-type low-speed airmotor is a precision-engineered motor designed for use in dental, medical, and laboratory applications. It is characterized by its compact size, low noise level, and long life expectancy.

2. Specifications

| Model | Speed (RPM) | Output (W) | Weight (g) |
|----------|-------------|------------|------------|
| 645-2428 | 1000 | 1.0 | 100 |
| 645-2429 | 1500 | 1.5 | 150 |
| 645-2430 | 2000 | 2.0 | 200 |

3. Features

- Low noise level
- Long life expectancy
- Compact size
- Low power consumption

4. Installation

4.1. Mounting: The airmotor should be mounted on a rigid surface. The mounting holes are spaced 10mm apart.

4.2. Wiring: The airmotor is supplied with a 2-wire power cord. The wires are color-coded: red for positive (+) and black for negative (-). The airmotor should be connected to a power source with a voltage of 120V AC.

5. Operation

5.1. Start-up: Before starting the airmotor, ensure that the power is off. Turn the power on and the airmotor will start to rotate.

5.2. Stopping: To stop the airmotor, turn the power off.

6. Maintenance

6.1. Cleaning: The airmotor should be cleaned regularly with a soft cloth. Do not use harsh chemicals or solvents.

6.2. Lubrication: The airmotor does not require lubrication.

7. Safety

7.1. Do not touch the rotating parts of the airmotor.

7.2. Do not use the airmotor for purposes other than those intended.

7.3. Do not use the airmotor in a flammable or explosive atmosphere.

[Patterson E-type Low-speed Airmotor Operation Manual](#)

Operation manual for Patterson E-type Low-speed Airmotors, including specifications, part descriptions, installation, operation, cleaning, lubrication, sterilization, and warranty information.