Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- > WE-VIBE /
- > We-Vibe Sync 2 Couples Vibrator Instruction Manual

WE-VIBE Sync 2

We-Vibe Sync 2 Couples Vibrator Instruction Manual

Model: Sync 2 | Brand: WE-VIBE

INTRODUCTION

The We-Vibe Sync 2 is an app-controlled, rechargeable couples vibrator designed for shared pleasure. Its ergonomic shape and flexible design provide dual stimulation for both partners during intimate moments. This manual provides essential information for setting up, operating, and maintaining your Sync 2 device.

PRODUCT FEATURES

- Ergonomic Pleasure Shape: Designed for shared vibrations during sex, ensuring a snug fit and dual pleasure.
- Adjustable Fit: Features a flexible internal arm that adapts to your body for targeted vibrations, staying in place during various positions.
- App & Remote Control: Control your Sync 2 using the free We-Vibe app or the included single-button remote for personalized settings and long-distance play options.
- Waterproof & Rechargeable: Fully waterproof (IPX7 rated) for use in baths or showers, and easy to clean. It is also rechargeable for convenience.
- Smooth as Silk: Made from ultra-hygienic, skin-friendly silicone, free from phthalates, BPA, or latex, ensuring durability and comfort.

WHAT'S INCLUDED

Your We-Vibe Sync 2 package includes:

- We-Vibe Sync 2 device
- Remote control
- · USB charging cable
- Storage pouch
- · Quick start guide and compliance information
- · Sample of water-based lubricant



Take Sync for a shower



Sync 2 is 100% waterproof (IPX7), making it easy to enjoy anywhere and simple to clean.

Image: The complete We-Vibe Sync 2 package contents, showing the vibrator, remote, charging cable, storage pouch, and lubricant.

SETUP

1. Charging the Device

Before first use, fully charge your We-Vibe Sync 2. The device is USB rechargeable.

- 1. Locate the charging port on the device.
- 2. Connect the magnetic USB charging cable to the device.
- 3. Plug the USB end into a compatible USB power source (e.g., computer, USB wall adapter).
- 4. The indicator light on the device will show charging status. A full charge typically takes about 1 hour and provides up to 120 minutes of active use.



Image: A hand connecting the magnetic USB charging cable to the We-Vibe Sync 2 device.

2. App Connection & Remote Control Pairing

The Sync 2 can be controlled via its single-button remote or the We-Vibe App.

- Remote Control: Ensure the remote has power (check for a battery tab to remove if new). Press and hold the power button on the remote to turn it on. The remote will automatically pair with the Sync 2 device when both are active and in close proximity.
- We-Vibe App:
 - a. Download the free We-Vibe App from your device's app store.

- b. Ensure your Sync 2 device is charged and turned on.
- c. Open the We-Vibe App and follow the on-screen instructions to connect your Sync 2 device via Bluetooth.
- d. The app offers various modes and options for customized control, including long-distance play.




Image: The We-Vibe Sync 2, its remote, and a smartphone showing the app, illustrating connectivity options.

OPERATING INSTRUCTIONS

1. Basic Operation

- Power On/Off: Press and hold the power button on the Sync 2 device or the remote control to turn it on or off.
- Adjusting Modes/Intensities: Short press the mode button on the device or remote to cycle through the 10 available vibration modes and intensities.

2. Usage with Partner

The Sync 2 is designed to be worn during partnered intimate activity.

- 1. Apply a water-based lubricant to the internal arm of the device and gently squeeze the flexible inner arm to facilitate easy insertion.
- 2. Position the device to ensure optimal G-spot and clitoral stimulation for one partner, while the external arm provides stimulation for the other.
- 3. Adjust vibration settings using the remote or app to find your preferred rhythm and intensity.



Image: The We-Vibe Sync 2 device, remote, and app, highlighting its design for dual stimulation.

MAINTENANCE

1. Cleaning

The Sync 2 is fully waterproof (IPX7 rated) for easy cleaning.

- Always clean your device before and after each use.
- Wash with warm water and a mild soap or a specialized toy cleaner.
- Rinse thoroughly and allow to air dry completely before storing.
- Do not submerge the remote control in water; it is not waterproof.



Adjustable fit



Soft edges and sleek design means Sync 2 slips inside comfortably, allowing easy wear.

Image: The We-Vibe Sync 2 device partially submerged in water, showing its waterproof capability.

2. Storage

Store your Sync 2 in the provided storage pouch in a cool, dry place, away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

- **Device not turning on:** Ensure the device is fully charged. Connect it to the charger and check if the indicator light appears.
- Remote/App connection issues:
 - Ensure both the Sync 2 and the remote/smartphone are fully charged.
 - Make sure Bluetooth is enabled on your smartphone.
 - Try restarting both the Sync 2 and your remote/app.
 - Ensure the remote is within range of the device.
 - If using the app, check for app updates and ensure your device's operating system is up to date.
- Weak vibrations: The device may need to be recharged.
- Discomfort during use: Ensure you are using a generous amount of water-based lubricant. Adjust the position of

the device for comfort.

If you continue to experience issues, please refer to the official We-Vibe support resources or contact customer service.

SPECIFICATIONS

Product Dimensions	12.64 x 11.5 x 9.06 inches; 2.47 ounces
Item Model Number	Sync 2
Batteries	1 Lithium Ion battery required (included)
Material	Silicone
Waterproof Rating	IPX7 (device only, remote is not waterproof)
Manufacturer	WOW Tech

WARRANTY & SUPPORT

For warranty information and customer support, please visit the official WE-VIBE website or contact their customer service directly. Keep your proof of purchase for any warranty claims.

OFFICIAL PRODUCT VIDEOS

We-Vibe Sync 2 Unboxing

Your browser does not support the video tag.

Video: An official unboxing video for the We-Vibe Sync 2, demonstrating the contents of the package.

We-Vibe Sync 2 Unboxing Purple

Your browser does not support the video tag.

Video: An official unboxing video specifically for the purple variant of the We-Vibe Sync 2, showcasing its features and packaging.

© 2025 WE-VIBE. All rights reserved.

Related Documents - Sync 2

Sync Table of contents 1. Speciments 2. Speciments 3. Owners 4. Person operator resists 6. Person operator resists 6. Person operator resists 6. Contents	We-Vibe Sync User Manual Comprehensive guide to the We-Vibe Sync, covering features, usage, charging, pairing, and safety instructions. Learn how to maximize your experience with this advanced personal massager.
	We-Vibe Sync™: User Guide and Product Information Comprehensive guide for the We-Vibe Sync™ couples vibrator, including setup, app connectivity, safety warnings, warranty, and compliance information. Features external and G-spot stimulation.
We-Vibe's Plus - Vibrator (for Pause - Vibrator (for	We-Vibe 4 Plus Vibrator for Couples: User Guide and Features Comprehensive guide to the We-Vibe 4 Plus, a couples vibrator designed for enhanced intimacy and pleasure. Learn about its features, app control, usage, charging, cleaning, and specifications.
Sync:	We-Vibe Sync™ User Manual: Features, Operation, and Care Comprehensive user manual for the We-Vibe Sync™ personal massager, covering features, charging, operation, safety, app connectivity, and troubleshooting. Learn how to use your Sync for optimal pleasure.
User Manual	Thrill by We-Vibe User Manual: Dual Stimulation and Features Comprehensive user manual for the Thrill by We-Vibe, detailing its dual stimulation design, charging, operation, cleaning, troubleshooting, and warranty information.
User Manual	Thrill by We-Vibe User Manual User manual for the Thrill by We-Vibe rechargeable and waterproof vibrator, detailing features, first steps, charging, cleaning, troubleshooting, and warranty information.