

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Legami](#) /

› [LEGAMI Erasable Gel Pens User Manual - Model 8051128755992](#)

Legami 8051128755992

LEGAMI Erasable Gel Pens User Manual

Model: 8051128755992

INTRODUCTION

This manual provides instructions for the use and care of your LEGAMI Set of 5 Erasable Gel Pens. These pens feature thermosensitive ink, allowing for smooth writing and clean erasure. The set includes pens with unique animal designs: Penguin (turquoise ink), Panda (black ink), Llama (blue ink), Bee (black ink), and Hippo (blue ink).



Image: The complete set of five Legami erasable gel pens, each featuring a different animal design and ink color.

SETUP

Your LEGAMI Erasable Gel Pens are ready for immediate use.

- 1. Uncap the Pen:** Remove the protective cap from the writing end of the pen.
- 2. Inspect the Tip:** Ensure the 0.7mm tip is clear of any debris.



Image: A close-up view of one of the Legami erasable gel pens, highlighting its design and cap.

OPERATING INSTRUCTIONS

Writing

Hold the pen comfortably and apply light pressure to write on paper. The 0.7mm tip provides a smooth writing experience with vibrant gel ink.



Image: A close-up of the Panda-designed pen, indicating its black ink color.

Erasing

To correct mistakes, use the special eraser located at the end of the pen. The thermosensitive ink reacts to the friction-generated heat, becoming invisible.

- 1. Position the Eraser:** Place the eraser tip directly over the ink you wish to remove.
- 2. Apply Gentle Pressure:** Rub the eraser over the ink with gentle, consistent pressure. The ink will disappear without damaging the paper.
- 3. Note:** The eraser does not wear down like traditional rubber erasers and leaves no residue.





Image: A detailed view of the eraser mechanism at the top of the Legami Panda pen.

Ink Reappearance (Special Feature)

The thermosensitive ink is designed to disappear with heat. However, it can reappear if exposed to very cold temperatures (below -10°C or 14°F). This feature can be used for creative purposes, such as "secret messages."

Send a secret message!

3, 2, 1 Let's go!



1. Write a secret message on
a piece of paper.



2. Erase it! with the «eraser»
on the end of the pen



3. Send it to your friend and ask them to
put it in the freezer for a few minutes.



4. The ink will reappear at temperatures
under -10°C and your friend will be
able to read your secret message!

-10°C



Image: An infographic illustrating the process of writing a message, erasing it, and then revealing it by placing the paper in a freezer, demonstrating the thermosensitive ink's property.

MAINTENANCE

- Storage:** Store pens at room temperature, away from direct sunlight or extreme heat, to prevent accidental ink fading.
- Refills:** These pens are designed to be refillable. When the ink runs out, replace the ink cartridge with a compatible LEGAMI thermosensitive gel ink refill.
- Cleaning:** If the pen barrel becomes dirty, wipe it gently with a soft, dry cloth. Do not use harsh chemicals.

★ Erasable pens ★ BE YOURSELF AND MAKE MISTAKES



Image: An infographic highlighting the key features of Legami erasable pens, including refillable thermosensitive ink and an everlasting eraser.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Ink not flowing smoothly.	Pen tip is dry or clogged; low ink level.	Gently scribble on a scrap piece of paper to restart ink flow. If ink is low, replace the refill.
Ink does not erase completely.	Insufficient friction/heat; paper type.	Apply slightly more pressure when erasing. Ensure you are using the correct eraser on the pen. Some paper types may react differently.
Ink reappears after erasing.	Exposure to cold temperatures.	This is a characteristic of thermosensitive ink. Avoid exposing written or erased areas to temperatures below -10°C (14°F).

Problem	Possible Cause	Solution
Pen cap is difficult to remove or replace.	Minor manufacturing variation or debris.	Twist gently while pulling/pushing. Ensure no foreign objects are obstructing the cap.

SPECIFICATIONS

- Brand:** Legami
- Model Number:** 8051128755992
- Item Weight:** Approximately 1.06 ounces (for the set)
- Product Dimensions (per pen):** Approximately 6.1 x 0.39 inches (Length x Diameter)
- Tip Size:** 0.7mm (Medium Point)
- Ink Type:** Thermosensitive Gel Ink
- Ink Colors:** Turquoise (Penguin), Black (Panda, Bee), Blue (Llama, Hippo)
- Material:** Plastic
- Closure Type:** Click-Off Cap
- Number of Items:** 5 pens per set

WARRANTY AND SUPPORT

For information regarding warranty coverage or product support, please refer to the official Legami website or contact their customer service directly. Keep your purchase receipt as proof of purchase.

Manufacturer: Legami

Website: www.legami.com (Please check for regional variations)



© 2024 Legami. All rights reserved.

This manual is for informational purposes only. Product specifications are subject to change without notice.