

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Homedics](#) /

› [Homedics Golden Dew Tabletop Water Fountain WFL-B170 Instruction Manual](#)

Homedics WFL-B170

Homedics Golden Dew Tabletop Water Fountain WFL-B170 Instruction Manual

Model: WFL-B170

INTRODUCTION

The Homedics Golden Dew Tabletop Water Fountain is designed to create a calming and peaceful ambiance in your home or office. Featuring three tiers of gentle water flow, natural river rocks, and subtle lighting, this fountain provides a soothing zen experience. This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting to ensure optimal performance and enjoyment of your fountain.

Homedics®



Image: The Homedics Golden Dew Tabletop Water Fountain, designed to enhance relaxation and wellness.

WHAT'S IN THE BOX

Carefully unpack all components and ensure you have the following items:

- Homedics Relaxation Fountain Base

- Set of Natural River Rocks
- Leaf Tiers (3 pieces)
- Pump Cover
- Water Pump
- Quick-Start Guide

SETUP INSTRUCTIONS

1. **Place the Fountain Base:** Select a flat, level, and water-resistant surface for your fountain. Ensure it is away from direct sunlight or heat sources.
2. **Assemble the Tiers:** Carefully insert the leaf tiers onto the central support structure of the fountain base. Ensure they are securely seated.
3. **Install the Pump:** Place the water pump inside the fountain base. Ensure the pump's power cord is routed through the designated opening in the base to prevent pinching.
4. **Add Water:** Fill the fountain base with approximately 2 cups of distilled water. The water level should be sufficient to completely submerge the pump. Do not overfill.
5. **Arrange River Rocks:** Distribute the natural river rocks onto the tiers and into the base. This helps to minimize splashing and enhance the natural aesthetic.
6. **Connect Power:** Insert 2 AA batteries (not included) into the battery compartment or connect the power adapter to a standard electrical outlet.



Image: Key components of the fountain, including the quiet submersible pump and battery power option.

OPERATING INSTRUCTIONS

To operate your Homedics Golden Dew Tabletop Water Fountain:

1. Ensure the fountain is properly assembled and filled with water.

2. If using batteries, ensure they are correctly inserted. If using the power adapter, plug it into an electrical outlet.
3. Locate the ON/OFF switch on the power cord or battery pack.
4. Flip the switch to the 'ON' position to start the water flow and activate the lights.
5. To turn off the fountain, flip the switch to the 'OFF' position.

The fountain features unique lighting that creates a soft reflection, enhancing the visual appeal of the flowing water.

MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your fountain:

- **Water Level:** Check the water level daily, especially in dry environments, and refill as needed to keep the pump fully submerged. This prevents pump damage and reduces pump noise.
- **Water Quality:** Use distilled water to prevent mineral buildup and keep the fountain clean.
- **Cleaning:** Clean the fountain and pump regularly (e.g., every two weeks) to prevent algae growth and maintain clear water flow. Disconnect power before cleaning.
- **Rock Placement:** Adjust the placement of the river rocks to fine-tune the water sound and minimize splashing.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Fountain not working / No water flow	Low water level; Power not connected; Pump clogged; Batteries drained.	Ensure water level covers pump; Check power connection/batteries; Clean pump impeller; Replace batteries.
Pump is noisy	Low water level; Air in pump; Pump not seated correctly.	Add water to cover pump; Gently shake fountain to release air; Ensure pump is securely placed.
Water splashing excessively	Incorrect rock placement; Water flow too strong.	Adjust river rocks to guide water flow; Check pump for flow adjustment (if available).
Lights not working	Loose connection; LED failure.	Check all electrical connections; Contact customer support if LEDs are faulty.

SPECIFICATIONS

- **Brand:** Homedics
- **Model Number:** WFL-B170
- **Color:** Golden
- **Product Dimensions:** 4.9"L x 4.9"W x 8.66"H
- **Item Weight:** 1.06 pounds
- **Power Source:** Battery Powered (2 AA Batteries required)
- **Special Feature:** Quiet Pump, Unique Lighting, Natural River Rocks

convenient tabletop size



Image: Dimensions of the Homedics Golden Dew Tabletop Water Fountain.

SAFETY INFORMATION

- Always place the fountain on a stable, level, and water-resistant surface.
- Keep the fountain out of reach of children and pets.
- Do not operate the pump without water, as this can cause damage.
- Disconnect the power before performing any maintenance or cleaning.
- If using a power adapter (not included with battery-powered model), ensure it is suitable for the fountain's specifications.
- Avoid placing the fountain near electrical appliances or outlets that are not protected by a Ground Fault Circuit Interrupter (GFCI) if using a 120V AC pump (this model uses low voltage DC).

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided in your Quick-Start Guide or visit the official Homedics website. Keep your purchase receipt as proof of purchase for any warranty

claims.