



[Manuals.plus](#) /

› [EVER ADVANCED](#) /

› EVER ADVANCED Collapsible Push & Pull Shopping Cart Instruction Manual

## EVER ADVANCED EA-TR-21830

# EVER ADVANCED Collapsible Push & Pull Shopping Cart Instruction Manual

Model: EA-TR-21830

## INTRODUCTION

---

This manual provides essential instructions for the safe and efficient use of your EVER ADVANCED Collapsible Push & Pull Shopping Cart. Please read this manual thoroughly before assembly and operation. Keep it for future reference.

## PRODUCT OVERVIEW

---

The EVER ADVANCED Collapsible Push & Pull Shopping Cart is designed for versatile transport of items, featuring both push and pull handle options, a practical integrated shopping basket, and all-terrain wheels with brakes. Its foldable design allows for compact storage and easy portability.



Figure 1: The EVER ADVANCED cart demonstrating both push and pull functionality.

## SETUP INSTRUCTIONS

Your EVER ADVANCED shopping cart requires minimal assembly, primarily involving the attachment of the wheels and unfolding the main frame.

1. **Unfolding the Cart:** Place the folded cart on a flat surface. Gently pull the sides apart until the frame fully extends and locks into place. Ensure all frame joints are securely engaged.
2. **Attaching the Wheels:** The wheels are designed for quick, tool-free attachment. Align each wheel's mounting shaft with its corresponding bracket on the cart frame. Push firmly until you hear a "click," indicating the wheel is securely locked. Verify all four wheels are properly attached before use.
3. **Setting up the Shopping Basket:** Position the integrated shopping basket onto the designated upper frame. Ensure it is stable and securely attached.



Figure 2: Detail of the all-terrain wheel with lock/unlock mechanism.

Video 1: Demonstrates the unfolding process and initial setup of the cart, including loading items.

## OPERATING INSTRUCTIONS

The EVER ADVANCED cart offers flexible handling and ample storage for various uses.

### Push and Pull Functionality

- **Push Handle:** The cart features a dedicated push handle for comfortable operation, similar to a traditional shopping cart. Adjust the telescopic handle to your preferred height and angle for optimal control.
- **Pull Handle:** For pulling, extend the telescopic pull handle. Ensure it is locked in position before use.

### Storage Features

- **Integrated Shopping Basket:** Use the upper basket (18"L x 9"W x 8"H) for smaller, frequently accessed items like phones, wallets, or groceries.
- **Main Compartment:** The large main compartment is suitable for bulkier items.
- **Cup Holders and Side Pockets:** Utilize the three dedicated cup holders and multiple side organizer pockets for beverages and smaller accessories.

# PRACTICAL SHOPPING BASKET

Better mall & supermarket shopping experience



Figure 3: The cart featuring its practical integrated shopping basket.



Figure 4: Close-up of the cart's cup holders and large side pocket.

## Wheel and Brake System

- The front wheels rotate 360° for easy maneuverability.
- Engage the dual-brake safety system on the wheels when parking the cart to prevent unintended movement. Push the red lever down to lock and up to unlock.

Video 2: Illustrates the push and pull functionality of the wagon, along with the wheel and brake features.

## MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your cart.

- **Cleaning:** Wipe down the fabric and frame with a damp cloth and mild soap. Avoid harsh chemicals. Allow to air dry completely before folding or storing.
- **Wheel Inspection:** Periodically check the wheels for debris (e.g., dirt, hair, small stones) that may hinder smooth rotation. Clean as necessary. Ensure wheels remain securely attached.
- **Storage:** When not in use, fold the cart for compact storage. Store in a dry place away from direct sunlight to prevent material degradation.

## TROUBLESHOOTING

---

If you encounter issues with your cart, refer to the following common problems and solutions:

| Problem                                   | Possible Cause   | Solution   |
|---|--|--|
| Wheels get stuck or cart trails sideways. | Debris in wheels; wheels not fully attached.               | Clean any debris from the wheels. Ensure each wheel's mounting shaft is pushed completely into its bracket until it "clicks" into place. |
| Brakes do not engage effectively.         | Brake lever not fully depressed; mechanism obstructed.     | Ensure the red brake lever is fully pushed down. Check for any obstructions around the brake mechanism.                                  |
| Difficulty pushing or pulling the cart.   | Handle not adjusted correctly; uneven weight distribution. | Adjust the telescopic handle to a comfortable height and angle. Distribute the load evenly within the cart to maintain balance.          |
| Cart is bulky when folded.                | Wheels not detached (if applicable).                       | For the most compact storage, detach the wheels by pressing the release button and pulling them off.                                     |

## SPECIFICATIONS

---

- **Model Number:** EA-TR-21830
- **Brand:** EVER ADVANCED
- **Product Dimensions (Unfolded):** 33"D x 18"W x 12.2"H
- **Folded Dimensions:** Approximately 29.5"L x 22.4"W x 7.5"H (with wheels detached)
- **Weight:** 26.4 lbs
- **Capacity:** Up to 260 lbs
- **Color:** Blue
- **Frame Material:** Aluminum
- **Handle Material:** Aluminum
- **Number of Wheels:** 4
- **Caster Type:** Swivel (front wheels)
- **Special Feature:** Sturdy, Collapsible, Push & Pull Design, Integrated Shopping Basket, Cup Holders, Side Pockets, All-Terrain Wheels with Brakes
- **Required Assembly:** Yes (minimal)
- **Recommended Uses:** Outdoor, Camping, Beach, Groceries, Utility

# DIMENSION



WEIGHT **26.4 lbs**



CAPACITY **260 lbs**

Figure 5: Detailed dimensions, weight, and capacity of the cart.

## WARRANTY AND SUPPORT

Specific warranty details are not provided in this manual. For warranty information, product support, or to inquire about replacement parts, please contact EVER ADVANCED customer service directly or visit their official website. Keep your purchase receipt as proof of purchase.