

[Manuals.plus](#) /

> [VINGLI](#) /

> VINGLI Fireplace TV Stand User Manual

VINGLI DS0BSJM-1

VINGLI Fireplace TV Stand

USER MANUAL

Model: DS0BSJM-1

INTRODUCTION

Thank you for choosing the VINGLI Fireplace TV Stand. This versatile entertainment center is designed to accommodate TVs up to 60 inches, offering a stylish mirrored glass door design, ample storage with adjustable shelves, and an integrated 18-inch electric fireplace. This manual provides essential information for safe assembly, operation, and maintenance of your new TV stand.



Image: The VINGLI Fireplace TV Stand, a white entertainment center with mirrored glass doors and a central electric fireplace, supporting

SAFETY INFORMATION

Please read all safety warnings and instructions carefully before assembly and use to prevent injury or damage.

- **Caution:** Keep children and pets away from the electric fireplace to prevent burns.
- Secure the entertainment center to the wall using appropriate anti-tip hardware (not included) to prevent tip-over, especially in households with children.
- Be cautious of small parts and sharp edges during assembly. Keep all hardware out of reach of children.
- Ensure the electric fireplace is plugged into a grounded outlet and avoid overloading circuits.
- Do not block the air vents of the electric fireplace to prevent overheating.

PACKAGE CONTENTS

Your VINGLI Fireplace TV Stand will be delivered in two separate packages. These packages may arrive on different days. Please ensure you have received both packages before beginning assembly.



Image: An illustration depicting the delivery process of the TV stand and fireplace in two separate packages.

Carefully unpack all components and check against the included parts list in your assembly instructions to ensure nothing is missing or damaged. If any parts are missing or damaged, please contact customer support immediately.


ASSEMBLY INSTRUCTIONS

Setting up your new entertainment center is designed to be a straightforward process. Detailed assembly instructions with diagrams are included in your package. Please follow these instructions step-by-step.

- **Preparation:** Clear a spacious area for assembly. It is recommended to assemble the unit on a soft, clean surface to prevent scratches.
- **Tools:** Basic household tools (e.g., screwdriver, hammer) may be required. Refer to the assembly manual for specific tool requirements.

- **Component Identification:** Familiarize yourself with all parts and hardware before starting.
- **Team Assembly:** For best results and safety, assembly by two people is recommended.

18 INCH Fireplace With Remote Control



The item will be delivered in **2** packages, and each may arrive at a different time.

(burn with or without heater)



Authentic
flame effect



0.5-6
Hours Timer



62°F-82°F



Seven Mesmerizing
Flame Colors



Overheating
protection



CSA Listed

Image: Detailed views highlighting the elegant mirrored glass doors, adjustable wood shelves, ample storage space, and integrated cable management system.

SETUP

Once assembled, position your TV stand in its desired location, ensuring it is on a stable, level surface.

- **TV Placement:** This stand is designed to support TVs up to 60 inches. Ensure the TV's base fits securely on the top surface. The maximum load-bearing capacity is 420 lbs.
- **Adjustable Shelves:** The interior shelves behind the mirrored glass doors are adjustable. You can customize their height to accommodate various media devices, books, or decorative items.
- **Cable Management:** Utilize the integrated cable management cutouts at the back of the unit to neatly route and organize power cords and media cables, keeping your setup tidy and safe.



Image: A visual representation of the TV stand's dimensions (47.24"W x 15.75"D x 31.77"H) and its compatibility with various TV sizes up to 60 inches.

OPERATING THE ELECTRIC FIREPLACE

The integrated 18-inch electric fireplace provides both warmth and ambiance. It can be operated with or without the heater function.

- **Power:** Plug the fireplace into a standard electrical outlet. Use the power button on the unit or the remote control to turn it on/off.
- **Temperature Control:** The heater offers a temperature range of 62°F to 82°F. Adjust the temperature using the controls on the unit or the remote to achieve your desired comfort level.
- **Timer Function:** Set the automatic shut-off timer for 0.5 to 6 hours for convenience and energy saving.
- **Flame Colors:** Enjoy seven mesmerizing flame color options to match your mood or decor. Cycle through the colors using the dedicated button on the unit or remote.
- **Safety Features:** The fireplace is equipped with overheating protection and is CSA certified, ensuring safe and reliable operation.

Meticulously Crafted Details



Elegant Mirrored Glass



Adjustable Wood Shelves



Ample Storage Space



Cable Management

Image: The 18-inch electric fireplace unit, its remote control, and icons representing features like authentic flame effect, 0.5-6 hours timer, 62-82°F temperature range, seven flame colors, overheating protection, and CSA listing.

MAINTENANCE AND CARE

Regular maintenance will help preserve the appearance and functionality of your VINGLI Fireplace TV Stand.

- **Cleaning the Stand:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that could damage the finish or mirrored glass.
- **Cleaning Mirrored Glass:** Use a glass cleaner specifically designed for mirrors and a lint-free cloth to avoid streaks.
- **Fireplace Maintenance:** Ensure the air intake and exhaust vents of the electric fireplace are kept clear of dust and debris to maintain proper airflow and prevent overheating. Periodically wipe the exterior of the fireplace unit.
- **Electrical Safety:** Regularly inspect the power cord for any signs of damage. If damaged, discontinue use and contact customer support.

TROUBLESHOOTING

If you encounter any issues with your VINGLI Fireplace TV Stand, please refer to the following common troubleshooting tips:

- **Fireplace Not Turning On:**
 - Check if the power cord is securely plugged into a working electrical outlet.
 - Ensure the main power switch on the fireplace unit is in the 'ON' position.
 - Verify that the remote control batteries are not depleted.
- **No Heat Output:**
 - Confirm the heater function is activated on the unit or remote.
 - Check if the temperature setting is higher than the ambient room temperature.
 - Ensure vents are not blocked. The overheating protection may have activated; unplug the unit, wait 10-15 minutes, and plug it back in.
- **Unstable Stand:**
 - Verify that all assembly hardware is tightened securely.
 - Ensure the stand is placed on a flat, level surface.
 - Consider using shims if the floor is uneven.

For issues not covered here or if problems persist, please contact VINGLI customer support.

PRODUCT SPECIFICATIONS

Feature	Detail
Brand	VINGLI
Model Number	DS0BSJM-1
Product Dimensions (L x W x H)	47.24 x 15.75 x 31.77 inches
Item Weight	88.9 pounds
Material	Engineered Wood
Color	White
TV Size Compatibility	Up to 60 inches
Electric Fireplace Size	18 inches
Fireplace Temperature Range	62°F to 82°F
Fireplace Timer	0.5 - 6 hours
Flame Colors	7 mesmerizing colors
Certifications	CSA Listed (for fireplace)

WARRANTY AND CUSTOMER SUPPORT

VINGLI is committed to providing high-quality products and excellent customer service.

- **1-Year Quality Service:** Your VINGLI Fireplace TV Stand is backed by a 1-year quality service guarantee.
- **24/7 Professional Customer Support:** VINGLI provides outstanding customer support to assist you with any questions, concerns, or issues you may encounter.

For assistance, please refer to the contact information provided in your product packaging or visit the official VINGLI store on Amazon: [VINGLI Store](#).



Image: The VINGLI brand promise, highlighting 1-year quality service and 24/7 professional customer support.

© 2024 VINGLI. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DPMVFPKN>

More documents and user manuals: <https://manuals.plus/>