Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Portronics Luxcell Bind Mini 20k

Portronics Luxcell Bind Mini 20k 20000mAh Powerbank User Manual

Model: Luxcell Bind Mini 20k (POR-2662)

1. Introduction

Welcome to the user manual for your Portronics Luxcell Bind Mini 20k 20000mAh Powerbank. This device is designed to provide portable and efficient charging for your electronic devices. Please read this manual carefully to ensure proper use and to maximize the lifespan of your power bank.

Key Features:

- **22.5W Fast Charging:** Delivers rapid power to compatible devices.
- **20000mAh Capacity:** High-capacity battery for multiple charges.
- **Built-in Cables:** Includes integrated Type-C PD (Input & Output) and 8-Pin cables for convenience.
- **LED Battery Display:** Clear digital display shows remaining power.
- **Triple Output:** Charge up to three devices simultaneously via USB-A, Type-C, and 8-Pin outputs.
- **Universal Compatibility:** Supports Android smartphones, iPhones, tablets, earbuds, and other devices.
- **BIS Certified:** Equipped with advanced chip protection against short circuits, over-temperature, and over-voltage.



The Portronics Luxcell Bind Mini 20k Powerbank, showcasing its 20000mAh capacity and digital LED display indicating 100% charge.

2. Package Contents

Please check the box for the following items:

- Portronics Luxcell Bind Mini 20k Powerbank (1N)
- Documentation (User Manual) (1N)
- Charging Cable (USB to Type-C) (1N)

3. Product Overview

The Luxcell Bind Mini 20k features a compact design with essential indicators and ports for efficient power management.

- **LED Display:** Shows the current battery percentage of the power bank.

- **Wake Button:** Activates the LED display and initiates charging if not automatic.
- **Built-in Type-C Cable:** For charging Type-C devices and recharging the power bank.
- **Built-in 8-Pin Cable:** For charging 8-Pin compatible devices.
- **USB-A Output Port:** For charging devices using your own USB-A cable.



A detailed view of the power bank's LED display, indicating battery percentage, and the conveniently located wake button.

4. Setup

4.1. Charging the Power Bank

1. Locate the Type-C input port on your power bank. This port also functions as an output.
2. Use the included USB to Type-C cable or the built-in Type-C cable to connect the power bank to a compatible USB wall adapter (not included) or a computer's USB port.
3. The LED display will show the charging progress, indicating the battery percentage as it charges.

4. Once the display shows 100%, the power bank is fully charged and ready for use.



The Luxcell Bind Mini 20k eliminates the need for carrying multiple charging cables, offering convenience with its integrated Type-C and 8-Pin cables.

5. Operating Instructions

5.1. Charging Your Devices

The Portronics Luxcell Bind Mini 20k offers multiple ways to charge your devices:

- **Using Built-in Type-C Cable:** Pull out the integrated Type-C cable and connect it directly to your Type-C compatible device.
- **Using Built-in 8-Pin Cable:** Pull out the integrated 8-Pin cable and connect it directly to your 8-Pin compatible device.
- **Using USB-A Output Port:** Connect your device's charging cable (USB-A to your device's connector) to the USB-A output port on the power bank.

Charging will typically begin automatically. If not, press the wake button to initiate charging.

5.2. Simultaneous Charging

You can charge up to three devices at once using a combination of the built-in cables and the USB-A output port. The 22.5W fast charging capability ensures efficient power delivery across all connected devices.



The power bank simultaneously charging three devices: a smartphone via the built-in Type-C cable, another smartphone via the built-in 8-Pin cable, and earbuds via the USB-A port.

5.3. LED Battery Display

The transparent plastic casing features an LED display that shows the power bank's remaining battery percentage. This allows you to monitor the charge level of both the power bank and your connected devices.



The power bank's universal compatibility allows it to charge a wide range of devices, including Android smartphones, iPhones, tablets, iPads, earphones, and smartwatches.

6. Safety Information

Your Portronics Luxcell Bind Mini 20k Powerbank is BIS certified and incorporates advanced chip protection layers to ensure the safety of your devices and the power bank itself. These protections include:

- **Short Circuit Protection:** Prevents damage from electrical shorts.
- **Over-Voltage Protection:** Safeguards against excessive voltage input/output.
- **Over-Current Protection:** Protects against excessive current flow.
- **Over-Temperature Protection:** Monitors and regulates internal temperature to prevent overheating.

General Safety Guidelines:

- Do not expose the power bank to extreme temperatures (hot or cold).

- Avoid dropping or subjecting the power bank to strong impacts.
- Do not disassemble or attempt to repair the power bank yourself.
- Keep away from water and high humidity.
- Store in a cool, dry place when not in use.



The power bank is designed with multiple safety protections, including safeguards against short circuits, over-voltage, and over-current, ensuring reliable and secure charging.

7. Maintenance

To ensure optimal performance and longevity of your power bank, follow these maintenance tips:

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the power bank. Avoid using harsh chemicals or abrasive materials.
- **Storage:** Store the power bank in a cool, dry environment, away from direct sunlight and extreme temperatures. If storing for extended periods, ensure it has at least a 50% charge.

- **Charging Cycles:** For best battery health, avoid completely draining the power bank frequently. Recharge it when the battery level is low.
- **Cable Care:** Handle the built-in cables gently. Avoid excessive bending or pulling to prevent damage.

8. Troubleshooting

If you encounter any issues with your Portronics Luxcell Bind Mini 20k Powerbank, please refer to the following common problems and solutions:

- **Power bank not charging:**
  - Ensure the charging cable is securely connected to both the power bank's Type-C input and the power source.
  - Try a different USB wall adapter or USB port.
  - Verify the power source is active.
- **Device not charging from power bank:**
  - Press the wake button on the power bank to activate it.
  - Ensure the built-in cables or your external cable are securely connected to both the power bank and your device.
  - Check if your device's charging port is clean and free of debris.
  - Verify the power bank has sufficient charge.
  - Try a different cable or output port on the power bank.
- **Slow charging:**
  - Ensure you are using a fast-charging compatible wall adapter for recharging the power bank.
  - For device charging, ensure your device supports 22.5W fast charging and that the cable used is capable of fast charging.
  - Charging multiple devices simultaneously may distribute the power, potentially slowing down individual device charging.
- **LED display not working:**
  - Press the wake button to activate the display.
  - If the power bank is completely drained, the display may not light up until it receives some charge.

If these steps do not resolve the issue, please contact customer support.

9. Specifications

Model Name	Luxcell Bind Mini 20k
Model Number	POR-2662
Battery Capacity	20000 mAh
Rapid Charging Performance	22.5W
Connector Type	USB Type C (Input & Output)
Output Ports	USB-A, Built-in Type-C, Built-in 8-Pin

Special Features	22.5W Fast Charging, In-Built Cables (8Pin + Type C), LED Display, Mach USB-A Output, Type C Port Input
Battery Cell Type	Lithium Polymer
Item Dimensions (L x W x Thickness)	16.3L x 8.6W x 2.1Th Centimeters
Item Weight	450 Grams
Compatible Devices	Smartphone, Tablet
Country of Origin	India

10. Warranty Information

The Portronics Luxcell Bind Mini 20k Powerbank comes with a**1-Year Warranty** from the date of purchase. This warranty covers manufacturing defects and issues arising from normal use.
Optional Protection Plans:

- **Onsitego 1 Year Extended Warranty:** Extends coverage for an additional 12 months.
- **1 Year Damage Protection by Onsitego:** Provides coverage against accidental damage for 12 months.
- **Onsitego 2 Year Extended Warranty:** Extends coverage for an additional 24 months.

For detailed terms and conditions regarding warranty claims or protection plans, please refer to the documentation included with your product or contact Portronics customer support.

11. Customer Support

For any assistance, queries, or support regarding your Portronics Luxcell Bind Mini 20k Powerbank, please use the following contact information:

- **Email:** help@portronics.com
- **Phone/WhatsApp:** +91 9555-245-245 (10 am - 6 pm)
- **Online Support:** https://support.portronics.com
- **Manufacturer/Importer:** Portronics Digital Pvt ltd, First Floor Property No D 8 Upper Basement Sector 8 Noida Uttar Pradesh 201301



The Portronics Luxcell Bind Mini 20k Powerbank is lightweight and flight-approved, making it an ideal travel companion.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DPMY43Y7

More documents and user manuals: **https://manuals.plus/**