

[Manuals.plus](#) /

› [Acupress](#) /

› Acupress Shaver Foil and Cutter Replacement Head User Manual

## Acupress 10B 20B 20S Shaver Foil + Cutter Replacement Head

# Acupress Shaver Foil and Cutter Replacement Head User Manual

Model: 10B 20B 20S Shaver Foil + Cutter Replacement Head

## 1. INTRODUCTION

---

This manual provides essential information for the installation, maintenance, and optimal use of your Acupress Shaver Foil and Cutter Replacement Head. This replacement part is designed to restore the cutting performance of your electric shaver, ensuring a close and comfortable shave.



Figure 1: Acupress Shaver Foil and Cutter Replacement Head components and packaging.

## 2. COMPATIBILITY

---

This replacement foil and cutter set is compatible with a wide range of electric shavers. Please verify your shaver model against the list below to ensure proper fit:

- Br-aun 10B, 20B, 20S
- Br-aun 1000 Series: 170, 180, 190, 1735, 1775
- Br-aun 2000 Series: 2615, 2675, 2775, 2776, 2778, 2838, 2864, 2865, 2866, 2874, 2876, 2878
- Br-aun CruZer Series: CruZer1, CruZer2, CruZer3, CruZer4
- Br-aun Z Series: Z20, Z30, Z40, Z50, Z60



### Fit for Braun 10B 20B Series

Figure 2: The replacement head is designed for a precise fit with compatible shaver models.

## 3. INSTALLATION INSTRUCTIONS

---

Replacing your shaver's foil and cutter block is a straightforward process. Follow these steps carefully to ensure correct installation and optimal performance.

1. **Preparation:** Ensure your electric shaver is turned off and unplugged from any power source.
2. **Remove Old Parts:** Gently press the release buttons (if present) or pull the old foil head upwards to detach it from the shaver body. The cutter block will typically come out with the foil head or can be easily removed from its housing.
3. **Clean Shaver:** Before installing the new parts, thoroughly clean any hair clippings or debris from the shaver's head area. This ensures a clean contact and prevents future blockages.
4. **Install New Cutter:** Carefully place the new cutter block into its designated slot on the shaver body. Ensure it is seated correctly and securely.
5. **Install New Foil Head:** Align the new foil head with the shaver body and press it down until it clicks into place.

Ensure it is firmly attached and does not wobble.

6. **Test:** Turn on your shaver briefly to confirm the new foil and cutter are functioning smoothly.



## Replacement steps



Figure 3: Visual guide for the replacement steps of the shaver foil and cutter.

## 4. USAGE GUIDELINES

---

With your new replacement head installed, your shaver is ready for optimal performance. For best results, ensure your skin is clean and dry before shaving. Hold the shaver at a right angle to your skin and move it against the direction of hair growth. Apply gentle pressure; excessive force is not necessary and can cause irritation or damage to the foil.



Figure 4: Demonstrating the use of the shaver with the new replacement head.

## 5. MAINTENANCE

---

Regular maintenance of your shaver head is crucial for maintaining hygiene and ensuring consistent shaving performance. Over time, hair and skin particles can accumulate, reducing efficiency.

### 5.1 Cleaning

After each shave, it is recommended to clean the foil and cutter block. Most compatible shavers allow for rinsing the head under running water. Ensure the shaver is turned off before cleaning. For a more thorough clean, you can detach the foil head and brush away any trapped hairs. Allow the parts to air dry completely before reassembling.



Waterproof



Figure 5: The replacement head is designed to be waterproof for easy rinsing and cleaning.

## 5.2 Replacement Frequency

The cutting parts of your shaver gradually wear out with use. It is recommended to replace the shaver's foil and cutter block every 18 months to maintain maximum performance and a comfortable shave. This ensures that your shaver continues to cut effectively and efficiently.



To maintain optimal shaving performance, recommend that you should clean the shaving parts regularly with cleaning agents and replace the foil & cutter block every 18 months.



Figure 6: Recommendation for regular cleaning and replacement to maintain optimal shaving performance.

## 6. TROUBLESHOOTING

---

If you experience issues after replacing your shaver head, consider the following common problems and solutions:

- **Reduced Shaving Performance:**

- Ensure the foil head and cutter block are correctly installed and securely clicked into place.
- Check for any trapped hairs or debris that might be impeding the blades. Clean thoroughly.
- If the replacement head is old, it might be time for another replacement.

- **Irritation or Redness:**

- Ensure you are not applying excessive pressure during shaving.
- Shave on clean, dry skin.
- If irritation persists, consult your shaver's original manual for skin sensitivity guidelines.

- **Difficulty Installing:**

- Refer to the installation instructions (Section 3) and the diagram. Ensure correct alignment.
- Do not force the parts; they should click into place with moderate pressure.

## 7. PRODUCT SPECIFICATIONS

---

Attribute	Detail
Product Type	Shaver Foil and Cutter Replacement Head
Material	ABS (as per product description)
Compatibility	Br-aun 10B, 20B, 20S, 1000 Series, 2000 Series, CruZer Series, Z Series
Recommended Replacement	Every 18 months
Package Includes	1 Set of Shaver Foil Screen Set (1 Foil Head, 1 Cutter Block)
Manufacturer	Acupress
Country of Origin	China





Figure 7: Detailed views of the replacement foil head and cutter block.

## 8. CUSTOMER SUPPORT

---

Acupress is committed to providing a satisfactory shopping experience. If you have any questions, concerns, or require assistance with your product, please do not hesitate to contact our customer support team. We are here to help.

For support inquiries, please refer to the contact information provided with your purchase or visit the official Acupress brand store online.