

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Maxell](#) /

› [Maxell USB Flash Memory, 64GB USB 3.2 \(Gen1\) User Manual](#)

Maxell MXUB-A64GB

Maxell USB Flash Memory User Manual

Model: MXUB-A64GB

PRODUCT OVERVIEW

The Maxell USB Flash Memory is a portable storage device designed for convenient data transfer and storage. Featuring a 64GB capacity and USB 3.2 (Gen1) connectivity, it offers fast and reliable performance for your files.



Image: Front view of the Maxell 64GB USB Flash Memory drive, showing its black casing and the silver USB connector extended.

This flash drive features a slide-type mechanism, eliminating the need for a cap and protecting the USB connector when not in use. Its compact design makes it easy to carry.

スライド式

キヤップレスでコンパクト



Image: The Maxell USB Flash Memory with an arrow illustrating the slide mechanism for extending and retracting the USB connector.

コンパクトサイズ



Image: A hand holding the Maxell USB Flash Memory, highlighting its small and portable form factor.

SETUP

The Maxell USB Flash Memory is designed for plug-and-play operation, requiring no special driver installation for most modern operating systems.

- Extend the USB Connector:** Gently slide the mechanism on the flash drive to expose the USB Type-A connector.
- Insert into USB Port:** Plug the USB connector firmly into an available USB port on your computer or compatible device. Ensure the connector is oriented correctly.
- Device Recognition:** Your operating system should automatically detect the flash drive and make it accessible as a removable storage device. A notification may appear indicating that the device is ready for use.

OPERATING INSTRUCTIONS

Once the USB flash drive is recognized by your system, you can begin transferring and managing files.

Transferring Files

- **Access the Drive:** Open "This PC" (Windows) or "Finder" (macOS) and locate the newly mounted drive, typically labeled as "Removable Disk" or "Maxell USB".
- **Copy Files:** Drag and drop files or folders from your computer to the flash drive's window, or right-click on files/folders and select "Send to" > "Maxell USB" (Windows).
- **Paste Files:** Alternatively, copy files from your computer, then open the flash drive's window and paste them.
- **Copy from Drive:** To transfer files from the flash drive to your computer, reverse the process: drag and drop from the flash drive to a folder on your computer.



Image: The Maxell USB Flash Memory inserted into the USB port of a laptop, demonstrating typical usage.

Safely Removing the Drive

It is crucial to safely eject the flash drive before physically removing it to prevent data corruption.

- **Windows:** Click the "Safely Remove Hardware and Eject Media" icon in the system tray (bottom-right corner), then select the Maxell USB drive. Wait for the "Safe to Remove Hardware" message.
- **macOS:** Drag the flash drive icon from your desktop or Finder sidebar to the Trash icon, or right-click the drive icon

and select "Eject".

- **Physical Removal:** Once the "Safe to Remove" message appears or the drive icon disappears, you can safely unplug the flash drive from the USB port. Retract the USB connector by sliding the mechanism.

MAINTENANCE

Proper care of your Maxell USB Flash Memory will ensure its longevity and reliable performance.

- **Physical Protection:** Keep the flash drive in a clean, dry environment. Avoid exposing it to extreme temperatures, direct sunlight, or moisture. The slide mechanism helps protect the connector from dust and damage.
- **Avoid Drops and Impacts:** While durable, severe physical shocks can damage the internal components.
- **Cleanliness:** If necessary, gently wipe the exterior with a soft, dry, lint-free cloth. Do not use liquid cleaners or solvents.
- **Data Backup:** Regularly back up important data stored on the flash drive to another storage medium (e.g., computer hard drive, cloud storage) to prevent data loss in case of unforeseen issues.

TROUBLESHOOTING

If you encounter issues with your Maxell USB Flash Memory, try the following common troubleshooting steps:

- **Drive Not Recognized:**
 - Try plugging the drive into a different USB port on your computer.
 - Test the drive on another computer to determine if the issue is with the drive or your computer's USB ports.
 - Restart your computer.
 - Check Device Manager (Windows) or System Information (macOS) to see if the drive is listed, even if it doesn't appear in "This PC" or "Finder".
- **Slow Transfer Speeds:**
 - Ensure you are using a USB 3.0 or USB 3.2 compatible port on your computer for optimal speeds. Connecting to a USB 2.0 port will result in slower transfer rates.
 - Avoid running multiple demanding applications during large file transfers.
 - Check if the drive is nearly full, as this can sometimes affect performance.
- **Cannot Write/Delete Files:**
 - Check if the drive is full.
 - Ensure the files are not read-only.
 - The drive might be formatted with a file system (e.g., NTFS) that macOS can read but not write to without third-party software. Consider reformatting to exFAT if cross-platform compatibility is needed (note: reformatting will erase all data).

If these steps do not resolve your issue, please refer to the support information section.

SPECIFICATIONS

Feature	Detail
Brand	Maxell
Model Number	MXUB-A64GB

Feature	Detail
Memory Storage Capacity	64 GB
Connectivity Technology	USB
Hardware Connectivity Technology	USB Type A
USB Standard	USB 3.2 (Gen1)
Write Speed	60 MB/s
Item Weight	0.704 ounces
Package Dimensions	3.74 x 3.74 x 0.39 inches

WARRANTY AND SUPPORT

Specific warranty information for the Maxell USB Flash Memory (Model: MXUB-A64GB) is not provided in this manual. Please refer to the product packaging or the official Maxell website for detailed warranty terms and conditions.

For technical support or further assistance, please visit the official Maxell support page or contact their customer service department. Contact information can typically be found on the Maxell website or product packaging.

You can visit the Maxell Store on Amazon for more information:[Maxell Store](#)

© 2024 Maxell. All rights reserved.

Related Documents - MXUB-A64GB

	<p>Maxell Smart LED Bulb LEDA19E26 User Manual</p> <p>Comprehensive user manual for the Maxell Smart LED Bulb (LEDA19E26), detailing features like Wi-Fi connectivity, voice control, dimming, multicolor options, app setup, device pairing, and various control modes including white, color, scene, timer, schedule, grouping, and music sync.</p>
	<p>Maxell DISTRIKT Wireless Speaker User Manual and Specifications</p> <p>User manual for the Maxell DISTRIKT Wireless Speaker, detailing its features, operation, specifications, package contents, and TWS functionality. Includes instructions for Bluetooth pairing, music control, and call handling.</p>

 <p>maxell SMART LED BULB Dimmable & Multicolor</p> <p>Model: LEDBR30E26</p> <p>2015 MARSH 001 MAXELL USA INC. 2015 MARSH 001 MAXELL USA INC.</p>	<p><u>Maxell LEDBR30E26 Smart LED Bulb: User Manual & Features</u></p> <p>Discover the Maxell LEDBR30E26 Smart LED Bulb. This guide covers Wi-Fi connectivity, voice control, dimming, multicolor options, app setup, and various control modes for smart home lighting.</p>
 <p>maxell  Dual Driver TWS Model: TWDD-BK</p> <p>TWDD-BK FCC ID: 2ABHJ-A0000</p>	<p><u>Maxell Dual Driver TWS Wireless Earbuds User Manual</u></p> <p>User manual for the Maxell Dual Driver TWS wireless earbuds (Model: TWDD-BK), detailing specifications, charging, pairing, controls, warranty, and FCC compliance information.</p>
 <p>maxell 2WAY WALKIE TALKIE RADIO</p> <p>Model: RAD-2</p> <p>2015 MARSH 001 MAXELL USA INC. 2015 MARSH 001 MAXELL USA INC.</p>	<p><u>Maxell 2WAY Walkie Talkie Radio RAD-2 User Manual</u></p> <p>User manual for the Maxell 2WAY Walkie Talkie Radio (Model RAD-2). Learn about setup, operation, features like channel selection, volume control, and battery management for effective communication.</p>
 <p>maxell MXH-BTGD50</p> <p>2015 MARSH 001 MAXELL USA INC. 2015 MARSH 001 MAXELL USA INC.</p>	<p><u>Maxell MXH-BTGD50 Bluetooth Wireless Earphones User Manual</u></p> <p>User manual for the Maxell MXH-BTGD50 Bluetooth wireless earphones, covering setup, usage, safety precautions, troubleshooting, and specifications.</p>