

[Manuals.plus](#) /

› [COLAMY](#) /

› COLAMY Upholstered Dining Chairs (Model 3008B) Instruction Manual

COLAMY 3008B

COLAMY Upholstered Dining Chairs (Model 3008B) Instruction Manual

1. PRODUCT OVERVIEW

The COLAMY Upholstered Dining Chairs (Model 3008B) are designed for dining rooms, kitchens, and various other settings. These chairs feature a modern aesthetic with a padded seat, curved backrest, and sturdy wood legs, offering both comfort and durability. This manual provides essential information for assembly, use, and maintenance.



Image 1.1: Overview of the COLAMY Upholstered Dining Chairs in Green.

2. IMPORTANT SAFETY INFORMATION

- Assembly may require tools and careful handling.
- Do not exceed the maximum weight recommendation of **300 pounds per chair**.
- Ensure all screws and bolts are securely tightened before use. Periodically check and re-tighten as necessary.
- Keep small parts away from children during assembly to prevent choking hazards.
- Avoid standing on the chair or using it as a step stool.

3. PACKAGE CONTENTS

Each set includes the following components:

- 6 x Upholstered Chair Seats

- 24 x Chair Legs (4 per chair)
- Assembly Hardware (screws, washers, Allen wrench)
- Instruction Manual

4. ASSEMBLY INSTRUCTIONS

Follow these steps to assemble your COLAMY Dining Chairs. It is recommended to assemble the chairs on a soft, clean surface to prevent scratches.

4.1. Visual Assembly Guide



Video 4.1: Official assembly guide for COLAMY Upholstered Dining Chairs. This video demonstrates the process of attaching the chair legs to the seat base.

4.2. Step-by-Step Assembly

1. **Unpack Components:** Carefully remove all chair components and hardware from the packaging. Verify that all parts listed in Section 3 are present.
2. **Identify Legs:** The chair legs are typically marked (e.g., B/C) to distinguish between front and rear legs. Front legs may have adjustable nails on the bottom.
3. **Attach Front Legs:** Invert the chair seat. Rotate the two front legs into the pre-drilled screw holes on the bottom of the chair seat. Ensure they are securely tightened.
4. **Attach Rear Legs:** Similarly, rotate the two rear legs into the remaining pre-drilled screw holes on the bottom of the chair seat. Tighten them firmly.
5. **Final Check:** Once all legs are attached, gently place the chair upright. Check for stability and ensure all legs are even. Adjust the footpads on the front legs if necessary to prevent wobbling.

5. OPERATING INSTRUCTIONS

The COLAMY Upholstered Dining Chairs are designed for comfortable seating. To use:

- Position the chair at your dining table or desired location.
- Ensure the chair is on a flat, stable surface before sitting.
- Sit gently, distributing your weight evenly on the seat.
- Avoid sudden movements or excessive force when sitting or getting up.

6. MAINTENANCE AND CARE

Proper care will extend the life and appearance of your dining chairs.

- **Cleaning:** Spot clean the upholstered areas with a damp cloth and mild soap. Wipe clean the wooden legs with a dry or slightly damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Spills:** Blot spills immediately with a clean, dry cloth. Do not rub, as this can spread the stain.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight to prevent fading of the upholstery.
- **Regular Inspection:** Periodically check all connections and tighten any loose screws or bolts to maintain stability.

7. TROUBLESHOOTING

If you encounter any issues with your chairs, refer to the following common solutions:

Problem	Possible Cause	Solution
Chair wobbles	Uneven legs or loose connections.	Ensure all legs are fully tightened. Adjust the footpads on the front legs to level the chair.
Squeaking sound	Loose joints or friction between parts.	Tighten all assembly hardware. If the issue persists, disassemble and reassemble, ensuring all parts are correctly aligned.
Upholstery damage	Sharp objects, excessive force, or improper cleaning.	For minor damage, consult a professional upholstery repair service. Prevent future damage by avoiding sharp objects and following care instructions.

8. SPECIFICATIONS

Feature	Detail
Brand	COLAMY
Model Number	3008B
Material	PU Leather, Rubberwood
Color	Green (as per current variant)
Overall Dimensions	29.72" H x 18.5" W x 20.28" D
Seat Dimensions	18.5" W x 16.5" D x 17.91" H
Back Dimensions	11.93" H x 18.31" W
Item Weight	25 pounds (per chair)
Maximum Load Capacity	300 Pounds
Special Feature	Cushion Availability, Adjustable Footpads
Included Components	6 dining chairs



Image 8.1: Detailed dimensions of the COLAMY Upholstered Dining Chair.

9. WARRANTY AND SUPPORT

For warranty information or customer support, please contact COLAMY directly through their official website or the retailer where the product was purchased. Keep your purchase receipt as proof of purchase.

Visit the [COLAMY Store on Amazon](#) for more products and information.