

Glitzhome 2022800029

Glitzhome 23.5-inch Tall Round Tapered Planters (Set of 2)

Model: 2022800029

User Manual

1. INTRODUCTION

This manual provides comprehensive instructions for the proper setup, use, and maintenance of your Glitzhome 23.5-inch Tall Round Tapered Planters. Please read this manual thoroughly before using the product to ensure optimal performance and longevity.

2. PRODUCT OVERVIEW AND FEATURES

The Glitzhome Tall Round Tapered Planters are designed for both indoor and outdoor use, offering a stylish solution for plant display. They feature a durable construction and a faux ceramic finish.



Image: Glitzhome 23.5-inch Tall Round Tapered Planters (Set of 2).

Key Features:

- **Material:** Constructed from durable PP plastic with a faux ceramic finish, suitable for various environments.
- **Design:** V-shape round design with a gradient cobalt blue color, providing an attractive appearance.
- **Drainage:** Equipped with a pre-installed, knock-out drainage hole for efficient water management.
- **Durability:** Lightweight yet sturdy, UV protected, and weather-resistant to prevent fading and cracking.
- **Versatility:** Suitable for both indoor and outdoor applications, including patios, porches, decks, gardens, living rooms, and bedrooms.
- **Guarantee:** Includes a one-year guarantee for product quality.



Manual Measurement, Allowable Error

Image: Overview of product features including weather resistance and drainage.

3. SPECIFICATIONS

Attribute	Detail
Brand	Glitzhome
Model Number	2022800029
Material	Plastic (PP)
Color	Gradient Cobalt Blue
Product Dimensions	13.75"D x 13.75"W x 23.5"H
Internal Size	13.25"D X 23.5"H
Bottom Size	8.75"D
Capacity	1244 Fluid Ounces
Number of Pieces	2
Item Weight	11.03 pounds (5.01 Kilograms)
Special Feature	With Drainage Holes
Indoor/Outdoor Usage	Indoor, Outdoor
Mounting Type	Floor Standing
Finish Type	Polished (Faux Ceramic)



Image: Product dimensions.

4. SETUP AND INSTALLATION

These planters require minimal setup. Follow these steps for proper installation:

1. **Unpacking:** Carefully remove the planters from their packaging. Inspect for any damage during transit.
2. **Drainage Hole Preparation:** Each planter comes with a pre-installed knock-out drainage hole at the bottom. Ensure this hole is fully open to allow for proper water drainage. If it is not open, gently push it out.



Image: Detail of the drainage hole at the base of the planter.

3. **Placement:** Choose a suitable location for your planters. They are designed for both indoor and outdoor use. For outdoor placement, consider areas that offer some shelter from extreme winds to prevent tipping, especially when empty or with small plants.

5. PLANTING INSTRUCTIONS

Once your planters are in place, you can proceed with planting:

1. **Soil:** Fill the planter with appropriate potting soil for your chosen plants. Leave adequate space from the rim for watering.
2. **Planting:** Carefully place your plant(s) into the planter, ensuring the roots are well-covered with soil. Gently pat down the soil around the base of the plant.
3. **Watering:** Water your plants thoroughly after planting. The drainage hole will prevent waterlogging, which is crucial for plant health.



Image: Planters in an outdoor setting.



Image: Planters in an indoor setting.

6. CARE AND MAINTENANCE

To maintain the appearance and functionality of your Glitzhome planters, follow these care guidelines:

- **Cleaning:** Wipe the planters with a soft, damp cloth to remove dust and dirt. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Drainage:** Periodically check the drainage hole to ensure it remains clear of debris, which could impede water flow.
- **Seasonal Care:** While weather-resistant, prolonged exposure to extreme temperatures or harsh weather conditions may affect the material over time. For optimal longevity, consider moving indoor during severe winter conditions if used outdoors.
- **UV Protection:** The planters are UV protected to resist fading. However, direct, intense sunlight over many years may still cause slight color changes.

7. TROUBLESHOOTING

This section addresses common issues you might encounter:

- **Water Accumulation:** If water is not draining properly, verify that the knock-out drainage hole at the bottom of the planter is fully open and not obstructed by soil or debris. Clear any blockages.
- **Planter Instability:** If the planter appears unstable, especially when empty or in windy conditions, consider adding a layer of gravel or heavy stones to the bottom before adding soil to increase its weight and stability. Ensure it is placed on a flat, level surface.
- **Fading/Cracking:** While designed to be UV protected and weather-resistant, extreme environmental conditions can impact any material. Ensure the planters are not exposed to prolonged, unusually harsh conditions.

8. WARRANTY AND SUPPORT

Your Glitzhome planters come with a one-year guarantee, ensuring quality and satisfaction. For any questions, concerns, or support needs regarding your product, please contact Glitzhome customer service. Refer to your purchase documentation for specific contact details or visit the official Glitzhome website for assistance.