

Manuals.plus /

› Xmenha /

› Xmenha JM21 True Wireless Earbuds User Manual

Xmenha JM21

Xmenha JM21 True Wireless Earbuds User Manual

Model: JM21 | Brand: Xmenha

INTRODUCTION

Welcome to your Xmenha JM21 True Wireless Earbuds. These earbuds feature Bluetooth 5.4 connectivity, a smart touchscreen charging case, and IPX7 waterproofing, designed for a superior audio experience. Please read this manual carefully to ensure proper use and optimal performance.

PACKAGE CONTENTS

The following items are included in your Xmenha JM21 True Wireless Earbuds package:

- 1 x Pair of True Wireless Earbuds
- 1 x Smart Touchscreen Charging Case
- 1 x USB Charging Cable
- 1 x User Manual

SETUP

1. Initial Charging

Before first use, fully charge the earbuds and the charging case. Connect the provided USB cable to the charging port on the case and a power source.

FINGERTIP MOVEMENT

EASY TOUCH CONTROL

The earbuds supports light touch pressure-sensitive operation, easy to touch the sensitive feedback can be achieved call answering swith and music playback control



Image: The charging case with a USB cable connected, indicating the charging process.

The charging case display will show the battery level. A full charge takes approximately 1 hour. The earbuds provide up to 6 hours of playtime, and the charging case extends this to a combined total of 60 hours.

ULTRA LONG BATTERY LIFE

6 h
Single
Endurance

60 h
Combined
range

120 day
Ultra-long s
tandby time



Image: The charging case screen showing battery percentages and estimated usage times for single endurance, combined range, and standby time.

2. Pairing with Your Device

1. Open the lid of the charging case. The earbuds will automatically power on and enter pairing mode.
2. On your mobile device (smartphone, tablet, etc.), go to the Bluetooth settings.
3. Search for available devices and select "JM21" (or similar) from the list.
4. Once connected, you will hear a confirmation tone, and the earbuds will be ready for use.

The earbuds utilize Bluetooth 5.4 for a fast, stable, and low-latency connection.

OPERATING INSTRUCTIONS

Earbud Touch Controls

The earbuds feature sensitive touch controls for various functions:

- **Play/Pause Music:** Single tap on either earbud.
- **Next Track:** Double tap on the right earbud.
- **Previous Track:** Double tap on the left earbud.

- **Answer/End Call:** Single tap on either earbud.
- **Reject Call:** Press and hold either earbud for 2 seconds.
- **Activate Voice Assistant:** Triple tap on either earbud.
- **Volume Adjustment:** Use the touchscreen case or your connected device.



Image: A hand demonstrating the touch control on an earbud, highlighting the ease of fingertip operation for music and call management.

Smart Touchscreen Charging Case Functions

The innovative touchscreen on the charging case allows for direct control without needing your phone:

- **Volume Control:** Adjust playback volume directly from the case screen.
- **EQ Modes:** Select from various equalizer presets (e.g., Studio, Vocals, Jazz) to customize your audio experience.
- **Battery Level:** View the current battery status of both earbuds and the case.
- **Time Display:** Check the current time.
- **Alarm Settings:** Set alarms directly from the case.
- **Remote Camera Control:** Connect the case via Bluetooth to your phone to use it as a remote shutter for taking photos.

Touch the screen, remote control to take photos Sensitive sensors, capture the moment

Connect the Bluetooth to turn into a selfie remote control in seconds, one press to take a picture to freeze the beautiful moments.



Volume adjustment is more convenient

Get rid of your mobile phone, the charging compartment or headphones can adjust the volume with one button



Image: The touchscreen charging case displaying options for volume adjustment and a camera icon, illustrating its remote control capabilities for photography.

ADJUSTABLE EQ MODE **TO CHOOSE YOUR STYLE**




Image: The touchscreen charging case displaying various equalizer modes such as 'Studio', 'Vocals', 'Clubs', and 'Jazz', allowing users to adjust audio style.

Audio Quality and Noise Cancellation

The earbuds are equipped with 13mm graphene diaphragm drivers for high-fidelity stereo sound, offering clear and powerful audio. CVC8.0 noise cancellation technology with dual HD microphones ensures clear calls even in noisy environments. The earbuds also feature Deep Active Noise Reduction (ANC) for an immersive listening experience.

Comfort and Fit

Designed for extended wear, the earbuds offer a secure and comfortable fit, making them suitable for various activities.

ZERO GRAVITY CLOUD COMFORT

- secure fit
- cloud wear
- skin-friendly



Image: A woman wearing the Xmenha JM21 earbuds, illustrating their comfortable and secure fit, described as 'Zero Gravity Cloud Comfort'.

MAINTENANCE

To ensure the longevity and optimal performance of your Xmenha JM21 earbuds, follow these maintenance guidelines:

- **Cleaning:** Regularly wipe the earbuds and charging case with a soft, dry, lint-free cloth. Avoid using abrasive materials or harsh chemicals.
- **Water Resistance:** The earbuds are IPX7 waterproof, meaning they can withstand immersion in water up to 1 meter for 30 minutes. However, the charging case is not waterproof. Do not expose the charging case to liquids. Always ensure earbuds are dry before placing them back in the charging case.
- **Storage:** Store the earbuds in their charging case when not in use to protect them from dust and damage. Keep them in a cool, dry place away from extreme temperatures.
- **Charging:** Use only the provided USB cable or a certified equivalent for charging.

TROUBLESHOOTING

If you encounter any issues with your earbuds, please refer to the following common solutions:

- **Earbuds not pairing:** Ensure both earbuds are charged. Place them back in the case, close the lid, then open it again to re-initiate pairing mode. Check your device's Bluetooth settings to ensure Bluetooth is enabled and try reconnecting.
- **No sound from one earbud:** Try resetting the earbuds by placing them in the case and then taking them out. Ensure both earbuds are charged.
- **Charging issues:** Verify the USB cable is securely connected to both the case and the power source. Ensure the charging contacts on the earbuds and inside the case are clean and free of debris.
- **Touch controls unresponsive:** Ensure your fingers are clean and dry. A light, firm touch is usually sufficient.
- **Poor sound quality:** Ensure the earbuds are properly seated in your ears. Try adjusting the EQ settings via the charging case.

If the problem persists, please contact customer support.

SPECIFICATIONS

Feature	Specification
Model Number	JM21
Bluetooth Version	5.4
Transmission Distance	Approximately 10 meters (33 feet)
Earbud Play Time	Up to 6 hours
Total Play Time (with Case)	Up to 60 hours
Earbud Charging Time	Approximately 1 hour
Water Resistance	IPX7 (Earbuds only)
Speaker Size	13mm
Noise Cancellation	CVC8.0 (for calls), Deep Active Noise Reduction (ANC)
Impedance	10 Ohms
Control Type	Touch, Volume Control (via case)
Material	Plastic
Weight	3.8 Ounces (total product)

WARRANTY AND SUPPORT

Your Xmenha JM21 True Wireless Earbuds come with a standard manufacturer's warranty. For specific warranty details, please refer to the documentation provided at the time of purchase or contact your retailer.

If you encounter any issues, receive a defective product, or have questions regarding the use or functionality of your earbuds, please do not hesitate to contact Xmenha customer support. Our team is

ready to assist you.

Contact information can typically be found on the product packaging, the official Xmenha website, or through your purchase platform.