

KISLOT T-KSA2051

KISLOT Counter Height Swivel Barstools with Back (T-KSA2051) - Instruction Manual

Model: T-KSA2051 | Set of 4 Grey Fabric

1. SAFETY INFORMATION

Please read and understand all instructions before assembly and use. Keep this manual for future reference.

- **Maximum Weight Capacity:** Each barstool is designed to support a maximum weight of **300 pounds (136 kg)**. Do not exceed this limit to prevent injury or damage.
- Ensure all bolts and screws are securely tightened before use. Periodically check and re-tighten as necessary.
- Do not stand on the barstool.
- Keep small parts away from children during assembly.
- Use the barstool on a flat, stable surface.

2. PACKAGE CONTENTS

Verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

Note: Your order may arrive in two separate packages at different times.

SWIVEL COUNTER HEIGHT STOOLS



Image: Barstool dimensions and package information. Each stool supports up to 300 lbs.

Components for One Barstool:

- (1) Seat with Backrest
- (1) Swivel Plate (pre-attached to seat or separate)
- (4) Legs
- (1) Footrest Ring
- Hardware Pack (screws, washers, Allen wrench)

Note: This product includes a set of 4 barstools, so you will receive four sets of the above components.

3. ASSEMBLY INSTRUCTIONS (SETUP)

Assembly is quick and typically takes less than 15 minutes per stool. Follow these steps carefully:

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a soft, clean surface to prevent scratches.
2. **Attach Swivel Plate (if separate):** If the swivel plate is not pre-attached to the seat, align it with the pre-drilled holes on the underside of the seat and secure it using the provided screws. Ensure it is centered and tight.

3. **Assemble Legs:** Attach the four legs to the swivel mechanism or seat base. Ensure the legs are oriented correctly as shown in the diagram. Do not fully tighten screws yet.
4. **Install Footrest Ring:** Connect the footrest ring to the legs. This ring provides stability and a comfortable footrest. Align the holes and insert the screws.
5. **Final Tightening:** Once all parts are loosely assembled, place the stool upright on a flat surface. Apply gentle pressure to ensure all legs are evenly touching the ground. Then, systematically tighten all screws and bolts using the Allen wrench until secure. Do not overtighten.
6. **Check Stability:** Gently rock the stool to ensure it is stable and does not wobble. If it wobbles, loosen the screws slightly, adjust, and re-tighten.



Image: Visual guide for barstool assembly steps.

4. USAGE AND FEATURES (OPERATING)

Your KISLOT barstools are designed for comfort and versatility in various settings such as kitchen islands, home bars, or dining areas.

- **360° Swivel Function:** The smooth swivel mechanism allows for effortless rotation, providing flexibility and ease of interaction in any direction.
- **Ergonomic Design:** The barrel-curved backrest and plush button-tufted upholstery offer superior lumbar support and comfort for extended seating.

- **Optimal Height:** With a 26-inch seat height, these barstools are ideally suited for countertops ranging from 35 to 37 inches high.
- **Protective Footpads:** The legs are equipped with protective footpads to prevent scratching your floors and ensure stability.



Image: Illustration of 360° swivel and recommended counter height compatibility.

EXTRA THICK CUSHION



Image: Detail of the ergonomic backrest design.



Image: Detail of the extra thick seat cushion for enhanced comfort.

5. CARE AND MAINTENANCE

Proper care will extend the life and appearance of your barstools.

- **Cleaning Fabric:** The stain-resistant fabric can be easily cleaned. For spills, gently wipe with a dry cloth immediately. For tougher stains, use a mild fabric cleaner and follow the product instructions, testing on an inconspicuous area first.
- **Frame Care:** Wipe the wooden legs and iron footrest with a dry cloth to remove dust and debris. Avoid abrasive cleaners.
- **Regular Checks:** Periodically inspect all screws and bolts to ensure they remain tight. Re-tighten if necessary to maintain stability and safety.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight may cause fabric fading.

6. TROUBLESHOOTING

If you encounter any issues, refer to the following common solutions:

- **Wobbling Stool:** Ensure all screws are evenly tightened. Loosen all screws slightly, sit on the stool to settle the legs, then re-tighten all screws firmly.

- **Creaking Noise:** Creaking can sometimes occur due to loose connections. Re-tighten all assembly hardware. Applying a small amount of silicone lubricant to the swivel mechanism or joints may also help.
- **Missing Parts:** If you find any parts missing upon unboxing, please contact KISLOT customer support immediately with your purchase details. Do not attempt to assemble with incomplete parts.
- **Difficulty Swiveling:** Check for any obstructions around the swivel plate. Ensure the stool is on a level surface.

7. SPECIFICATIONS

Brand	KISLOT
Model Number	T-KSA2051
Color	Grey Fabric
Product Dimensions (Overall)	20.9"D x 19.7"W x 37.8"H (53.1cm D x 50cm W x 96cm H)
Seat Height	26" (66 cm)
Maximum Weight Recommendation	300 lbs (136 kg)
Item Weight (per stool)	Approximately 11.25 lbs (45 lbs / 4 stools)
Number of Pieces	4 (Set of 4)
Assembly Required	Yes
Materials	Fabric upholstery, Solid Wood legs, Iron footrest

8. WARRANTY AND SUPPORT


KISLOT products are designed for quality and durability. We stand by our products with the following:






- **Warranty:** This product is covered by a **1-year warranty** from the date of purchase, covering manufacturing defects.
- **Customer Support:** For any questions, missing parts, or warranty claims, please contact our customer support team.

Email: Cs.furniture@outlook.com

Please include your purchase details (order number, date of purchase) when contacting support for faster assistance.

Related Documents - T-KSA2051

	<p>21st Scooter User Manual: Assembly, Safety, and Care Guide for 3-in-1 Kids Scooters</p> <p>Comprehensive user manual for the 21st Scooter, detailing safety instructions, assembly steps for the 3-in-1 Seat, O-bar, and T-bar configurations, servicing, warranty information, and usage guidelines for children's scooters.</p>
---	--

	<p>Aeroquip by Danfoss 1A Braided Hose Ends Quick Reference Guide</p> <p>Comprehensive quick reference guide for Aeroquip by Danfoss 1A Braided Hose Ends, detailing part numbers, thread specifications, and hose sizes for various fitting types, including NPTF, JIC, ORS, SAE, DIN, and BSPP connections.</p>
	<p>Westfalia Tow Bar Installation and Operating Manual</p> <p>Comprehensive installation and operating manual for Westfalia tow bars, detailing fitment for various Audi, Seat, Skoda, and Volkswagen models. Includes safety guidelines and part specifications.</p>
	<p>Ki Mobility Arc Technical Manual: A Guide for Qualified Technicians</p> <p>Comprehensive technical manual for the Ki Mobility Arc wheelchair, detailing setup, adjustments, and maintenance procedures for qualified technicians. Covers seat height, caster configuration, chair width, and various component adjustments.</p>
	<p>LaScoota Kick Scooter User Guide and Features</p> <p>An informative guide detailing the features and usage instructions for the LaScoota kick scooter, including safety information and product specifications.</p>
	<p>Tunturi Adjustable T-Bar Row User Manual and Assembly Guide</p> <p>Comprehensive user manual and assembly guide for the Tunturi Adjustable T-Bar Row, including safety instructions, parts list, usage, and maintenance tips.</p>