ZWP WHHW081AW

ZWP WHHW081AW Replacement Air Conditioner Remote Control User Manual

Model: WHHW081AW | Brand: ZWP

INTRODUCTION

This manual provides instructions for the ZWP WHHW081AW Replacement Air Conditioner Remote Control. Please read this manual thoroughly before use to ensure proper operation and to maximize the lifespan of your remote control.

PRODUCT OVERVIEW

The ZWP WHHW081AW is a direct replacement remote control designed for a wide range of window air conditioner models from various brands. It offers essential functions for controlling your air conditioner.

This image displays the ergonomic design of the remote control, highlighting its primary function buttons.

Stable.Smarter

Smart and stable signal enjoy your life

∞

Stable Link

Quick response

AI

Smart Chip

Save power

POWER   COOL

SLEEP   ∧   FAN SPEED

TIMER   ECO   DISPLAY

AUTO MODE   ∨   FAN ONLY

The remote is engineered for stable signal transmission, quick response times, and energy efficiency through its smart chip technology.

Constructed from durable, environmentally friendly ABS material, this remote is designed for a comfortable grip and extended operational life.

SETUP

Battery Installation

The remote control requires two AAA batteries (not included).

1. Locate the battery compartment on the back of the remote control.
2. Slide open the battery compartment cover.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Close the battery compartment cover until it clicks securely into place.

CAUTION:

- Be sure the batteries are inserted properly.
- Do not use batteries other than the type specified.
- Do not use old and new batteries together.

- Do not dispose of batteries in fire. Batteries may explode or leak.

Work Right Out of The Box After Putting Batteries

Requires Two AAA batteries
(Batteries are not included)

CAUTION
1. Be sure the batteries are inserted properly.
2. Do not use batteries other than the type specified.
3. Do not use old batteries with new ones.
4. Do not dispose of batteries in fire. Batteries may explode or leak.

This image illustrates the correct method for inserting two AAA batteries into the remote control's battery compartment.

OPERATING INSTRUCTIONS

Basic Operation

This remote control is designed to work immediately with compatible air conditioner models after battery installation. No programming is typically required.

The remote control offers a long operational distance of up to 8 meters, allowing flexible control of your air conditioner.

Button Functions

Button	Function
POWER	Turns the air conditioner On or Off.
COOL	Activates or adjusts the cooling mode.
FAN SPEED	Adjusts the fan speed (e.g., Low, Medium, High, Auto).
DISPLAY	Toggles the display on the air conditioner unit.
SLEEP	Activates or deactivates sleep mode for energy saving and quiet operation.
TIMER	Sets a timer for the air conditioner to turn On or Off automatically.
ECO	Engages or disengages the energy-saving ECO mode.

Button	Function
AUTO MODE	Automatically selects the operating mode (cooling, fan) based on room temperature.
FAN ONLY	Operates the unit as a fan without cooling.
Arrow Buttons (Up/Down)	Adjusts temperature settings or navigates timer settings.

Compatibility

This remote is compatible with numerous window air conditioner models from brands including, but not limited to:

- Black+Decker (e.g., BWAC06WT, BWAC08WT, BWAC10WT, BWAC12WT)
- Della (e.g., 048-TL-W08KW, 048-TL-W10KW, A54-WAC-002-6K-WIFI)
- Amana (e.g., AMAP151BW, AMAP061BW, AMAP101CW)
- TCL (e.g., TAW05CMW0N, TAW08CR19, TAW12CR19)
- Crosley (e.g., RCRCATS15B1, CATS12A1, CATS06A1)
- Acekool (e.g., CW1, CW2, Smart Window Air Conditioner 6000 BTU)
- Emerson Quiet Kool (e.g., EARC15RE1, EARC5RD1, EARC10RE1)
- ROVSUN (e.g., G46000667)
- GarveeHome
- Magshion (e.g., MAG-A54-WAC-003)
- Adoolla
- ACONEE
- GAOMON (e.g., WAC6K, WAC10K)
- Comfort Zone (e.g., CZ12759)
- Honeywell (e.g., HAC6)
- Mollie (e.g., A54-WAC-002-6K-WIFI)

For a complete list of compatible models, please refer to the product listing or contact customer support.

CARE AND MAINTENANCE

- Keep the remote control dry. If it gets wet, wipe it dry immediately.
- Use a soft, dry cloth to clean the remote control. Do not use abrasive cleaners or solvents.
- Avoid exposing the remote control to extreme temperatures or direct sunlight.
- If the remote control will not be used for an extended period, remove the batteries to prevent leakage.

TROUBLESHOOTING

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Remote not responding.	Dead or incorrectly inserted batteries.	Replace batteries with new AAA batteries, ensuring correct polarity.
Remote has limited range.	Obstruction between remote and AC unit; low battery power.	Ensure a clear line of sight to the AC unit. Replace batteries if needed.
Specific functions not working.	Remote may not be fully compatible with all advanced features of your specific AC model.	Verify compatibility with your AC model's manual. This remote provides core functions.

PRODUCT SPECIFICATIONS

- **Model:** WHHW081AW
- **Brand:** ZWP
- **Color:** White
- **Special Feature:** Ergonomic design
- **Power Source:** 2 x AAA Batteries (not included)
- **Item Weight:** 2.89 ounces (approx. 82 grams)
- **Package Dimensions:** 4.96 x 2.99 x 1.1 inches (approx. 12.6 x 7.6 x 2.8 cm)
- **Compatible Devices:** Air Conditioner
- **Max Number of Supported Devices:** 1

WARRANTY AND SUPPORT

For any questions regarding the ZWP WHHW081AW Replacement Air Conditioner Remote Control, please contact your retailer or the manufacturer directly. While specific warranty details are not provided in this manual, most products come with a standard manufacturer's warranty against defects. Please retain your purchase receipt for warranty claims.

Visit the ZWP Store on Amazon for more information or to contact customer service.