

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Tiksounds](#) /

› [Tiksounds Wireless Earbuds A12 User Manual](#)

Tiksounds A12

Tiksounds Wireless Earbuds A12 User Manual

Model: A12 | Brand: Tiksounds

[What's in the Box](#)

[Product Overview](#)

[Initial Setup](#)

[Bluetooth Pairing](#)

[Touch Controls](#)

[Charging](#)

[Wearing](#)

[Waterproofing](#)

[Specifications](#)

[Troubleshooting](#)

[Warranty & Support](#)

1. WHAT'S IN THE BOX

Upon opening your Tiksounds Wireless Earbuds A12 package, please verify that all the following components are included:

- Wireless Earbuds (Left and Right)
- Charging Case
- Eartips (S, M, L sizes)
- Type-C Charging Cable
- User Manual

What's in the box?

1. Eartips SML
2. Type-C Charging Cable
3. Wireless Earbuds
4. Packaging box
5. Charging Case
6. User Manual




Image: All items included in the Tiksounds A12 Wireless Earbuds package.

2. PRODUCT OVERVIEW

The Tiksounds A12 Wireless Earbuds are designed for an enhanced audio experience, featuring a secure fit and advanced connectivity. Key features include:

- **Bluetooth 5.3 Connectivity:** Ensures stable and efficient wireless connection.
- **72-Hour Total Playtime:** 8 hours per earbud, with an additional 64 hours provided by the charging case.
- **ENC Noise Canceling Mic:** For clear call quality by reducing environmental noise.
- **IPX7 Waterproof Rating:** Provides protection against sweat and rain, suitable for workouts.
- **Over-Ear Hook Design:** Offers a secure and comfortable fit, ideal for active use.
- **14.2mm Dynamic Drivers:** Delivers deep bass and clear audio.
- **LED Power Display:** On the charging case for easy battery monitoring.



Image: Tiksounds A12 Wireless Earbuds and Charging Case.

Bass Boosted by 85%

Vibrant bass, balanced midrange and treble



Image: Internal structure of the earbud highlighting the 14.2mm driver for enhanced bass.

ENC Noise Reduction Chip

Stereo sound without background noise



Image: Earbud with ENC Noise Cancelling Microphone for clear calls.

3. INITIAL SETUP

3.1 First Use and Charging

Before using your Tiksounds A12 earbuds for the first time, it is recommended to fully charge both the earbuds and the charging case.

1. Place both earbuds into the charging case.
2. Connect the Type-C charging cable to the charging port on the case and plug the other end into a USB power adapter (not included).
3. The LED display on the charging case will show the battery level. Allow the case and earbuds to charge until the display indicates 100% for the case and full charge for the earbuds.



Image: Charging the earbuds and case, illustrating battery life.

4. BLUETOOTH PAIRING

4.1 Pairing with Your Device

Follow these steps to connect your Tiksounds A12 earbuds to your smartphone, tablet, or other Bluetooth-enabled device:

1. Ensure the earbuds are fully charged.
2. Open the charging case. The earbuds will automatically enter pairing mode, and their indicator lights will flash.
3. On your device, go to Bluetooth settings and turn Bluetooth ON.
4. Search for available devices and select "A12" from the list.
5. Once connected, the earbud indicator lights will turn off, and your device will show "Connected".

One Step Pairing

Advanced bluetooth V5.3, Enjoy a stable connection and HD call



Image: One-step pairing process with a mobile device.

4.2 Pairing Demonstration Video

Your browser does not support the video tag.

Video: A visual guide demonstrating the pairing process and key features of Tiksounds Bluetooth Earbuds. This video shows the earbuds opening, connecting via Bluetooth 5.3, touch controls, and charging.

5. TOUCH CONTROLS

The Tiksounds A12 earbuds feature intuitive touch controls on each earbud for easy management of audio playback and calls. The specific functions are:

Action	Left Earbud	Right Earbud
Play/Pause Music	Single Tap	Single Tap
Next Track	Double Tap	Double Tap

Action	Left Earbud	Right Earbud
Previous Track	Triple Tap	Triple Tap
Volume Up	Press and Hold	N/A
Volume Down	N/A	Press and Hold
Answer/End Call	Single Tap	Single Tap
Reject Call	Press and Hold	Press and Hold
Activate Voice Assistant	Quadruple Tap	Quadruple Tap

Note: Some functions may vary slightly depending on your connected device and operating system.

6. CHARGING THE EARBUDS AND CASE

6.1 Earbud Charging

To charge the earbuds, simply place them back into the charging case. They will automatically begin charging from the case's internal battery. The LED indicators on the earbuds will show charging status, and the case's display will show the earbuds' individual charge levels.

6.2 Case Charging

When the charging case battery is low, connect it to a power source using the provided Type-C USB cable. The LED display on the case will show the current battery percentage, indicating charging progress.

A full charge provides approximately 8 hours of listening time for the earbuds, and the charging case extends this to a total of 72 hours.



Image: Visual representation of earbud and case battery life and charging via Type-C.

7. WEARING THE EARBUDS

For optimal sound quality and comfort, it is important to wear the earbuds correctly. The Tiksounds A12 earbuds feature flexible earhooks and multiple eartip sizes to ensure a secure fit.

1. **Choose the Right Eartips:** Experiment with the included S, M, and L eartips to find the size that provides the best seal and comfort for your ears. A good seal is crucial for bass response and noise isolation.
2. **Position the Earbud:** Gently insert the earbud into your ear canal.
3. **Adjust the Earhook:** Loop the flexible earhook over the top of your ear. Adjust it until it rests comfortably and securely behind your ear, holding the earbud in place.
4. **Check the Fit:** The earbud should feel snug but not uncomfortable. It should remain stable even during movement.

Secure and Comfort Fit




Image: Guide to achieving a secure and comfortable fit with the earhooks and interchangeable eartips.

8. IPX7 WATERPROOF PROTECTION

The Tiksounds A12 earbuds are rated IPX7 waterproof, meaning they are protected against immersion in water up to 1 meter for up to 30 minutes. This makes them suitable for:

- Workouts and intense exercise (sweat resistance)
- Running in light rain
- Accidental splashes

Important Considerations:

- The charging case is **not** waterproof. Do not expose the charging case to liquids.
- Avoid using the earbuds in saltwater, chlorinated water, or other chemical liquids.
- Ensure the earbuds are completely dry before placing them back into the charging case to prevent damage.



Image: Earbuds demonstrating IPX7 waterproof capability.

9. PRODUCT SPECIFICATIONS

Detailed technical specifications for the Tiksounds A12 Wireless Earbuds:

Feature	Specification
Model Name	A12
Connectivity Technology	Wireless (Bluetooth)
Bluetooth Version	5.3
Bluetooth Range	15 Meters
Audio Driver Size	14.2 Millimeters
Battery Life (Earbuds)	8 Hours (single charge)
Total Playtime (with Case)	72 Hours
Noise Control	Hybrid Noise Cancellation (ENC Mic)
Water Resistance Level	IPX7 Waterproof
Control Method	Touch

Feature	Specification
Ear Placement	Over Ear (with earhooks)
Compatible Devices	Smartphones, Tablets, Laptops, Smartwatches
Item Weight	0.11 Kilograms (approx. 3.84 ounces)
Product Dimensions	1.81 x 1.26 x 1.02 inches

10. TROUBLESHOOTING

If you encounter any issues with your Tiksounds A12 earbuds, please refer to the following common problems and solutions:

10.1 Earbuds Not Pairing

- **Ensure Charge:** Make sure both earbuds and the charging case have sufficient battery.
- **Reset Earbuds:** Place both earbuds back into the charging case, close the lid for 5 seconds, then open it again.
- **Forget Device:** On your device's Bluetooth settings, forget or delete "A12" from the list of paired devices. Then, attempt to pair again following the instructions in Section 4.
- **Proximity:** Ensure the earbuds are close to your device during pairing.

10.2 No Sound or Low Volume

- **Check Volume:** Increase the volume on both your connected device and the earbuds (using touch controls).
- **Re-pair:** Disconnect and re-pair the earbuds with your device.
- **Clean Eartips:** Ensure eartips are clean and free of debris that might block sound.
- **Proper Fit:** Adjust the earbuds for a secure fit in your ear canal to ensure optimal sound delivery.

10.3 Charging Issues

- **Check Cable:** Ensure the Type-C charging cable is securely connected to both the case and the power source. Try a different cable or power adapter.
- **Clean Charging Contacts:** Gently clean the charging contacts on both the earbuds and inside the charging case with a dry cotton swab.
- **Case Battery:** Ensure the charging case itself has power.

10.4 Call Quality Issues

- **Microphone Position:** Ensure the microphone on the earbuds is not obstructed.
- **Environment:** Move to a quieter environment if possible, as ENC works best on consistent background noise.
- **Signal Strength:** Stay within the Bluetooth range of your connected device.

11. WARRANTY AND SUPPORT

Tiksounds products are designed with quality and customer satisfaction in mind. For specific warranty information, including coverage duration and terms, please refer to the warranty card included in your product packaging or visit the official Tiksounds website.

If you require technical assistance, have questions about your product, or need to initiate a warranty claim, please

contact Tiksounds customer support through the following channels:

- **Email:** Refer to your product packaging or the official website for the support email address.
- **Website:** Visit the [Tiksounds Official Store on Amazon](#) for FAQs and contact options.

Please have your product model number (A12) and purchase details ready when contacting support to ensure efficient service.

© 2024 Tiksounds. All rights reserved.

Related Documents - A12

	<p>Tiksounds X15 Wireless Earbuds User Manual and Operation Guide</p> <p>Comprehensive guide for Tiksounds X15 Wireless Earbuds, covering Bluetooth pairing, operation, reset procedures, volume control, and troubleshooting. Learn how to use your Tiksounds X15 earbuds effectively.</p>
	<p>Tiksounds BX17 Bluetooth Wireless Earbuds Instruction Manual</p> <p>Comprehensive user guide for the Tiksounds BX17 Bluetooth Wireless Earbuds, detailing setup, operation, pairing procedures, troubleshooting tips, and FCC compliance information.</p>
	<p>Tiksounds X15 Wireless Earbuds User Manual</p> <p>User manual for the Tiksounds X15 Wireless Earbuds, detailing connection, operation, reset procedures, and troubleshooting steps.</p>
	<p>Tiksounds BX17 Bluetooth Wireless Earbuds Instruction Manual</p> <p>Instruction manual for the Tiksounds BX17 Bluetooth Wireless Earbuds, covering setup, operation, and troubleshooting.</p>
	<p>Q25-TWS Stereo Headset User Manual - Setup, Features, and Safety</p> <p>Comprehensive user manual for the Q25-TWS Stereo Headset, covering setup, key features, indicator status, safety notes, and maintenance. Learn how to pair, use, and care for your wireless earbuds.</p>



[Tiksounds S20 Smart Wireless Earbuds: Instruction Manual](#)

Comprehensive guide for setting up and using Tiksounds S20 Smart Wireless Earbuds, covering pairing, operation, battery indicators, and troubleshooting.