

[Manuals.plus](#) /

› [UNIHIMAL](#) /

› UNIHIMAL 15-Way Golf Cart Bag Instruction Manual

UNIHIMAL Golf Cart Bag Lite 004

UNIHIMAL 15-Way Golf Cart Bag

INSTRUCTION MANUAL

Introduction

The UNIHIMAL Golf Cart Bag is designed to enhance your golfing experience by providing superior organization, protection, and convenience for your golf clubs and accessories. Crafted from durable 420D polyester and luxurious PU leather, this bag combines rugged reliability with sleek style, making it suitable for any course condition.

This manual provides detailed instructions on the setup, features, operation, and maintenance of your new golf cart bag to ensure optimal performance and longevity.

Product Features



Image: The UNIHIMAL 15-Way Golf Cart Bag in black and white, showcasing its overall design and the detailed 15-way top divider.



15 FULL-LENGTH DIVIDERS



35inch



Image: A visual representation of the 15 full-length dividers within the golf bag, numbered for clarity, alongside the bag's 35-inch height.

- **15-Way Full-Length Dividers:** This golf cart bag features a 15-way top with full-length dividers and a dedicated putter well. This design effectively organizes and protects your clubs, minimizing friction and noise during transport and play, allowing you to concentrate on your game.
- **Stable Top and Ergonomic Handle:** The innovative top design securely holds clubs to prevent displacement and collision. An auxiliary handle facilitates easier lifting and movement, particularly when navigating uphill terrain or loading the bag onto a golf cart, ensuring smooth operation.
- **Ample Storage (14 Pockets):** The bag includes 14 strategically placed pockets for comprehensive organization. These include a cooler pocket for beverages, a valuables pocket for personal items, a dedicated shoe pocket, and a magnetic pocket for quick access to essentials.
- **Upgraded Cart-Friendly Design:** Equipped with cart strap channels and removable Velcro straps, the bag can be securely attached to most golf or push carts. A specialized rain cover is included to protect your clubs in adverse weather conditions. The thick velvet adjustable shoulder strap provides comfort during carrying.
- **Sturdy and Durable Construction:** A reinforced base ensures exceptional stability on various terrains. The bag is constructed from high-quality 420D polyester and luxurious PU leather, offering tear resistance and a sophisticated

appearance for long-lasting use on the course.

Components Overview

Your UNIHIMAL Golf Cart Bag comes equipped with several key components designed for functionality and convenience:

- **15-Way Top Divider:** Individual slots for each club, including an oversized putter well.
- **Ergonomic Top Handles:** For easy lifting and maneuvering.
- **Shoulder Strap:** Padded and adjustable for comfortable carrying.
- **Multiple Pockets:**
 - Cooler Pocket: Insulated for drinks.
 - Valuables Pocket: Secure storage for personal items.
 - Shoe Pocket: Separate compartment for golf shoes.
 - Magnetic Pocket: For quick access items like golf balls or tees.
 - Tee Holder: External loops for easy tee access.
 - Water Bottle Sleeve: Dedicated slot for hydration.
 - Additional large and middle pockets for general storage.
- **Umbrella Holder:** Secure strap and loop for an umbrella.
- **Towel & Glove Hook:** Convenient attachment point for accessories.
- **Cart Strap Channels:** Designed to secure the bag to a golf cart.
- **Reinforced Base:** Provides stability when standing.
- **Rain Cover:** Protects clubs from elements.

AMPLE STORAGE FOR ESSENTIALS



Tee Holder



Cooler Pocket



Gnetic Pocket




Shoe Pocket



Towel & Glove Hook



Valuables Pocket



Bottom Side Pocket



Water Bottle Sleeve

Image: A detailed view highlighting the various storage pockets available on the UNIHIMAL Golf Cart Bag, including the tee holder, cooler pocket, magnetic pocket, shoe pocket, valuables pocket, and water bottle sleeve.



DUST COVER UMBRELLA STAND

Umbrella Holder



Rain Cover



Image: The golf bag shown with its protective rain cover installed and an umbrella secured in the dedicated umbrella holder.

Setup

1. **Unpacking:** Carefully remove the golf bag and all accessories from its packaging. Inspect for any damage.
2. **Attaching Shoulder Strap:** Locate the padded shoulder strap. Attach each end of the strap to the D-rings located on the upper sides of the bag. Adjust the strap length for comfortable carrying.
3. **Club Placement:** Utilize the 15-way full-length dividers to organize your clubs. Place longer clubs (drivers, woods) in the larger top slots and shorter clubs (irons, wedges) in the lower slots. The dedicated putter well is designed for easy access to your putter.
4. **Accessory Organization:**
 - Store golf balls and tees in the magnetic pocket or ball pocket.
 - Use the valuables pocket for your phone, wallet, and keys.
 - Place golf shoes in the dedicated shoe pocket to keep them separate from other items.
 - Utilize the cooler pocket for drinks and snacks.
 - Attach your golf towel and glove to the designated hook.

5. **Rain Cover Installation:** For protection against rain, snap the rain cover onto the top of the bag, ensuring it fully covers the club heads.

Operating Instructions

On the Golf Course:

1. Securing to a Golf Cart:



Image: The UNIHIMAL Golf Cart Bag securely attached to the back of a golf cart, demonstrating the fixed webbing and removable strap features for stability.

- Place the bag on the back of your golf cart. Utilize the cart strap channels and removable Velcro straps to firmly secure the bag to the cart. This prevents shifting and ensures stability during movement across the course.
2. **Club Access:** The 15-way divider system allows for easy insertion and retrieval of clubs. The stable top design minimizes club rattling and tangling.
 3. **Accessing Pockets:** All 14 pockets are designed for easy access. Zippers are durable and smooth for quick opening and closing. The magnetic pocket offers instant access without needing to zip/unzip.

4. **Carrying the Bag:** When not on a cart, use the padded shoulder strap for comfortable carrying. The auxiliary handle at the top provides an additional grip for lifting and maneuvering.

Product Video:

Your browser does not support the video tag.

Video: An official product video showcasing the features and functionality of the UNIHIMAL Golf Cart Bag, including its storage capacity, club organization, and ease of use on the golf course.

Maintenance

- Cleaning:**
For general cleaning, wipe the exterior of the bag with a damp cloth and mild soap. For tougher stains, a soft brush can be used. Ensure the bag is completely dry before storage to prevent mildew.
The polyester and PU leather materials are designed for easy cleaning and durability.
- Storage:** Store the golf bag in a cool, dry place away from direct sunlight when not in use. Ensure all pockets are empty and clean before long-term storage.
- Zipper Care:** Periodically check zippers for smooth operation. If a zipper becomes stiff, apply a small amount of zipper lubricant or wax.

Troubleshooting

Problem	Possible Cause	Solution
Clubs rattling excessively.	Improper club placement or bag not fully loaded.	Ensure clubs are placed in their designated dividers. The 15-way system is designed to minimize movement. If the bag is not full, consider adding headcovers to reduce space.
Bag feels unstable when standing.	Uneven surface or heavy items concentrated on one side.	Place the bag on a flat, stable surface. Distribute weight evenly among the pockets. The reinforced base provides stability, but extreme unevenness can still cause issues.
Difficulty securing bag to golf cart.	Incorrect use of straps or channels.	Ensure cart straps pass through the designated cart strap channels. Use the removable Velcro straps for additional security if needed.
Zippers are stiff or stuck.	Dirt, debris, or lack of lubrication.	Clean the zipper teeth with a small brush. Apply a small amount of zipper lubricant, wax, or even a pencil lead to the teeth to improve smoothness.

Specifications

Attribute	Detail
Brand	UNIHIMAL
Model Name	Golf Cart Bag Lite 004
Color	Black White
Material	Polyester, PU Leather
Product Dimensions (L x W x H)	16" x 11" x 35"

Attribute	Detail
Item Weight	9.3 Pounds
Number of Dividers	15 (full-length)
Number of Pockets	14
Strap Type	Adjustable Shoulder Strap
UPC	198715395433

Warranty and Support

Please note that this product does not come with a manufacturer's warranty as per the provided specifications. For any product-related inquiries, support, or assistance, please contact the seller directly through the platform where the purchase was made.

For general care and maintenance tips, please refer to the "Maintenance" section of this manual.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DPQ653RP>

More documents and user manuals: <https://manuals.plus/>