

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [domi outdoor living](#) /
- › [Domi 10x12FT Hardtop Gazebo Instruction Manual](#)

domi outdoor living 10x12FT Hardtop Gazebo

Domi 10x12FT Hardtop Gazebo Instruction Manual

Model: 10x12FT Hardtop Gazebo | Brand: domi outdoor living

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your Domi 10x12FT Hardtop Gazebo. Please read all instructions carefully before beginning assembly and retain this manual for future reference. Proper assembly and care will ensure the longevity and safe use of your gazebo.



Image: Fully assembled Domi 10x12FT Hardtop Gazebo, showcasing its design and size in an outdoor environment.

SAFETY INFORMATION

Important Safety Warnings:

- Ensure all parts are present and undamaged before assembly. Do not proceed with assembly if any parts are missing or damaged.
- Assembly requires at least two adults.
- Wear appropriate safety gear, such as gloves, during assembly.
- Choose a level and stable surface for installation. Secure the gazebo to the ground using appropriate anchoring methods to prevent tipping in strong winds.
- Do not hang heavy objects from the gazebo frame or roof.
- In case of severe weather conditions (heavy snow, strong winds), it is recommended to remove curtains and netting and, if possible, disassemble the gazebo to prevent damage.

- Keep children and pets away from the assembly area.

PARTS LIST

Before starting assembly, verify that all components listed below are included in your package. Refer to the assembly diagram for visual identification of parts.

Part Name	Quantity	Description
Roof Panels (Galvanized Steel)	Varies by model	Main roof sections, double-layer design.
Frame Posts (Metal)	4 or more	Main support columns for the gazebo structure.
Support Beams/Bars	Varies	Connective elements for the roof and frame.
Triangular Supports	Varies	Reinforcement for the main posts.
Base Plates (Reinforced)	Varies	For anchoring the posts to the ground.
Curtains (Detachable)	4 or more	Fabric panels for privacy and weather protection.
Netting (Detachable)	4 or more	Mesh screens for insect protection.
Ceiling Hooks	3	For hanging lights or fans.
Hardware Kit	1 set	Bolts, screws, washers, and tools for assembly.

ASSEMBLY INSTRUCTIONS

Follow these steps carefully for proper assembly. It is recommended to have at least two people for this process.

Step 1: Assemble the Main Frame

1. Unpack all components and lay them out on a clean, flat surface.
2. Connect the main frame posts (A) to the top and bottom support beams (B, C) using the provided hardware. Ensure all connections are secure but do not fully tighten bolts yet.
3. Attach the triangular support structures (D) to the main posts for added stability.

STURDY METAL FRAME

Powder-coated and Thickened posts, Triangular Support, Reinforced Base.




Image: Detail of the sturdy metal frame, highlighting the triangular support and reinforced base for secure installation.

Step 2: Install the Double Galvanized Steel Roof

1. Carefully lift and position the lower roof panels onto the assembled frame. Secure them with the designated hardware.
2. Install the upper roof panels, forming the double-layer design. This design enhances airflow and provides UV protection.
3. Ensure all roof panels are properly aligned and fastened to prevent water leakage.

Double Roof Design



Image: Visual representation of the double roof design, showing how it allows for air ventilation and offers protection from UVA and UVB rays.

Step 3: Attach Curtains and Netting

1. Hang the detachable curtains and netting onto the designated tracks or hooks on the gazebo frame.
2. Ensure the zippers on the netting and curtains function smoothly for easy opening and closing.

DETACHABLE CURTAIN AND NETTING



Keep
Ventilated



Enjoy the
outdoors



Anti-mosquito



Block Harsh
Sunlight



Privacy
Protection



Keep
Warm

Image: Various configurations of the gazebo with detachable curtains and netting, illustrating options for ventilation, insect protection, and privacy.

Step 4: Final Tightening and Anchoring

1. Once all major components are in place, go back and fully tighten all bolts and screws.
2. Anchor the gazebo to the ground using the reinforced base plates and appropriate ground stakes or bolts (not always included, depending on surface). This step is crucial for stability and safety.

OPERATING INSTRUCTIONS

Your Domi Hardtop Gazebo is designed for versatile outdoor use. Here's how to maximize its features:

- **Curtains and Netting:** The detachable curtains provide privacy and protection from sun and light rain. The netting keeps insects out while allowing airflow. Use the integrated zippers and ties to adjust their position as needed.
- **Ceiling Hooks:** Three hooks are located on the interior ceiling of the gazebo. These can be used to hang lightweight decorative items such as string lights, small fans, or plants. Do not exceed the weight limit specified in

the product documentation (if any).

Excess Ceiling Hooks

There are three hooks on the ceiling available for hanging fans, lights, decorations, and more.



Image: Interior roof of the gazebo, illustrating the three ceiling hooks suitable for hanging various items like lights or fans.

MAINTENANCE

Regular maintenance will extend the life and appearance of your gazebo.

- **Frame:** Clean the metal frame with a mild soap and water solution. Rinse thoroughly and dry to prevent rust. Inspect all bolts and connections periodically and tighten if necessary.
- **Roof:** The galvanized steel roof is designed for durability. Clean it with water and a soft brush to remove debris. Ensure the water gutter system is clear of leaves and blockages to maintain efficient drainage.
- **Curtains and Netting:** These can be detached and machine washed on a gentle cycle with cold water, or hand washed. Air dry only. Do not bleach or iron. Store them indoors during off-seasons or severe weather.
- **Winter Care:** While the gazebo is designed to withstand snow loads up to 2500 lbs and winds up to 40 mph, it is advisable to clear heavy snow accumulation from the roof to prevent structural stress. Consider disassembling and

storing the gazebo in areas with extreme winter conditions.



Image: Detail of the water gutter design, illustrating how rainwater is channeled away from the gazebo structure.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Gazebo feels unstable or wobbly.	Loose connections; improper anchoring; uneven ground.	Ensure all bolts are tightened. Verify the gazebo is anchored securely to a level surface.
Water pooling on the roof or leaking.	Improper roof panel installation; blocked gutters.	Check roof panel alignment and ensure all fasteners are secure. Clear any debris from the water gutters.
Curtains/Netting not closing properly.	Zippers stuck; fabric snagged; tracks obstructed.	Inspect zippers for damage or obstructions. Ensure fabric is not caught. Clean tracks if necessary.

Problem	Possible Cause	Solution
Rust spots appearing on metal frame.	Lack of regular cleaning and drying; prolonged exposure to moisture.	Clean and dry the frame regularly. Apply rust-inhibiting paint to affected areas if needed.

SPECIFICATIONS

Brand: domi outdoor living

Model: 10x12FT Hardtop Gazebo

Material: Metal, Galvanized Steel Roof, Alloy Steel, Aluminum

Color: Gray

Product Dimensions (L x W x H): 142.91"L x 117.32"W x 114.7"H

Item Weight: 370 Pounds

Water Resistance Level: Waterproof

Ultraviolet Light Protection: 99% UV-proof, UPF 50+

Snow Load Capacity: Up to 2500 lbs

Wind Resistance: Up to 40 mph

Assembly Required: Yes

Dimensions of Domi Gazebo

Create a comfortable outdoor living space for your family.




Image: Dimensional drawing of the Domi Gazebo, providing length, width, and height measurements.

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided with your purchase documentation or visit the official Domi Outdoor Living website. Keep your purchase receipt as proof of purchase for any warranty claims.

Contact Information:

Brand Website: [domi outdoor living Store on Amazon](#)

Customer Service: Refer to your product packaging or the brand's official website for specific contact methods (phone, email).



