



---

[Manuals.plus](#) /

› [OUKITEL](#) /

› OUKITEL P1 Smartphone User Manual

## OUKITEL OUKITEL P1

# OUKITEL P1 Smartphone User Manual

Model: OUKITEL P1

## 1. INTRODUCTION

---

This manual provides detailed instructions for the OUKITEL P1 Unlocked Cell Phone. Please read this manual carefully before using your device to ensure proper operation and to maximize its features. Keep this manual for future reference.



Figure 1: OUKITEL P1 Smartphone

## 2. WHAT'S IN THE BOX

Upon opening the package, please verify that all items listed below are present and in good condition:

- 1 x OUKITEL P1 Mobile Phone
- 1 x Charger
- 1 x Tempered Film
- 1 x Instruction Manual
- 1 x Cleaning Cloth
- 1 x Card Pins
- 1 x Case
- 1 x Mobile Box

## 3. PRODUCT OVERVIEW

---

### 3.1 Design and Display

The OUKITEL P1 features an elegant and ultra-thin design with a 3D curved glass body and metal frame, providing a comfortable grip. It is equipped with a 6.7-inch FHD+ AMOLED display, offering sharp images and vibrant colors for an immersive viewing experience. The display boasts a 120Hz refresh rate and a resolution of 1080×2412, ensuring smooth scrolling and vivid visuals.

# 6.7" FHD+ AMOLED Screen




Resolution  
1080×2412



Size  
6.7 Inch



Brightness  
500 Nits



Aspect Ratio  
20:09



Figure 2: Display Specifications (Resolution, Size, Brightness, Aspect Ratio)

Your browser does not support the video tag.

Video 1: Demonstration of the 6.7 Inch AMOLED FHD+ Display quality.

## 3.2 Performance and Storage

The OUKITEL P1 is powered by the MediaTek Helio G99 chipset, which provides excellent graphics processing, gaming performance, and energy efficiency. It comes with 8GB of RAM, expandable up to 24GB, and 256GB of internal storage (ROM), expandable up to 2TB with an external memory card. This ample storage allows for thousands of photos, 4K videos, and applications.

# 24GB RAM + 256GB ROM



**24GB(8+16)**  
RAM

**256GB**  
ROM

**2TB**  
Expandable

**Octa-Core**  
Processor

Figure 3: Memory and Storage Capabilities

# MediaTek Helio G99

Gaming Performance ↑ CPU Performance ↑ Battery Efficiency ↑




Figure 4: MediaTek Helio G99 Processor

### 3.3 Camera System

Capture clear photos, scenic videos, and detailed portraits with the OUKITEL P1's versatile camera system. It features a 50MP main camera, a 32MP front camera for high-quality selfies, and a 2MP macro lens for close-up shots. The camera system is designed to produce bright images even in low-light conditions.



Figure 5: Camera System Overview

### 3.4 Battery and Connectivity

The OUKITEL P1 is equipped with a 5150mAh high-capacity battery, providing long-lasting performance for all-day usage. It supports 18W fast charging via a Type-C port and features OTG reverse charging, allowing the phone to act as a portable power bank for other devices. Connectivity options include Bluetooth, Wi-Fi, NFC, and Dual SIM 4G support.

# 5150mAh Large Battery



Figure 6: Battery Performance

# OUKITEL P1 Smartphone

Have unlimited enjoyment with  
powerful performance



Figure 7: Key Features Summary

## 4. SETUP

### 4.1 Inserting SIM Card and SD Card

1. Locate the SIM card tray on the side of the phone.
2. Insert the provided SIM ejector tool into the small hole next to the tray and push gently until the tray pops out.
3. Place your Nano-SIM card(s) and/or microSD card into the designated slots on the tray. Ensure the gold contacts are facing down.
4. Carefully push the tray back into the phone until it is flush with the device body.

### 4.2 Initial Power On and Setup Wizard

1. Press and hold the Power button (located on the side) until the OUKITEL logo appears.
2. Follow the on-screen instructions of the setup wizard to select your language, connect to Wi-Fi, set up your Google account, and configure security options (Face ID, Fingerprint, PIN, Pattern, Password).

3. The OUKITEL P1 runs on Android 14, offering an intuitive and customizable user experience.



Figure 8: Android 14 Operating System

## 5. OPERATING YOUR SMARTPHONE

### 5.1 Basic Navigation

- **Home Screen:** Swipe left or right to navigate between home screens.
- **App Drawer:** Swipe up from the bottom of the screen to access all installed applications.
- **Notifications & Quick Settings:** Swipe down from the top of the screen to view notifications and access quick settings toggles.

### 5.2 Making Calls and Sending Messages

- **Calls:** Tap the Phone icon, enter the number, and tap the call button.
- **Messages:** Tap the Messages icon, start a new conversation, enter the recipient and your message.

## 5.3 Using the Camera

To open the camera, tap the Camera icon on your home screen or app drawer. You can switch between the 50MP main camera and 32MP front camera, and select various modes like Portrait, Macro, and Beauty. Tap the shutter button to take a photo or record a video.

## 5.4 Security Features

The OUKITEL P1 supports multiple unlock options for enhanced security:

- **Face ID:** Register your face for quick and secure unlocking.
- **Fingerprint Sensor:** Use your fingerprint for biometric authentication.
- **PIN/Pattern/Password:** Standard unlock methods for additional security.

# 6. MAINTENANCE

## 6.1 Battery Care

- Avoid extreme temperatures, as they can degrade battery life.
- Use the original OUKITEL charger for optimal charging performance.
- For long-term storage, charge the battery to about 50% and power off the device.

## 6.2 Cleaning Your Device

- Use a soft, lint-free cloth to clean the screen and body.
- Avoid using harsh chemicals or abrasive materials.
- For stubborn smudges, slightly dampen the cloth with water or a screen cleaner.

## 6.3 Software Updates

Regularly check for software updates to ensure your device has the latest features, security patches, and performance improvements. Go to **Settings > System > System update** to check for available updates.

# 7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Phone does not turn on	Low battery; Software crash	Charge the phone for at least 30 minutes. Press and hold the Power button for 10-15 seconds to force restart.
Cannot connect to Wi-Fi	Incorrect password; Router issue; Phone Wi-Fi module issue	Verify Wi-Fi password. Restart your router. Toggle Wi-Fi off and on on your phone.
Apps crashing or freezing	Insufficient RAM; App bug; Outdated software	Close background apps. Clear app cache (Settings > Apps > [App Name] > Storage > Clear cache). Update the app or phone software.
Poor camera quality	Dirty lens; Low light conditions; Incorrect settings	Clean the camera lens with a soft cloth. Ensure adequate lighting. Adjust camera settings or try different modes.

If the problem persists, please contact OUKITEL customer service for further assistance.

## 8. SPECIFICATIONS

Feature	Detail
Model Name	OUKITEL P1
Operating System	Android 14
Display Size	6.7 Inches
Display Resolution	1080x2412
Refresh Rate	120 Hz
CPU Model	MediaTek Helio G99
CPU Speed	2.2 GHz
RAM Memory Installed Size	24 GB (8GB + 16GB expandable)
Memory Storage Capacity	256 GB (expandable up to 2TB)
Rear Camera	50 MP Main, 2 MP Macro, 0.3 MP Depth
Front Camera	32 MP
Battery Capacity	5150 Milliamp Hours
Charging Time	2.5 Hours (18W Fast Charging)
Connectivity Technologies	Bluetooth, Wi-Fi, NFC
Special Features	Stereo Speakers, Dual SIM, Built-In GPS, Face ID, Fingerprint Sensor
Product Dimensions	6.39 x 3 x 0.32 inches
Item Weight	15.8 ounces

## 9. WARRANTY AND SUPPORT

OUKITEL provides comprehensive support for the P1 smartphone:

- **2-Year Warranty:** The OUKITEL P1 comes with a 2-year warranty from the date of purchase.
- **30-Day Return Policy:** Enjoy a 30-day unconditional return policy.
- **Technical Support:** Long-term technical support is available for any issues you may encounter.
- **Customer Service:** 24-hour online customer service is provided to assist you.

For warranty claims or technical assistance, please visit the official OUKITEL website or contact their customer service team directly.