

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [PXN](#) /

› [PXN P5 Wireless Controller User Manual](#)

PXN P5

PXN P5 Wireless Controller User Manual

Model: P5

INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your PXN P5 Wireless Controller. Please read this manual thoroughly before use to ensure optimal performance and longevity of your device.

Package Contents

- PXN P5 Wireless Controller
- User Manual
- AA Battery (1)

PRODUCT FEATURES

- Multi-Platform Compatibility:** Supports Windows 10 and above, Android 11.0 and above, Nintendo Switch, and iOS devices.
- Wireless Connectivity:** Enjoy gaming without cables through reliable Bluetooth connection.
- Ergonomic Design:** Engineered for comfortable extended gameplay sessions.
- Precise Controls:** Responsive buttons and joysticks for accurate input.

CONTROLLER LAYOUT

Familiarize yourself with the buttons and components of your PXN P5 Wireless Controller.



This image displays the front view of the PNX P5 Wireless Controller, highlighting its primary buttons and joysticks. The controller features two analog sticks, a D-pad, ABXY action buttons, and various system buttons.

Button Descriptions

Button	Function
Left Analog Stick	Movement, camera control
Right Analog Stick	Camera control, aiming
D-Pad	Directional input
A/B/X/Y Buttons	Action commands
View Button (two overlapping squares)	Access in-game maps, inventory, or other information
Menu Button (three horizontal lines)	Access in-game menus, options
Share Button (two squares with arrows)	Capture screenshots or video clips
Home Button (house icon)	Return to system home screen
PNX Logo Button (center)	Power on/off, system menu access
Trigger Buttons (LT, RT)	Analog input for acceleration, firing
Bumper Buttons (LB, RB)	Digital input for various actions

BATTERY INSTALLATION

The PNX P5 Wireless Controller requires one AA battery for operation.

1. Locate the battery compartment on the back of the controller.
2. Press down on the tab and slide the battery cover open.
3. Insert one AA battery, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.

compartment.

4. Replace the battery cover by sliding it back into place until it clicks securely.

Note: Always use fresh, high-quality AA batteries. Remove batteries if the controller will not be used for an extended period.

SETUP AND CONNECTION

Powering On/Off

To power on the controller, press and hold the PNX Logo button (center) for 1-2 seconds. The indicator lights will illuminate. To power off, press and hold the PNX Logo button for 5 seconds until the lights turn off.

Connecting to PC (Windows 10 and above)

1. Ensure your PC has Bluetooth enabled.
2. On the controller, press and hold the PNX Logo button and the "X" button simultaneously for 3 seconds until the indicator lights flash rapidly, indicating pairing mode.
3. On your PC, go to "Settings" > "Devices" > "Bluetooth & other devices".
4. Click "Add Bluetooth or other device" and select "Bluetooth".
5. Select "PNX P5 Controller" from the list of available devices.
6. Once connected, the indicator light on the controller will become solid.

Connecting to Nintendo Switch

1. From the Nintendo Switch HOME Menu, select "Controllers" > "Change Grip/Order".
2. On the controller, press and hold the PNX Logo button and the "Y" button simultaneously for 3 seconds until the indicator lights flash rapidly.
3. The Switch will detect the controller. Once connected, the indicator light on the controller will become solid.

Connecting to Android Devices (11.0 and above)

1. Ensure Bluetooth is enabled on your Android device.
2. On the controller, press and hold the PNX Logo button and the "A" button simultaneously for 3 seconds until the indicator lights flash rapidly.
3. On your Android device, go to "Settings" > "Connected devices" > "Bluetooth".
4. Select "PNX P5 Controller" from the list of available devices.
5. Once connected, the indicator light on the controller will become solid.

Connecting to iOS Devices

1. Ensure Bluetooth is enabled on your iOS device.
2. On the controller, press and hold the PNX Logo button and the "B" button simultaneously for 3 seconds until the indicator lights flash rapidly.
3. On your iOS device, go to "Settings" > "Bluetooth".
4. Select "PNX P5 Controller" from the list of available devices under "Other Devices".
5. Once connected, the indicator light on the controller will become solid.

OPERATING INSTRUCTIONS

Basic Gameplay

Once connected, the controller functions as a standard gamepad for compatible games. Refer to your game's specific control settings for optimal configuration.

Indicator Lights

- Rapid Flashing:** Pairing mode.
- Solid Light:** Successfully connected.
- Slow Flashing:** Low battery warning.

MAINTENANCE AND CARE

- Clean the controller regularly with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Avoid exposing the controller to extreme temperatures, direct sunlight, or high humidity.
- Do not disassemble the controller. Unauthorized disassembly voids the warranty.
- Store the controller in a safe place when not in use to prevent damage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Controller does not power on.	Low or dead battery.	Replace the AA battery.
Controller does not connect to device.	Not in pairing mode; Bluetooth off; device out of range.	Ensure controller is in pairing mode (rapid flashing lights). Verify Bluetooth is enabled on your device. Move controller closer to the device.
Connection is unstable or disconnects frequently.	Interference; low battery.	Move away from other wireless devices. Replace the AA battery.
Buttons or joysticks are unresponsive.	Software issue; physical damage.	Restart the controller and the connected device. If problem persists, contact customer support.

If troubleshooting steps do not resolve the issue, please contact PXN customer support.

SPECIFICATIONS

- Model:** PXN P5
- Compatibility:** PC (Windows 10+), Android (11.0+), Nintendo Switch, iOS
- Connectivity:** Wireless (Bluetooth)
- Dimensions:** 6.1 x 2.35 x 4.2 inches
- Weight:** 7.7 ounces
- Power Source:** 1 x AA Battery (included)
- Manufacturer:** Shenzhen PXN Electronic Technology Co., Ltd
- Release Date:** November 1, 2024

WARRANTY AND SUPPORT

PXN products are designed and manufactured to the highest quality standards. For warranty information and customer support, please refer to the official PXN website or contact your retailer. Keep your purchase receipt for warranty claims. For further assistance, visit: [PXN Official Store on Amazon](#)