

[manuals.plus](#) /› [Kuizil](#) /› **Kuizil C16 Bluetooth 5.4 Wireless Earbuds User Manual**

Kuizil C16

Kuizil C16 Bluetooth 5.4 Wireless Earbuds User Manual

Model: C16

INTRODUCTION

Thank you for choosing the Kuizil C16 Bluetooth 5.4 Wireless Earbuds. This manual provides detailed instructions for setting up, operating, and maintaining your earbuds to ensure optimal performance and longevity. Please read this manual thoroughly before use.



Image: Kuizil C16 Bluetooth 5.4 Wireless Earbuds and their charging case. The earbuds feature ear hooks and touch control areas. The charging case displays battery levels.

PACKAGE CONTENTS

Ensure all items are present in the package:

- 1 x Charging Case
- 2 x Wireless Earbuds (Left and Right)
- 1 x USB-C Charging Cable
- 3 x Pairs of Ear Caps (S/M/L)
- 1 x User Manual

PARTI NELLA SCATOLA

1*CUSTODIA DI RICARICA

2*CUFFIE BLUETOOTH

1*CAVO DI RICARICA TIPO-C

3*CAPPELLI AURICOLARI (S/M/L)

1*MANUALE D'USO



Image: An illustration of the Kuizil C16 package contents, including the charging case, earbuds, USB-C cable, and various ear tip sizes.

PRODUCT OVERVIEW

The Kuizil C16 earbuds are designed for comfort and high-quality audio, featuring Bluetooth 5.4 connectivity, HiFi stereo sound, ENC noise cancellation, and IP7 waterproofing.

Key Features:

- Bluetooth 5.4:** Enhanced data transmission speed, reduced latency, and extended range up to 15 meters.
- HiFi Stereo Sound:** 13mm titanium diaphragm drivers with AAC/SBC audio coding for clear, powerful audio.
- ENC Noise Cancellation:** Four HD microphones detect and eliminate up to 80% of ambient noise for clear calls.
- Long Battery Life:** Up to 8 hours playtime per charge, with a total of 50 hours using the charging case.
- LED Digital Display:** Shows real-time battery status of the case and individual earbuds.
- Ergonomic Design:** Lightweight (3g per earbud) with soft ear hooks and multiple ear tip sizes for secure and comfortable fit.
- IP7 Waterproof:** Nano-coating protects against sweat and rain, suitable for sports.
- Smart Touch Control:** Manage music, calls, and voice assistant with simple taps.

POWERFUL BASS BALANCED SOUND

Balanced sound from powerful 13mm speaker drivers and semi-in-ear acoustics



Image: An exploded view of the earbud's internal structure, emphasizing the 13mm driver and the Bluetooth chip, alongside icons for HiFi sound, CVC 8.0 noise cancelling, and HD calls.

SETUP

1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and charging case.

- Connect the provided USB-C cable to the charging port on the case and a power source.
- The LED digital display on the case will show the charging progress.
- Earbuds will charge automatically when placed inside the case. Their individual battery levels will be shown on the case display.
- A full charge takes approximately 1.5 hours.

LONG BATTERY LIFE LED DIGITAL DISPLAY



Power of Case



Earbud Power Display



48 HRS
With Charging Case



8 HRS
Earbud Playtime



USB-C
Fast Charging

Image: The charging case with its LED display showing the battery percentage of the case and the charge status of the left and right earbuds. This image also highlights the 50-hour total playtime and USB-C fast charging.

2. Pairing with Your Device (One-Step Pairing)

The earbuds feature one-step automatic pairing.

1. Ensure Bluetooth is enabled on your device (smartphone, tablet, etc.).
2. Open the charging case and remove both earbuds. They will automatically power on and enter pairing mode.
3. On your device, search for Bluetooth devices and select "C16" from the list.
4. Once connected, you will hear a confirmation prompt, and the earbuds will be ready for use.
5. After the initial pairing, the earbuds will automatically connect to the last paired device when removed from the case.

AVANZATO BLUETOOTH 5.4 CHIP

Migliorare l'efficienza
della trasmissione dell'80%



Image: A visual representation of the advanced Bluetooth 5.4 chip, highlighting its features like improved transmission efficiency and extended range.

OPERATING INSTRUCTIONS

Wearing the Earbuds

For optimal sound quality and comfort, ensure the earbuds are worn correctly.

1. Choose the correct ear tip size (S/M/L) for a snug fit.
2. Place the ear hook over your ear.
3. Gently insert the earbud into your ear canal.
4. Adjust the earbud and hook until it feels secure and comfortable.

DESIGN FOR SPORTS

Let you enjoy your sports
Lightweight and ergonomic in-ear design



Image: A person using the earbuds during a workout, demonstrating the secure fit. Insets show the soft ear hooks, ergonomic design, and the three included ear tip sizes.

Smart Touch Controls

The earbuds feature intuitive touch controls on the outer surface of each earbud.

Function	Action
Play/Pause Music	Single tap on either earbud
Volume Up	Tap and hold on the Right earbud
Volume Down	Tap and hold on the Left earbud
Next Song	Double tap on the Right earbud
Previous Song	Double tap on the Left earbud
Answer/End Call	Single tap on either earbud
Reject Call	Tap and hold on either earbud
Activate Voice Assistant	Triple tap on either earbud



Image: A detailed diagram showing the touch control areas on the earbuds and the corresponding actions for music playback, call management, and voice assistant.

MAINTENANCE

Cleaning

- Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth.
- Remove ear tips and clean them with mild soap and water, then dry thoroughly before reattaching.
- Do not use abrasive cleaners or solvents.

Water Resistance (IP7)

The Kuizil C16 earbuds are IP7 waterproof, meaning they are protected against immersion in water up to 1 meter for 30 minutes. They are resistant to sweat and rain, making them suitable for workouts and outdoor activities.

- Do not intentionally submerge the earbuds in water for extended periods.
- Ensure the earbuds are dry before placing them back into the charging case to prevent damage.
- The charging case is not waterproof.

IP7 WATERPROOF & SWEATPROOF

No fear rain and sweat during sport



Rainy Day



Sweatproof



Splashproof



Image: The earbuds covered in water droplets, visually representing their IP7 waterproof and sweatproof capabilities, suitable for use in various conditions.

TROUBLESHOOTING

If you encounter issues, refer to the following common solutions:

Problem	Solution
Earbuds not pairing	<ul style="list-style-type: none">Ensure earbuds are charged.Turn off and on your device's Bluetooth.Forget "C16" from your device's Bluetooth list and re-pair.Place earbuds back in the case, close, then reopen and try again.

Problem	Solution
Only one earbud working	<ul style="list-style-type: none"> Ensure both earbuds are charged. Place both earbuds back in the charging case, close the lid for 5 seconds, then take them out simultaneously. If the issue persists, try resetting the earbuds (refer to manufacturer's website if specific reset instructions are not in this manual).
Low volume or poor sound quality	<ul style="list-style-type: none"> Adjust volume on both your device and the earbuds. Ensure ear tips are clean and correctly sized for a good seal. Check for obstructions in the earbud speaker mesh.
Earbuds not charging	<ul style="list-style-type: none"> Ensure the charging cable is securely connected. Check if the charging case has power. Clean the charging contacts on both the earbuds and the case.
Call quality issues (robotic voice)	<ul style="list-style-type: none"> Ensure earbuds are fully charged. Move closer to your connected device to improve signal strength. Check for environmental interference. Ensure microphones are not obstructed.

SPECIFICATIONS

Feature	Detail
Model	C16
Bluetooth Version	5.4
Wireless Range	Up to 15 meters
Earbud Playtime	Up to 8 hours (single charge)
Total Playtime (with case)	Up to 50 hours
Charging Time	Approx. 1.5 hours
Charging Port	USB-C
Driver Size	13mm Titanium Diaphragm
Noise Control	ENC (Environmental Noise Cancellation)
Microphones	4 HD Microphones
Water Resistance Rating	IP7 (Earbuds only)
Earbud Weight	Approx. 3g per earbud

Feature	Detail
Compatible Devices	iOS 9.0+, Android 5.0+, Bluetooth-enabled devices
Battery Type	Lithium Polymer (1 x 9V included)
Material	Plastic


WARRANTY AND SUPPORT

Kuizil products are designed and manufactured to the highest quality standards. For warranty information or technical support, please refer to the warranty card included in your package or visit the official Kuizil website. You may also contact customer service through your purchase platform.

For further assistance, please contact Kuizil customer support.

© 2024 Kuizil. All rights reserved.

Related Documents - C16

 Kuizil Q76-BY Wireless Earbuds: Quick Start Guide and Features	Learn how to use your Kuizil Q76-BY wireless earbuds, including touch controls, pairing, charging, and Bluetooth connectivity. This guide provides essential information for sports and workout use.
 HD65 True Wireless Earbuds - User Manual & Features	Discover the HD65 True Wireless Earbuds by Kuizil. This comprehensive guide covers pairing, functions, charging, product specifications, and FAQs for these Hi-Fi, sports-ready, IPX7 waterproof earbuds with Bluetooth 5.4 and long battery life.
 C16 True Wireless Stereo Earphones User Guide	User guide for C16 True Wireless Stereo Earphones, covering specifications, setup, functions, charging, maintenance, and troubleshooting.
 Occiam C16 True Wireless Earbuds User Manual	Comprehensive user manual for Occiam C16 True Wireless Earbuds, covering setup, Bluetooth connection, controls, charging, specifications, troubleshooting, and FCC compliance.