

[Manuals.plus](#) /

› [BVXZIOP](#) /

› BVXZIOP X10 Plus Retro Game Console with Projector User Manual

BVXZIOP X10 Plus

BVXZIOP X10 Plus Retro Game Console with Projector User Manual

INTRODUCTION

Welcome to the user manual for your BVXZIOP X10 Plus Retro Game Console with Projector. This device combines a portable projector with a retro gaming system, offering a versatile entertainment experience. It features 4K HD projection, over 10,000 pre-installed games, 2.4G wireless controllers, and Wi-Fi connectivity for streaming and screen mirroring. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your device to ensure optimal performance and enjoyment.



Image: The BVXZIOP X10 Plus projector, two wireless controllers, remote control, power cable, and quick installation guide.

COMPONENTS INCLUDED

Please verify that all the following items are included in your package:

- 1 x BVXZIOP X10 Plus Projector
- 2 x 2.4G Wireless Controllers
- 1 x Remote Control
- 1 x Power Cable
- 1 x Quick Installation Guide (Manual)
- 1 x Game Stick (integrated)

SETUP GUIDE

1. Powering On

1. Connect the power cable to the projector's power input port.
2. Plug the other end of the power cable into a suitable power outlet.
3. Press the power button on the projector or the remote control to turn on the device.

2. Connecting Wireless Controllers

The X10 Plus comes with two 2.4G wireless controllers. These controllers are designed for high sensitivity and ease of use, requiring no complex installation.

- Ensure the controllers have fresh batteries installed (1 'A' battery required per controller, not included).
- The controllers should automatically pair with the projector upon startup. If not, refer to the troubleshooting section.



Image: Detailed view of the wireless controller, highlighting buttons for 'Open Search', 'Collect', 'Quit Game (Select+Start)', 'Back', 'Verify', and 'Start/Select'.

3. Projector Placement and Adjustment

Place the projector on a stable, flat surface. The 180-degree free projection feature allows you to adjust the projection angle to suit your viewing needs, whether on a wall or ceiling. Adjust the focus ring on the projector lens

until the image is clear.

4. Initial System Configuration

Upon first power-on, the projector will guide you through initial setup steps, including:

- **Language Selection:** Choose your preferred language.
- **Wi-Fi Connection:** Connect the projector to your home Wi-Fi network for access to online features and streaming applications.
- **Time and Date Settings:** Configure the correct time and date.



Image: The Android 11.0 OS interface, showcasing various applications and a clean user experience.

OPERATING INSTRUCTIONS

1. Navigating the Interface

The X10 Plus operates on Android 11.0 OS. Use the remote control or the wireless game controllers to navigate through menus, select applications, and adjust settings. The interface is designed to be intuitive for easy access to

games, streaming services, and other features.

2. Playing Retro Games

The device comes pre-loaded with over 10,000 retro games across 9+ simulators. To access and play games:

1. From the main menu, select the 'Games' or 'Retro Games' section.
2. Browse through the available game titles or use the search function to find specific games. The search function allows you to add spaces to search for games.
3. Select a game to start playing. The 2.4G wireless controllers provide a responsive gaming experience.
4. To quit a game, press the 'SELECT' and 'START' buttons simultaneously on the controller.



Image: A user engaging in gameplay, with the X10 Plus projector displaying a game on a large screen, controlled by a wireless gamepad.

3. Streaming Media

With Wi-Fi connectivity, you can access various streaming applications directly from the projector's Android interface. Popular apps like YouTube, Netflix, and others are available for a wide range of entertainment options.

4. Screen Mirroring

The X10 Plus supports convenient screen mirroring, allowing you to project content from your smartphone, tablet, or computer wirelessly.

1. Ensure your mobile device or computer and the projector are connected to the same Wi-Fi network.
2. On the projector, select the 'Screen Mirroring' application.
3. On your mobile device or computer, activate the screen mirroring feature (e.g., 'Smart View' on Android, 'Screen Mirroring' on iOS, or 'Cast' on Windows/Chrome).
4. Select the X10 Plus projector from the list of available devices to begin mirroring.



Image: A smartphone displaying a basketball game, which is simultaneously being mirrored and projected onto a larger screen by the X10 Plus projector.

5. Product Demonstration Video

Your browser does not support the video tag.

Video: A short demonstration showcasing the BVXZIOP X10 Plus projector's capabilities, including its ease of setup, seamless streaming of Netflix and YouTube, and immersive gaming experience with vibrant colors. It highlights how the device can enhance

MAINTENANCE

To ensure the longevity and optimal performance of your BVXZIOP X10 Plus projector and game console, follow these maintenance guidelines:

- **Cleaning the Lens:** Gently wipe the projector lens with a soft, lint-free cloth specifically designed for optical surfaces. Avoid using abrasive materials or harsh chemicals.
- **Cleaning the Device:** Use a soft, dry cloth to clean the exterior of the projector and controllers. Do not use liquid cleaners directly on the device.
- **Ventilation:** Ensure the projector's ventilation ports are clear of dust and obstructions to prevent overheating.
- **Storage:** When not in use for extended periods, store the device in a cool, dry place away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

If you encounter issues with your BVXZIOP X10 Plus, refer to the following common problems and solutions:

- **No Power:**
 - Ensure the power cable is securely connected to both the projector and the power outlet.
 - Verify that the power outlet is functional.
- **No Image Projected:**
 - Check if the projector is powered on.
 - Adjust the focus ring to ensure the image is not simply out of focus.
 - Ensure no lens cap is covering the projector lens.
- **Blurry Image:**
 - Rotate the focus ring on the projector until the image becomes sharp.
 - Ensure the projection surface is flat and smooth.
- **Controllers Not Connecting/Responding:**
 - Check if the controllers have fresh batteries.
 - Restart the projector and controllers to re-establish the connection.
 - Ensure no strong interference sources are nearby.
- **Wi-Fi Connection Issues:**
 - Verify that your Wi-Fi network is active and working correctly.
 - Re-enter the Wi-Fi password to ensure it is correct.
 - Move the projector closer to your Wi-Fi router to improve signal strength.

PRODUCT SPECIFICATIONS

Feature	Specification
---------	---------------

Feature	Specification
Brand	BVXZIOP
Model Name	X10 Plus
Product Dimensions	7.09 x 3.86 x 7.87 inches
Item Weight	4.11 pounds
Item Model Number	X10 Plus
Manufacturer Recommended Age	5 years and up
Batteries Required	1 A battery (for remote, controllers require separate batteries)
Platform	Android
Input Device	Gamepad
Color	White

WARRANTY AND SUPPORT

For warranty information, technical support, or any inquiries not covered in this manual, please contact BVXZIOP customer service through the retailer where the product was purchased or refer to the official BVXZIOP website for contact details. Please have your product model number (X10 Plus) and purchase information ready when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DPQSLC2S>

More documents and user manuals: <https://manuals.plus/>