

[Manuals.plus](#) /

› [DERCASS](#) /

› DERCASS Platform Bed with Multi-Storage Headboard, USB, and Drawers (King, White) - Instruction Manual

DERCASS GX000400A

DERCASS Platform Bed with Multi-Storage Headboard, USB, and Drawers (King, White)

Instruction Manual

INTRODUCTION

Thank you for choosing the DERCASS Platform Bed. This manual provides essential information for the safe assembly, operation, and maintenance of your new bed frame. Please read these instructions carefully before beginning assembly and retain them for future reference.

This King-size platform bed features a multi-storage headboard with integrated USB ports and power outlets, along with two under-bed storage drawers. It is designed for use without a box spring.



Image: The DERCASS King Platform Bed in white, featuring a multi-storage headboard, integrated USB ports, and under-bed drawers.

SAFETY INFORMATION

- Ensure all parts are present and undamaged before assembly.
- Do not use power tools for assembly unless specifically instructed, as this may overtighten fasteners and damage the wood.
- Assemble on a soft, clean surface to prevent scratches.
- Keep small parts away from children during assembly.
- Periodically check and tighten all connections to ensure stability.
- Do not exceed the recommended weight capacity of 600 lbs.
- Only use mattresses with a thickness of 8-10 inches.

SETUP AND ASSEMBLY

Assembly of your DERCASS Platform Bed requires two adults. Please follow the step-by-step instructions provided in the separate

assembly guide included with your packaging. Ensure all components are accounted for before starting.

Package Contents:

- Sub-item 1: 84 x 12.9 x 4.5 in. (approx. 55.12 lbs)
- Sub-item 2: 79.3 x 12.9 x 4.2 in. (approx. 55.12 lbs)
- Sub-item 3: 48.45 x 21.9 x 5.7 in. (approx. 66.14 lbs)
- All necessary hardware and tools (usually an Allen wrench).

Key Assembly Steps (General Overview):

1. Unpack all components and verify against the parts list.
2. Assemble the headboard structure, including the storage shelves and USB/power outlet unit.
3. Assemble the side rails and footboard.
4. Attach the headboard to the side rails.
5. Install the center support beam and legs.
6. Place the wooden slats across the bed frame.
7. Assemble the two under-bed drawers and slide them into position.



Image: Exploded view of the DERCASS King Platform Bed components, showing the headboard, frame, slats, and drawers.



Image: Close-up of the DERCASS King Platform Bed frame with wooden slats installed, ready for a mattress.

OPERATING INSTRUCTIONS

Multi-Storage Headboard:

The headboard features multiple open shelves for convenient storage of books, decor, or personal items. The integrated unit includes 2 standard plug outlets and 2 USB ports for charging mobile phones, tablets, or other electronic devices. Ensure the bed is plugged into a functional wall outlet for the charging features to work.



Image: Close-up view of the DERCASS King Platform Bed's headboard, highlighting the integrated USB ports and standard power outlets.

Under-Bed Drawers:

Two spacious drawers are located under the bed frame, one on each side. These drawers provide additional storage for bedding, clothing, or other items. They are designed to slide smoothly on their tracks for easy access.

SIZE: INCH




Image: The DERCASS King Platform Bed with one under-bed drawer partially open, revealing its storage capacity.

MAINTENANCE

Cleaning:

Wipe the bed frame with a dry, soft cloth. For stubborn marks, a slightly damp cloth can be used, followed immediately by a dry cloth. Avoid abrasive cleaners or harsh chemicals, as these can damage the finish.

Hardware Check:

Periodically (e.g., every 3-6 months), check all bolts, screws, and fasteners to ensure they are tight. Re-tighten if necessary to maintain the bed's stability and structural integrity.

TROUBLESHOOTING

- **Squeaking Noises:**

Check all bolts and screws for tightness. Ensure the slats are properly seated and evenly distributed. If the issue persists, disassemble and reassemble the affected section, ensuring all connections are secure.

- **USB Ports/Outlets Not Working:**

Verify that the bed's power cord is securely plugged into a functional wall outlet. Check for any tripped circuit breakers. If the issue continues, contact customer support.

- **Drawers Sticking:**
Ensure the drawers are correctly aligned on their tracks. Check for any obstructions or debris in the drawer slides. Lightly lubricate the drawer slides if necessary.
- **Bed Frame Instability:**
Re-check all assembly points, ensuring every bolt and screw is fully tightened. Make sure the bed is on a level surface.

SPECIFICATIONS

Feature	Detail
Brand	DERCASS
Model Number	GX000400A
Size	King
Color	White
Overall Product Dimensions	91"L x 78.3"W x 43.8"H
King Bed Dimensions	80.7" x 76.3"
Total Height	43.8"
Material	Pine Wood + MDF
Number of Bed Slats	10 pcs
Recommended Mattress Thickness	8"-10"
Overall Product Weight	165.5 lbs
Bed Weight Capacity	600 lbs
Included Components	Drawer, Platform Bed Frame, Slat, Storage Headboard, USB Port
Assembly Required	Yes
Origin	Vietnam



Image: Detailed diagram showing all key dimensions of the DERCASS King Platform Bed in inches.

WARRANTY INFORMATION

Specific warranty details are typically provided with your purchase documentation or on the manufacturer's official website. Please refer to those resources for comprehensive warranty coverage and terms. Generally, products are covered against manufacturing defects for a limited period from the date of purchase.

CUSTOMER SUPPORT

If you have any questions regarding the assembly, operation, or maintenance of your DERCASS Platform Bed, please contact our customer support team. Refer to your purchase receipt or the product packaging for specific contact details. For general inquiries or to report missing/damaged parts, please reach out to the seller directly through the platform where the purchase was made. We are committed to resolving any issues promptly.

Online Support: Visit the DERCASS brand page on Amazon for FAQs and additional product information:[DERCASS Amazon Store](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question