

[Manuals.plus](#) /

› [SoarFlash](#) /

› SoarFlash Leather Bar Stool Instruction Manual

SoarFlash W1143P168319

SoarFlash Leather Bar Stool Instruction Manual

Model: W1143P168319

Brand: SoarFlash

IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before assembly and use. Keep this manual for future reference.

- Ensure all parts are present and undamaged before beginning assembly.
- Do not use power tools for assembly as this may overtighten screws and cause damage.
- Place the stool on a flat, stable surface during assembly and use.
- Do not stand on the stool.
- Do not exceed the maximum weight capacity.
- Keep small parts away from children during assembly.
- Periodically check all connections and tighten as necessary.

PACKAGE CONTENTS

Verify that all components listed below are included in your package:

Item	Description	Quantity
A	Seat Cushion	2
B	Gas Lift Cylinder	2
C	Footrest Ring	2
D	Base Plate	2
E	Screws/Bolts	(Various)
F	Allen Wrench	1

SETUP: ASSEMBLY INSTRUCTIONS

Estimated assembly time: Approximately 20 minutes per stool.

Step 1: Attach Seat to Gas Lift Mechanism

Carefully align the seat cushion (A) with the mounting plate on the top of the gas lift cylinder (B). Secure using the provided screws/bolts (E) and Allen wrench (F). Ensure the handle for height adjustment is accessible.

ADJUSTABLE SEAT HEIGHT



This image illustrates the adjustable seat height mechanism, highlighting the upgraded metal handle for easy height adjustment.

Step 2: Assemble Base and Footrest

Insert the footrest ring (C) into the designated slot on the gas lift cylinder (B). Ensure it is securely in place. Then, place the gas lift cylinder (B) into the center hole of the base plate (D). The base plate provides stability and features a wide

chrome finish.



This image details the ergonomic features of the bar stool, including the 360-degree smooth swivel, the stable footrest, and the wide chrome base for enhanced stability.

Step 3: Final Check

Once assembled, gently test the stool for stability. Ensure all connections are tight and the stool operates smoothly. Repeat the process for the second stool.



A view of two fully assembled SoarFlash leather bar stools, ready for use in a kitchen or bar area.

OPERATING INSTRUCTIONS

Adjusting Seat Height

To adjust the seat height, locate the metal handle beneath the seat.

- **To raise the seat:** While standing, lift the handle. The seat will automatically rise. Release the handle at the desired height.
- **To lower the seat:** While seated, lift the handle. The seat will lower under your weight. Release the handle at the desired height.

The adjustable range is approximately 33.9 inches to 43.3 inches from the floor to the top of the backrest.

360° Swivel Function


The bar stool features a 360-degree swivel function, allowing for easy rotation in any direction. Simply rotate the seat to your desired position. This feature provides flexibility and ease of movement.

Using the Footrest

The integrated footrest ring provides a comfortable place to rest your feet, enhancing comfort during prolonged sitting. Ensure your feet are placed securely on the footrest.

Counter Height Compatibility

These bar stools are designed to be compatible with various counter heights. Refer to the diagram below to determine the ideal stool height for your counter.



This diagram helps in selecting the appropriate bar stool height based on your counter or bar height, ensuring optimal comfort.

MAINTENANCE AND CARE

Cleaning the Leather Upholstery

The PU leather upholstery is designed to be stain-resistant and waterproof.

- For general cleaning, wipe the surface with a soft, damp cloth.
- For spills or stains, wipe immediately with a damp cloth. Avoid abrasive cleaners or harsh chemicals, as these can damage the material.
- Allow the surface to air dry completely after cleaning.



PU LEATHER

HIGH QUALITY MATERIAL



SOFT SPONGE



Skin Friendly



Water Resistant



This image highlights the quality of the materials used, specifically the durable PU leather and the soft sponge padding, which contribute to the stool's comfort and ease of maintenance.

Metal Components Care

The metal leg and base are silver-plated.

- Wipe metal parts with a soft, dry cloth to remove dust and fingerprints.
- Avoid using abrasive cleaners or polishes that could scratch or tarnish the finish.

Regular Inspection

Periodically inspect all screws and connections to ensure they remain tight. Re-tighten any loose fasteners to maintain stability and safety.

Stool is Wobbly

- **Solution:** Check all screws and bolts. Ensure they are fully tightened. Make sure the base plate is on a flat, even surface.

Height Adjustment Not Working

- **Solution:** Ensure the gas lift cylinder is correctly installed and not obstructed. If the issue persists, the gas lift may need replacement. Contact customer support.

Difficulty Swiveling

- **Solution:** Check for any obstructions around the swivel mechanism. Ensure the stool is not overloaded.

SPECIFICATIONS

Feature	Detail
Product Dimensions	17.7"D x 20.7"W x 43.3"H (Max Height)
Adjustable Height Range	33.9" - 43.3" (from floor to top of backrest)
Color	Grey
Brand	SoarFlash
Material (Upholstery)	PU Leather
Material (Frame/Base)	Silver Plated Metal
Assembly Required	Yes
Number of Items	2 (Set of 2)
Item Weight	19.8 pounds (per stool)
Model Number	W1143P168319
Country of Origin	China

PRODUCT SIZE

Suitable chair height makes you more relaxed



This diagram provides precise measurements for the bar stool, including seat width, depth, and adjustable height range, to help with placement and fit.

WARRANTY AND SUPPORT

For any issues, damages, or inquiries regarding your SoarFlash Leather Bar Stool, please contact the manufacturer directly. While specific warranty details are not provided in this manual, SoarFlash is committed to assisting customers with product-related concerns.

Please refer to your purchase documentation or the seller's information for specific warranty terms and contact details.

Manufacturer: SoarFlash

For support, you may visit the [SoarFlash Store on Amazon](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question